MITSUBISHI ELECTRIC TRANE HVAC US

SPLIT-TYPE AIR CONDITIONERS



November 2024

No. OCHT810 REVISED EDITION-C

TECHNICAL & SERVICE MANUAL


<Outdoor unit>
[Model Name]

NTXMSM36A142BA NTXMSM48A182BA NTXMSM60A182BA NTXMSH36A142BA NTXMSH42A152BA NTXMSH48A182BA

Revision:

 Some descriptions have been revised in REVISED EDITION-C.

OCHT810B is void.



CONTENTS

1	. SAFETY PRECAUTION2
2	. OVERVIEW OF UNITS5
3	. SPECIFICATIONS 11
4	. DATA······14
5	. OUTLINES AND DIMENSIONS 36
6	. WIRING DIAGRAM ····· 37
7	. NECESSARY CONDITIONS
	FOR SYSTEM CONSTRUCTION 40
	. TROUBLESHOOTING 55
9	. ELECTRICAL WIRING ······133
10	. REFRIGERANT PIPING TASKS ······139
11	. DISASSEMBLY PROCEDURE ······147
12	REMOTE CONTROLLER168

PARTS CATALOG (OCBT810)

1

SAFETY PRECAUTION

1-1. ALWAYS OBSERVE FOR SAFETY

Before obtaining access to terminal, all supply circuit must be disconnected.

Preparation before the repair service

- Prepare the proper tools.
- Prepare the proper protectors.
- Provide adequate ventilation.
- After stopping the operation of the air conditioner, turn off the power-supply breaker.
- Discharge the condenser before the work involving the electric parts.

Precautions during the repair service

- Do not perform the work involving the electric parts with wet hands.
- Do not pour water into the electric parts.
- Do not touch the refrigerant.
- Do not touch the hot or cold areas in the refrigerating cycle.
- When the repair or the inspection of the circuit needs to be done without turning off the power, exercise great caution not to touch the live parts.
- When opening or closing the valve below freezing temperatures, refrigerant may spurt out from the gap between the valve stem and the valve body, resulting in injuries.

1-2. CAUTIONS RELATED TO NEW REFRIGERANT

Cautions for units utilizing refrigerant R410A

Use new refrigerant pipes.

Avoid using thin pipes.

Make sure that the inside and outside of refrigerant piping is clean and it has no contaminants such as sulfur, oxides, dirt, shaving particles, etc...

which are hazard to refrigerant cycle. In addition, use pipes with specified thickness.

Contamination inside refrigerant piping can cause deterioration of refrigerant oil, etc.

Follow the instructions below to prevent abrasive components contained in sandpaper and cutting tools from entering the refrigerant circuit because those components can cause failures of the compressor and valves.

- To deburr pipes, use a reamer or other deburring tools, not sandpaper.
- To cut pipes, use a pipe cutter, not a grinder or other tools that use abrasive materials.
- When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes.
- If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.

Store the piping indoors, and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Use a vacuum pump with a reverse flow check valve.

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil, etc.

Use the following tools specifically designed for use with R410A refrigerant.

The following tools are necessary to use R410A refrigerant.

Tools for R410A						
Gauge manifold	Flare tool					
Charge hose	Size adjustment gauge					
Gas leak detector	Vacuum pump adaptor					
Torque wrench	Electronic refrigerant charging scale					

Handle tools with care.

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Do not use a charging cylinder.

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.

The refrigerant oil applied to flare and flange connections must be ester oil, ether oil or alkylbenzene oil in a small amount.

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil, etc.

Charge refrigerant from liquid phase of gas cylinder.

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

Do not use refrigerant other than R410A.

If other refrigerant (R22, etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil, etc.

Use the specified refrigerant only.

Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of. Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

Do not pump down the system when a gas leak has been detected.

The intake of air or other gases causes abnormally high pressure in the refrigeration cycle, which may cause explosion or injury.


[1] Cautions for service

- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) If moisture or foreign matter might have entered the refrigerant piping during service, ensure to remove them.

[2] Additional refrigerant charge

When charging directly from cylinder

- (1) Check that cylinder for R410A on the market is a syphon type.
- (2) Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)



[3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.

No.	Tool name	Specifications				
1	Gauge manifold	· Only for R410A				
		· Use the existing fitting specifications. (UNF1/2)				
		· Use high-tension side pressure of 768.7 PSIG [5.3 MPa.G] or over.				
2	Charge hose	· Only for R410A				
		· Use pressure performance of 738.2 PSIG [5.09 MPa.G] or over.				
3	Electronic weighing scale	_				
4	Gas leak detector	· Use the detector for R134a, R407C or R410A.				
(5)	Adaptor for reverse flow check	· Attach on vacuum pump.				
6	Refrigerant charge base	_				
7	Refrigerant cylinder	· Only for R410A · Top of cylinder (Pink)				
		· Cylinder with syphon				
8	Refrigerant recovery equipment					

Cautions for refrigerant piping work

New refrigerant R410A is adopted for replacement inverter series. Although the refrigerant piping work for R410A is same as for R22, exclusive tools are necessary so as not to mix with different kind of refrigerant. Furthermore as the working pressure of R410A is 1.6 times higher than that of R22, their sizes of flared sections and flare nuts are different.

Thickness of pipes

Because the working pressure of R410A is higher compared to R22, be sure to use refrigerant piping with thickness shown below. (Never use pipes of 7/256 in [0.7 mm] or below.)


1 Diagram below: Piping diameter and thickness

Nominal	Outside	Thickness	: in [mm]
dimensions (in)	diameter (mm)	R410A	R22
1/4	ø6.35	1/32 [0.8]	1/32 [0.8]
3/8	ø9.52	1/32 [0.8]	1/32 [0.8]
1/2	ø12.70	1/32 [0.8]	1/32 [0.8]
5/8	ø15.88	5/128 [1.0]	5/128 [1.0]
3/4	ø19.05	5/128 [1.0]*	5/128 [1.0]

*Use 1/2 H or H pipes.

2 Dimensions of flare cutting and flare nut

The component molecules in HFC refrigerant are smaller compared to conventional refrigerants. In addition to that, R410A is a refrigerant, which has higher risk of leakage because its working pressure is higher than that of other refrigerants. Therefore, to enhance airtightness and strength, flare cutting dimension of copper pipe for R410A has been specified separately from the dimensions for other refrigerants as shown below. The dimension B of flare nut for R410A also has partly been changed to increase strength as shown below. Set copper pipe correctly referring to copper pipe flaring dimensions for R410A below. For 1/2 and 5/8 inch pipes, the dimension B changes. Use torque wrench corresponding to each dimension.







Flare cutting dimensions

Unit : in [mm]

Nominal	Outside	Dimensio	on A (-8.4)		
dimensions (in)	diameter (mm)	R410A	R22		
1/4	ø6.35	11/32-23/64 [9.1]	9.0		
3/8	ø9.52	1/2-33/64 [13.2]	13.0		
1/2	ø12.70	41/64-21/32 [16.6]	16.2		
5/8	ø15.88	49/64-25/32 [19.7]	19.4		
3/4	ø19.05	_	23.3		

Flare nut dimensions

Unit: in [mm]

Nominal	Outside	Dimens	sion B
dimensions (in)	diameter (mm)	R410A	R22
1/4	ø6.35	43/64 [17.0]	17.0
3/8	ø9.52	7/8 [22.0]	22.0
1/2	ø12.70	1-3/64 [26.0]	24.0
5/8	ø15.88	1-9/64 [29.0]	27.0
3/4	ø19.05	_	36.0

③ Tools for R410A (The following table shows whether conventional tools can be used or not.)

Tools and materials	Use	R410A tools	Can R22 tools be used?	Can R407C tools be used?
Gauge manifold	Air purge, refrigerant charge	Tool exclusive for R410A	×	×
Charge hose	and operation check	Tool exclusive for R410A	×	×
Gas leak detector	Gas leak check	Tool for HFC refrigerant	×	0
Refrigerant recovery equipment	Refrigerant recovery	Tool exclusive for R410A	×	×
Refrigerant cylinder	Refrigerant charge	Tool exclusive for R410A	×	×
Applied oil	Apply to flared section	Ester oil, ether oil and	×	Ester oil, ether oil: O
		alkylbenzene oil (minimum amount)		Alkylbenzene oil: minimum amount
Safety charger	Prevent compressor malfunction	Tool exclusive for R410A	×	×
	when charging refrigerant by			
	spraying liquid refrigerant			
Charge valve	Prevent gas from blowing out	Tool exclusive for R410A	×	×
	when detaching charge hose			
Vacuum pump	Vacuum drying and air	Tools for other refrigerants can	△ (Usable if equipped	△ (Usable if equipped
	purge	be used if equipped with adop-	with adopter for rever-	`with adopter for rever-
	. 3	ter for reverse flow check	se flow)	se flow)
Flare tool	Flaring work of piping	Tools for other refrigerants		△ (Usable by adjusting
		can be used by adjusting	flaring dimension)	flaring dimension)
		flaring dimension	,	,
Bender	Bend the pipes	Tools for other refrigerants can be used		0
Pipe cutter	Cut the pipes	Tools for other refrigerants can be used		0
Welder and nitrogen gas cylinder	Weld the pipes	Tools for other refrigerants can be used		0
Refrigerant charging scale	Refrigerant charge	Tools for other refrigerants can be used	0	0
Vacuum gauge or thermis-	Check the degree of vacuum. (Vacuum	Tools for other refrigerants	0	0
tor vacuum gauge and	valve prevents back flow of oil and refri-	can be used		
vacuum valve	gerant to thermistor vacuum gauge)			
Charging cylinder	Refrigerant charge	Tool exclusive for R410A	×	_

 $[\]times$: Prepare a new tool. (Use the new tool as the tool exclusive for R410A.)


 $[\]triangle$: Tools for other refrigerants can be used under certain conditions.

O: Tools for other refrigerants can be used.

OVERVIEW OF UNITS

2-1. Auxiliary HEATING ON/OFF CONTROL SET-UP

- (1) Auxiliary heating operation controls another heat source that depends on the main system's operations, which means the interlock operation shown in "b)" will be possible.
- a) Indoor unit must be R410A UL model for this function to operate.
- b) Different Indoor unit applications that can be applied:



(2) Outdoor unit DIPSW5-4 for auxiliary heating control:

Set DIPSW5-4 when power is turned off at unit.

OFF: Disable auxiliary Heating Function (Initial setting)

ON: Enable auxiliary Heating Function

(3) Determine required indoor fan speed during defrost mode:

To set the fan speed, see the chapter referring to heater control in the indoor unit's Technical & Service Manual.


(4) Determine fan speed setting during indoor thermo-OFF conditions:

- a) These settings are done within Indoor DIPSW1-7 and DIPSW1-8, see chart below for options.
- b) Recommended SW1-7 OFF and SW1-8 ON will determine airflow based on "Setting on the remote controller".

Auxiliary sig		Fan speed setting	Fan speed setting		
Thermo c	ondition	OFF	ON		
SW1-7	SW1-8				IC2 IC1 RA21°C
OFF	OFF	Very low	Setting on remote controller	20°C 20°C Thermo - ON Ther	20°C Thermo - OFF
ON	OFF	Low	Controller	The first of the f	
OFF	ON	Setting on remote controller			—Baseboard Heating—
ON	ON	Stopped			

(5) Setting outdoor unit and auxiliary heat switch over temperatures

When the DIPSW 5-4 is set to "ON", the outdoor unit and the contact output operates as shown below. a)Outdoor default setting and operations are shown below:



When the set temperature ranges overlap, the previously set pattern (1, 2 or 3) has a priority. The stage 1 has the highest priority, 2 the second and then 3.

b) Based on above chart listed the sequence of operation on "On ambient decrease"

/ Stage 1: (TH7 ≥ 50°F [10°C]): the outdoor unit runs in HP mode.

Stage 2: (TH7 = 50 to −13°F [10 to −25°C]): the outdoor unit runs in HP mode with auxiliary heating.

\text{Stage 3: (TH7 ≤ −13°F [−25°C]): Auxiliary heating only (Outdoor unit is OFF).}


c) Based on above chart listed the sequence of operation on "On ambient increase"

Stage 3: (TH7 \leq 32°F [0°C]): Auxiliary heating only (Outdoor unit is OFF). Stage 2: (TH7 \geq 32 to 68°F [0 to 20°C]): Auxiliary heating with outdoor unit in HP mode. Stage 1: (TH7 \geq 68°F [20°C]): Outdoor unit in HP mode only.

(6) Locally procured wiring

A basic connection method is shown.

(i.e. interlocked operation with the electric heater with the fan speed setting on high)



Outdoor unit control board

Dip switch SW5-4 "ON"

For relay X use the specifications given below operation coil

Rated voltage: 12 V DC

Power consumption: 0.9 W or less

*Use the diode that is recommended by the relay manufacturer at both ends of the relay coil.

The length of the electrical wiring for the PAC-YU24HT is 2 meters (6-1/2 ft)


To extend this length, use sheathed 2-core cable.

Control cable type: CVV, CVS, CPEV, or equivalent.

Cable size: 0.5 mm² to 1.25 mm² (AWG22 to AWG16)

Do not extend the cable more than 10 meters (32 ft).

Recommended circuit



2-2. SYSTEM CONSTRUCTION

Outdoor unit		4HP	4.5HP 5HP		7HP		
		NTXMSM36A142BA NTXMSH36A142BA	NTXMSH42A152BA		NTXMSM60A182BA		
Applicable	Capacity	04 to 36	04 to	04 to 54			
indoor unit	Max. No. of units	11					
	Total system capacity range	50 to 130% of outdoor unit capacity					

	•	/		
Model name	CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E	
Number of branches	2	4	8	

								<u> </u>									
						Conne	ctable in	idoor uni	t lineup								
Model type		Model nam	е	04	05	06	08	12	15	18	24	27	30	36	48	54	72
Ceiling Cassette	4-way flow	TPLFYP	EM14**					•	•	•	•		•	•	•		
	2 by 2	TPLFYP	FM14**		•		•	•	•	•							
	1-way flow	TPLFYP	BM14**			•	•	•	•								
Ceiling Concealed		TPEFYP	MA14**			•	•	•	•	•	•	•	•	•	•	•	
			MS14**			•	•	•	•	•	•						
			MH14**						•	•	•	•	•	•	•	•	
			MH140*														•*
Wall Mounte	d	TPKFYP	KM14**								•		•				
			LM14**	•		•	•	•	•	•							
Ceiling Susp	ended	TPCFYP	KM14**						•		•		•	•			
Floor standing	Exposed	TPFFYP	CS14**			•	•	•	•	•	•						
3	Concealed		RE14**			•	•	•	•	•	•						
Multi-position air handling unit		TPVFYP	AM14**				•	•		•	•		•	•	•	•	

^{*} Only NTXMSM60 is connectable.

Remote controller	Name	M-NET remote controller	MA remote controller
	Model number	PAR-F27MEA-E, TAR-U01MEDU	TAR-40MAA
	Functions	A handy remote controller for use in conjunction with the Melans centralized management system. Addresses must be set.	Addresses setting is not necessary.

2-3 SYSTEM CONSTRUCTION(BRANCH BOX SYSTEM)

		`	,			
Outdoor unit	Model name	Model name NTXMSM36A142BA NTXMSH42A152BA NTXMSH48A182BA NTXMSH48A182BA				
	Horse power	4HP	4.5HP	5HP	7HP	
Applicable	Capacity class	Type 06 to Type 36				
indoor unit		Caution: The indoor unit 36 kBtu/ h (Type	which rated capacity e e 36) can NOT be con			
	Max. No. of units	4	5	8	8	
	Total system capacity range	33 to 130% of outdoor unit capacity	29 to 130% of outdoor unit capacity	25 to 130% of outdoor unit capacity	20 to 130% of outdoor unit capacity	
		12 to 46.8 kBtu/h	12 to 54.6 kBtu/h	12 to 62.4 kBtu/h	12 to 78 kBtu/h	
Branch box that can be connected	Number of units		1 0	r 2		



	Co	nnectable indoor unit lineups (He	at pump inve	erter typ	e)								
	Model type	Model name	06	09	12	15	18	24	24 30				
Wall-mounted	Deluxe	N*XWPH*A112A* N*XWPH**B112A*	•	•	•	•	•						
	Standard	N*XWST**A112A* N*XWST**B112A*	•	•	•	•	•	•					
Ducted	Low static*2 *3	N*XDKS**A112A*		•	•	•	•						
	P-series mid static*2 *3	*PEADA0**1AA*0*		•	•	•	•	•	•	•			
1-way ceiling cas	ssette	N*XUKS**A112** ^{*5}	•	•	•		•						
4-way ceiling	P-series 22*22	N*XCKS**A112A*		•	•	•							
cassette	P-series 33*33	*PLA0A0**1EA*0* ^{*4}			•		•	•	•	•			
Floor standing	•	N*XFKS**A112A*		•	•	•	•						
Standard Multi-position air handler*1		N*XAMT**A112A*			•		•	•	•	•			



Branch box	TAC-MKA52/53BC	TAC-MKA32/33BC
Number of branches (Indoor unit that can be connected)	5 (MAX. 5 units)	3 (MAX. 3 units)

Note: A maximum of 2 branch boxes can be connected to 1 outdoor unit.



2- branch pipe (joint), Optional parts	Model name	Note			
Using 1 branch box	No required				
Lloing 2 branch boyog	MSDD-50AR-E Connection method: flare				
Using 2 branch boxes	MSDD-50BR-E Connection method: brazing				

Note: Select a model according to the connection method.



Option Optional accessories for indoor units and outdoor units are available.

*1 When connecting a multi-position unit(s), set additional constraints as follows. For connections other than those specified below, consult your dealer.

• Models other than NTXMSM60A182BA (For each connected branch box) • NTXMSM60A182BA (For each connected branch box)

Number of connecting multi-position unit	Constraints
2	Any indoor units other than ducted units are not connectable.
1	The total system wide capacity should be 130% or below including the ducted unit. Only 1 ducted unit can be included in the connection.

Number of connecting multi-position unit	Constraints
2	Any indoor units other than ducted unit are not connectable.
1	The total system wide capacity should be 100% or below including the ducted unit. Only 1 ducted unit can be included in the connection.

For NTXMSM60A182BA; When connecting the N*XDKS and *PEAD-series units, the total system wide capacity per 1 branch box should be 100% or below including the ducted units. (Only if connecting to branch box)
When not outside units 60: A branch box can connect to maximum 3 of the ducted units. When connecting with 3 of the ducted units per 1 branch box, other

indoor units cannot be connected.

When outside units 60: A branch box can connect to maximum 2 of the ducted units. When connecting with 1 and over 1 of the ducted units, the total ability including of the ducted units is 100% and below 100%.

When 1 or more TPLA0A0 units is connected, the number of the maximum connectable indoor units is decreased as follows:

³ for NTXMSM36A142BA and NTXMSH36A142BA, 4 for NTXMSH42A152BA, and 6 for NTXMSM48A182BA, NTXMSH48A182BA and NTXMSH60A182BA only NTXMSM36/48 and NTXMSH36/42/48 are connectable.

2-4. SYSTEM SPECIFICATIONS


(1) Outdoor Unit

Outdoor unit	Model name	NTXMSM36A142BA	NTXMSH36A142BA	NTXMSH42A152BA	NTXMSM48A182BA	NTXMSH48A182BA	NTXMSM60A182BA
Capacity	Cooling (kBtu/h)	3	6	42	4	60	
	Heating (kBtu/h)	41	42	48	50	54	66

Cooling/Heating capacity indicates the maximum value at operation under the following condition.

Cooling Indoor D.B. 80°F/W.B. 67°F: [D.B. 26.7°C/W.B. 19.4°C]
Outdoor D.B. 95°F/W.B. 75°F: [D.B. 35°C/W.B. 23.9°C]
Heating Indoor D.B. 70°F/W.B. 60°F: [D.B. 21.1°C/W.B. 15.6°C]
Outdoor D.B. 47°F/W.B. 43°F: [D.B. 8.3°C/W.B. 6.1°C]

(2) Method for identifying



SPECIFICATIONS

		Service Ref.		N ⁻	ΓXMSM36A142E	BA	N	TXMSM48A182E	BA		
Ind	oor type			Non-Ducted	Mix	Ducted	Non-Ducted	Mix	Ducted		
	Capacity Rated*	1	Btu/h	36.000	36,000	36,000	48.000	48,000	48,000		
D	Rated power con		W	2,400	2,740	3,190	3,665	4,090	4,615		
Cooling	Current input (20		A	11.7/10.6	13.4/12.1	15.6/14.1	17.9/16.2	20.0/18.1	22.5/20.4		
8	EER2	0/230V)	Btu/h/W	15.00	13.4/12.1	11.30	13.10	11.75	10.40		
0			Dlu/II/VV								
	SEER2	·*1		23.00	19.30	15.60	23.00	18.85	14.70		
	Capacity Rated		Btu/h	41,000	41,000	41,000	50,000	50,000	50,000		
	Capacity Max. 17		Btu/h	36,000	36,000	36,000	,	43,000 43,000 43,0			
Heating	Capacity Max. 5°		Btu/h	29,000	29,000	29,000	35,400	35,400	35,400		
ati	Rated power con	•	W	3,005	3,250	3,535	3,665	4,075	4,580		
Ĭ	Current input (20	8/230V)	Α	14.7/13.3	15.9/14.3	17.3/15.6	17.9/16.2	19.9/18.0	22.4/20.2		
	COP 47°F*1		W/W	4.00	3.70	3.40	4.00	3.60	3.20		
	HSPF2 Ⅳ/V		-	11.00/8.75	9.80/8.05	8.60/7.40	10.40/8.35	9.35/7.90	8.30/7.50		
Pov	wer supply		1			1-phase 208	/230 V, 60 Hz				
		um over current protection			30 A/6		r is supplied sepa	arately)			
D , c	and Gizo, Maxim	am ever earrent protection					applied from the o				
Mir	nimum circuit amp	acity					supplied separa				
	iii i airi oii oait airip	acity					lied from the out				
Ind	oor unit	Total capacity					tdoor unit capacit				
	nectable	Model/Quantity *3	CITY MULTI		04 - 36/11	00 10 100 70 01 001		04 - 54/12			
		Wodel/Quartity	Branch box		06 - 36/4			06 - 36/8			
201	und pressure leve	.1	Branch box		49/53			51/54			
(measured in anechoic room)			dB <a>		49/53			51/54			
Refrigerant Liquid pipe piping diameter			inch (mm)	3/8 (ø9.52)							
		Gas pipe	inch (mm)			5/8 (ø	15.88)				
Far	า	Type × Quantity				Propelle	r fan × 2				
	/	Airflow rate	m³/min			1	10				
			L/s			1,8	334				
			cfm	3,885							
		Control, Driving mechanis	sm	DC control							
		Motor output	kW	0.074 × 2							
		External static press.		0							
Co	mpressor	Type × Quantity		Scroll hermetic compressor x 1							
-		Manufacture		Mitsubishi Electric Corporation							
		Starting method					erter				
		Motor output	kW		2.8	11100	J. 101	3.4			
		Case heater	kW		۷.0		<u> </u> D	3.4			
			KVV				3oz. (2.3L)				
Г	annal finite	Lubricant			0 1		(- /	0/11>			
	ernal finish	1 W D			Galva		t <munsell 3y="" 7.8<="" td=""><td>8/ 1.1></td><td></td></munsell>	8/ 1.1>			
∟xt	ernal dimension l	-1 × VV × D	mm				0 × 330 (+25)				
_		T	inch				11/32 × 13 (+1)				
	tection	High pressure protection				0 1	sure switch				
dev	rices	Inverter circuit (COMP./FA	AN)		Overcurrent de	tection, Overhea	t detection (Heat	sink thermistor)			
		Compressor protection			Com	pressor thermo,	Overcurrent dete	ection			
		Fan motor protection				Overheating/Vo	Itage protection				
Re	frigerant	Type × original charge				R410A 10 lbs	. 9 oz. (4.8kg)				
		Control					ansion Valve				
Net	t weight		lb (kg)			<u>.</u>	(123)				
	at exchanger		, (0)				and tube				
	C circuit (HIC: Hea	at Inter-Changer)					circuit				
	frosting method						rigerant circuit				
	aranteed operation	in range	(Cooling)		D :		.B5 to 46°C] *4 [;]	*5*6			
Ju	aranteeu operatio	ni rany c	- 07								
Re	marks		(Heating)	W.B13 to 59°F [W.B25 to 15°C] Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice.							
				Due to continuing	g improvement,	apove specificati	ons may be subje	ect to change wit	nout notice.		

^{*1} Rating conditions Cooling Indoor : D.B. 80°F/W.B. 67 °F [D.B.26.7°C/W.B. 19.4°C]

Outdoor : D.B. 95°F [D.B. 35.0°C]
Heating Indoor : D.B. 70°F [D.B. 21.1°C]

Outdoor: D.B. 47°F/W.B. 43°F [D.B. 8.3°C/W.B. 6.1°C]

*2 Conditions Heating Indoor : D.B. 70°F [D.B. 21.1°C]

Outdoor: D.B. 17°F/W.B. 15°F [D.B. -8.3°C/W.B. -9.4°C]

 $kcal/h = kW \times 860$

Conversion formula: Btu/h = $kW \times 3412$ CFM = $m^3/min \times 35.31$

^{*3} It cannot be connected mixed CITY MULTI indoor unit and branch box indoor unit.

^{*4} D.B. 5 to 115°F [D.B. -15 to 46°C], when an optional Air Outlet Guide is installed. However, this condition does not apply to the indoor units listed in *5.

^{*5 50} to 115°F (10 to 46°C) D.B.: When connecting TPKFYP004/006/008/012LM14**, TPFFYP006/008/012CS14**, and TPFFYP006/008/012RE14** type indoor unit. *6 When the temperature is below D.B. 50°F [D.B. 10°C] with branch box system, noise could potentially occur. Note: Refer to the indoor unit's service manual for the indoor units specifications.

	Service Ref.		NTX	NTXMSH36A142BA NTXMSH42A152BA NTXMSH48A182BA						2BA		
Indoor type		Non-Ducted	Mix	Ducted	Non-Ducted	Mix	Ducted	Non-Ducted	Mix	Ducted		
Capacity Rate	ed*1	Btu/h	36,000	36,000	36,000	42,000	42,000	42,000	48,000	48,000	48,000	
Rated power of	consumption*1	W	2,400	2,740	3,190	3,135	3,500	3,965	3,665	4,090	4,615	
Rated power of Current input	(208/230V)	Α	11.7/10.6	13.4/12.1	15.6/14.1	15.3/13.8	17.1/15.4	19.4/17.5	17.9/16.2	20.0/18.1	22.5/20.4	
S EER2	,	Btu/h/W	15.00	13.15	11.30	13.40	12.00	10.60	13.10	11.75	10.40	
SEER2		-	23.00	19.30	15.60	21.50	18.85	14.70	23.00	18.85	14.70	
Capacity Rate	ed 47°F*1	Btu/h	42,000	42,000	42,000	48,000	48,000	48,000	54,000	54,000	54,000	
Capacity Max	. 17°F*2	Btu/h	42,000	42,000	42,000	48,000	48,000	48,000	54,000	54,000	54,000	
Capacity Max Rated power of Current input	. 5°F	Btu/h	38,500	38,500	38,500	44,000	44,000	44,000	47,000	47,000	47,000	
Rated power	consumption 47°F*1	W	3,080	3,330	3,620	3,435	3,805	4,265	3,960	4,400	4,950	
Current input	(208/230V)	A	15.0/13.6	16.3/14.7	17.7/16.0	16.8/15.2	18.6/16.8	20.8/18.8	19.3/17.5	21.5/19.4	24.2/21.8	
COP 47°F*1	,	W/W	4.00	3.70	3.40	4.10	3.70	3.30	4.00	3.60	3.20	
HSPF2 IV / V	,	-	12.00/10.65	10.95/9.70	9.90/8.80	11.10/9.80	10.10/9.30	9.10/8.80	11.50/9.80	10.15/9.05	8.80/8.30	
Power supply						1-phas	se 208/230 \	/. 60 Hz				
Breaker Size/Max	otection			40 A	/80 A (When			rately)				
2. sanor c.23/maximam ever carrent protection						(When pow						
Minimum circuit ampacity					4	5 A (When po	ower is supp	lied separat	ely)			
				51 A (V	Vhen power	is supplied fi	om the outo	loor unit)				
Indoor unit	Total capacity					50 to 130%	of outdoor	unit capacity	/			
connectable	Model/Quantity *3	CITY MULTI		04 - 36/11			04 - 54/12			04 - 54/12		
		Branch box		06 - 36/4			06 - 36/5			06 - 36/8		
Sound pressure le		dB <a>		49/53			50/54			51/54		
Refrigerant	Liquid pipe	inch (mm)		3/8 (ø9.52)								
piping diameter	Gas pipe	inch (mm)		5/8 (ø15.88)								
Fan	Type × Quantity	,				P	ropeller fan	,				
	Airflow rate	m³/min		110								
		L/s	1,834									
		cfm	3,885									
	Control, Driving med	hanism	DC control									
	Motor output	kW					0.074 × 2					
	External static press	i.					0					
Compressor	Type × Quantity					Scroll he	rmetic comp	ressor × 1				
	Manufacture					Mitsubis	hi Electric C	orporation				
	Starting method						Inverter					
	Motor output	kW		2.8			2.9			3.4		
	Case heater	kW					0					
	Lubricant					FV	50S 78oz. (2	2.3L)				
External finish					Gal	vanized Stee	l Sheet <mu< td=""><td>nsell 3Y 7.8</td><td>/ 1.1></td><td></td><td></td></mu<>	nsell 3Y 7.8	/ 1.1>			
External dimension	on H × W × D	mm				1,338	× 1,050 × 33	30 (+25)				
		inch				52-11/16	6 × 41-11/32	× 13 (+1)				
Protection	High pressure prote	ction				Hig	h pressure s	witch				
devices	Inverter circuit (CON	IP./FAN)		(Overcurrent (detection, Ov	erheat dete	ction (Heat s	sink thermisto	or)		
	Compressor protect	ion			Co	mpressor th	ermo, Overd	urrent detec	ction			
	Fan motor protection	า				Overhea	ting/Voltage	protection				
Refrigerant	Type x original charg	ge				R410A	10 lbs. 9 oz	. (4.8kg)				
	Control					Linea	ar Expansion	Valve				
Net weight		lb (kg)					278 (126)					
Heat exchanger						Cr	oss fin and t	ube				
HIC circuit (HIC: I	Heat Inter-Changer)						HIC circuit					
Defrosting method	d					Revers	sed refrigera	nt circuit				
Guaranteed opera	ation range	(Cooling)				D.B 23 to 11	5°F [D.B5 t	o 46°C] *4*5	*6			
		(Heating)				W.B13 to	59°F [W.B.	-25 to 15°C				
Remarks			shall be refe	rred to the Ir	nstallation M	anual.		0.,	ower source	switch, and o	other items	
			Pae to coult	rung mpio	rement, and	ve specificat	ions may be	auniact to c	nange williot	at Houce.		

^{*1} Rating conditions Cooling Indoor : D.B. 80°F/W.B. 67 °F [D.B.26.7°C/W.B. 19.4°C]

Outdoor : D.B. 95°F [D.B. 35.0°C] Heating Indoor : D.B. 70°F [D.B. 21.1°C]

Outdoor : D.B. 47°F/W.B. 43°F [D.B. 8.3°C/W.B. 6.1°C]
Heating Indoor : D.B. 70°F [D.B. 21.1°C]

*2 Conditions

Outdoor: D.B. 17°F/W.B. 15°F [D.B. -8.3°C/W.B. -9.4°C]

Note: Refer to the indoor unit's service manual for the indoor units specifications.

12

 $kcal/h = kW \times 860$

CFM = $m^3/min \times 35.31$

Conversion formula: Btu/h = kW × 3412

^{*3} It cannot be connected mixed CITY MULTI indoor unit and branch box indoor unit.

 $^{^*4}$ D.B. 5 to 115°F [D.B. -15 to 46°C], when an optional Air Outlet Guide is installed. However, this condition does not apply to the indoor units listed in *5.

^{*5 50} to 115°F (10 to 46°C)D.B.: When connecting TPKFYP004/006/008/012LM14**, TPFFYP006/008/012CS14**, and TPFFYP006/008/012RE14** type indoor unit.

^{*6} When the temperature is below D.B. 50°F [D.B. 10°C] with branch box system, noise could potentially occur.

			T						
	Service Ref.			NTXMSM60A182BA					
Indoor type			Non-Ducted	Mix	Ducted				
Capacity Rate		Btu/h	60,000	60,000	60,000				
Rated power of Current input (consumption*1	W	4,515	5,065	5,770				
Current input ((208/230V)	Α	21.9/19.8	24.6/22.3	28.0/25.4				
ပိ EER2		Btu/h/W	13.30	11.85	10.40				
SEER2		-	20.00	17.75	15.50				
Capacity Rate	ed 47°F*1	Btu/h	66,000	66,000	66,000				
Capacity Max.	17°F*2	Btu/h	65,000	65,000	65,000				
		Btu/h	46,500	46,500	46,500				
	consumption 47°F*1	W	4,720	5,175	5,690				
Current input (A	22.9/20.7	25.2/22.8	27.7/25.0				
COP 47°F*1	200/2007)	W/W	4.10	3.74	3.40				
HSPF2 IV/V		-	10.50/8.65	9.55/8.05	8.60/7.45				
			10.30/8.03	1-phase 208/230 V, 60 Hz	0.00/1.43				
Power supply	include allow allowed protection		40.4/6		-4-1-A				
oreaker Size/Maxi	imum over current protection			80 A (When power is supplied separ					
Ainimatum -l2	mn a city		,	When power is supplied from the ou					
Minimum circuit ar	npacity			A (When power is supplied separate nen power is supplied from the outd					
ndoor unit	Total conscitu		,						
ndoor unit connectable	Total capacity Model/Quantity*3	CITY MULTI		50 to 130% of outdoor unit capacity 04 - 72 /12					
OfficeClable	Model/Quantity"3			· · · · · · · · · · · · · · · · · · ·					
		Branch box		06 - 36 / 8					
Sound pressure le measured in aned		dB <a>	58/59						
Refrigerant	Liquid pipe	inch (mm)	3/8 (ø9.52)						
iping diameter	Gas pipe	inch (mm)		3/4 (ø19.05)					
an	Type × Quantity	, ,		Propeller fan × 2					
	Airflow rate	m³/min		138					
	7	L/s	2,300						
		cfm		4,879					
	Control, Driving mechanis		DC control						
	Motor output	kW							
		KVV		0.200 × 2					
	External static press.		0 Serall harmetic compressor v 1						
Compressor	Type × Quantity		Scroll hermetic compressor x 1						
	Manufacture			Mitsubishi Electric Corporation					
	Starting method	1		Inverter					
	Motor output	kW		3.9					
	Case heater	kW		0					
	Lubricant			FVC68D 78oz. (2.3L)					
External finish			Galva	nized Steel Sheet < Munsell 3Y 7.8/	1.1>				
External dimensio	n H × W × D	mm		1,338 × 1,050 × 330 (+25)					
		inch		52-11/16 × 41-11/32 × 13 (+1)					
Protection	High pressure protection			High pressure switch					
levices	Inverter circuit (COMP./FA	AN)	Overcurrent de	etection, Overheat detection(Heat s	nk thermistor)				
	Compressor protection		Com	pressor thermo, Overcurrent detec	tion				
	Fan motor protection			Overheating/Voltage protection					
Refrigerant	Type x original charge			R410A 11 lbs. 4 oz. (5.1kg)					
-	Control			Linear Expansion Valve					
let weight		lb (kg)		300 (136)					
leat exchanger				Cross fin and tube					
	Heat Inter-Changer)			HIC circuit					
Defrosting method				Reversed refrigerant circuit					
Guaranteed opera		(Cooling)	l n	.B 23 to 115°F [D.B5 to 46°C] *4*5	*6				
Jaarantoeu opera	mon range	(Heating)		W.B13 to 59°F [W.B25 to 15°C]					
Remarks		(rieaung)	Details on foundation work, duct	work, insulation work, electrical wir					
			other items shall be referred to the		at to oboneo withtt'				
			pue to continuing improvement,	above specifications may be subject	it to change without notice.				

^{*1} Rating conditions Cooling Indoor : D.B. 80°F/W.B. 67 °F [D.B.26.7°C/W.B. 19.4°C]

Outdoor : D.B. 95°F [D.B. 35.0°C] Heating Indoor : D.B. 70°F [D.B. 21.1°C]

Outdoor: D.B. 47°F/W.B. 43°F [D.B. 8.3°C/W.B. 6.1°C]
Heating Indoor: D.B. 70°F [D.B. 21.1°C] *2 Conditions Outdoor: D.B. 17°F/W.B. 15°F [D.B. -8.3°C/W.B. -9.4°C] kcal/h = kW × 860

CFM = $m^3/min \times 35.31$

Conversion formula: Btu/h = kW × 3412

OCHT810C

^{*3} It cannot be connected mixed CITY MULTI indoor unit and branch box indoor unit.


^{*4} D.B. 5 to 115°F [D.B. -15 to 46°C], when an optional Air Outlet Guide is installed. However, this condition does not apply to the indoor units listed in *5.

^{*5 50} to 115°F (10 to 46°C) D.B.: When connecting TPKFYP004/006/008/012LM14**, TPFFYP006/008/012CS14**, and TPFFYP006/008/012RE14** type indoor unit. *6 When the temperature is below D.B. 50°F [D.B. 10°C] with branch box system, noise could potentially occur. Note: Refer to the indoor unit's service manual for the indoor units specifications.

4-1. SELECTION OF COOLING/HEATING UNITS


How to determine the capacity when less than or equal 100% indoor model size units are connected in total:

The purpose of this flow chart is to select the indoor and outdoor units. For other purposes, this flow chart is intended only for reference.



How to determine the capacity when greater than 100% indoor model size units are connected in total:

The purpose of this flow chart is to select the indoor and outdoor units. For other purposes, this flow chart is intended only for reference.



<Cooling>

Design Condition	Design Condition							
Outdoor Design Dry Bulb Temperature Total Cooling Load	98.6°F (37.0°C) 30.3 kBtu/h							
Room1 Indoor Design Dry Bulb Temperature Indoor Design Wet Bulb Temperature Cooling Load	80.6°F (27.0°C) 68.0°F (20.0°C) 13.6 kBtu/h							
Room2 Indoor Design Dry Bulb Temperature Indoor Design Wet Bulb Temperature Cooling Load	75.2°F (24.0°C) 66.2°F (19.0°C) 16.7 kBtu/h							
<other> Indoor/Outdoor Equivalent Piping Length</other>	250 ft							

Capacity of indoor unit (kBtu/h)

<TP•FY series>

Model Number for indoor unit	Model													
	004	005	006	008	012	015	018	024	027	030	036	048	054	072
Model Capacity	4.0	5.0	6.0	8.0	12.0	15.0	18.0	24.0	27.0	30.0	36.0	48.0	54.0	72.0

<N*X. T(A)P*A series>

Model name				Capacit	y class			
	06	09	12	15	18	24	30	36
N*XAMT**A112A*	-	-	12.0	-	18.0	24.0	30.0	36.0
N*XCKS**A112A*	-	8.4	11.1	15.0	-	-	-	-
N*XDKS**A112A*	-	8.1	11.5	14.1	17.2	-	-	-
N*XFKS**A112A*	-	9.0	12.0	15.0	17.0	-	-	-
N*XUKS**A112B*	-	9.0	12.0	-	17.2	-	-	-
N*XUKS**A112A*	6.0	-	-	-	-	-	-	-
N*XWPH**A112A*	6.0	9.0	12.0	15.0	17.2	-	-	-
N*XWPH**B112A*	6.0	9.0	12.0	15.0	17.2	-	-	-
N*XWST**A112A*	6.0	9.0	12.0	14.0	17.2	22.5	-	-
N*XWST**B112A*	6.0	9.0	12.0	14.0	18.0	22.4	-	-
*PEADA0**1AA80*	-	9.0	12.0	15.0	18.0	24.0	30.0	36.0
*PLA0A0**1EA70*	•	-	12.0	-	18.0	24.0	30.0	36.0

1. Cooling Calculation

(1) Temporary Selection of Indoor Units

Room1

TPEFYP015 15.0 kBtu/h (Rated)

Room2

TPEFYP018 18.0 kBtu/h (Rated)

(2) Total Indoor Units Capacity

P15+ P18 = P33

(3) Selection of Outdoor Unit

The capacity class 36 is selected as total indoor units capacity is 33.

NTXMSM36A142BA 36.0 kBtu/h

(4) Total Indoor Units Capacity Correction Calculation

Room1

Indoor Design Wet Bulb Temperature Correction (68.0°F) 1.02 (Refer to Figure 1)

Room2

Indoor Design Wet Bulb Temperature Correction (66.2°F) 0.95 (Refer to Figure 1)

Total Indoor Units Capacity (CTi)

CTi = Σ (Indoor Unit Rating × Indoor Design Temperature Correction)

= 15.0 × 1.02 + 18.0 × 0.95

= 32.4 kBtu/h

(5) Outdoor Unit Correction Calculation

Outdoor Design Dry Bulb Temperature Correction (98.6°F) 0.98 (Refer to Figure 2) Piping Length Correction (250 ft) 0.93 (Refer to Figure 3)

Total Outdoor Unit Capacity (CTo)

CTo = Outdoor Rating × G(CTi)*1 × Outdoor Design Temperature Correction

× Piping Length Correction

 $= 36.0 \times 0.98 \times 0.93$

= 32.8 kBtu/h

^{*1} G(CTi) is used only when greater than 100% indoor model size are connected in total, refer to STANDARD CAPACITY DIAGRAM.




Figure 3 Correction of refrigerant piping length

(6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

CTi = 32.4 < CTo = 32.8, thus, select CTi.

CTx = CTi = 32.4 kBtu/h




Figure 1 Indoor unit temperature correction



Figure 2 Outdoor unit temperature correction

To be used to correct outdoor unit only

(7) Comparison with Essential Load

Against the essential load 30.3 kBtu/h, the maximum system capacity is 32.4 kBtu/h: Proper outdoor units have been selected.

(8) Calculation of Maximum Indoor Unit Capacity of Each Room

CTx = CTi, thus, calculate by the calculation below

Room1

Indoor Unit Rating × Indoor Design Temperature Correction

= 15.0 × 1.02

= 15.3 kBtu/h OK: fulfills the load 13.6 kBtu/h

Room2

Indoor Unit Rating × Indoor Design Temperature Correction

 $= 18.0 \times 0.95$

= 17.1 kBtu/h OK: fulfills the load 16.7 kBtu/h

Go on to the heating trial calculation since the selected units fulfill the cooling loads of Room 1, 2.

<Heating>

Design Condition	
Outdoor Design Wet Bulb Temperature	35.6°F (2.0°C)
Total Heating Load Room1	34.0 kBtu/h
Indoor Design Dry Bulb Temperature	69.8°F (21.0°C)
Heating Load	16.3 kBtu/h
Room2	
Indoor Design Dry Bulb Temperature	73.4°F (23.0°C)
Heating Load	17.7 kBtu/h
<other></other>	
Indoor/Outdoor Equivalent Piping Length	328 ft

Capacity of indoor unit (kBtu/h)

<TP•FY series>

Model Number for indoor unit	Model 004	Model 005	Model 006	Model 008	Model 012	Model 015	Model 018	Model 024	Model 027	Model 030	Model 036	Model 048	Model 054
Model Capacity	4.5	5.6	6.7	9.0	13.5	17.0	20.0	27.0	30.0	34.0	40.0	54.0	60.0

<N*X, T(A)P*A series>

Model name				Capaci	ty class			
	06	09	12	15	18	24	30	36
N*XAMT**A112A*	-	-	12.0	-	18.0	27.0	34.0	40.0
N*XCKS**A112A*	-	10.2	13.7	17.1	-	-	-	-
N*XDKS**A112A*	-	10.9	13.6	18.0	17.2	-	-	-
N*XFKS**A112A*	-	10.9	13.0	18.0	21.0	-	-	-
N*XUKS**A112B*	-	10.9	13.0	-	21.0	-	-	-
N*XUKS**A112A*	7.2	-	-	-	-	-	-	-
N*XWPH**A112A*	8.7	10.9	13.6	18.0	20.3	-	-	-
N*XWPH**B112A*	8.7	10.9	13.6	18.0	20.3	-	-	-
N*XWST**A112A*	7.2	10.9	14.4	18.0	21.6	27.6	-	-
N*XWST**B112A*	7.2	10.9	14.4	18.0	21.6	27.6	-	-
*PEADA0**1AA80*	-	10.9	13.5	15.7	18.0	26.0	34.0	40.0
*PLA0A0**1EA70*	-	-	13.5	-	18.0	26.0	34.0	40.0

2. Heating Calculation

(1) Temporary Selection of Indoor Units

Room1

TPEFYP015 17.0 kBtu/h (Rated)

Room2

TPEFYP018 20.0 kBtu/h (Rated)

(2) Total Indoor Units Capacity

P15 + P18 = P33

(3) Selection of Outdoor Unit

The capacity class 36 is selected when the total indoor units capacity is 33.

NTXMSM36A142BA 41.0 kBtu/h

(4) Total Indoor Units Capacity Correction Calculation

Room1

Indoor Design Dry Bulb Temperature Correction (69.8°F) 1.00 (Refer to Figure 4)

Room2


Indoor Design Dry Bulb Temperature Correction (73.4°F) 0.92 (Refer to Figure 4)

Total Indoor Units Capacity (CTi)

CTi = Σ (Indoor Unit Rating × Indoor Design Temperature Correction)

 $= 17.0 \times 1.00 + 20.0 \times 0.92$

= 35.4 kBtu/h



69.8 71.6 73.4 75.2 77 78.8 80.6 [FD.B.] 21 22 23 24 25 26 27 [CD.B.]

Figure 5 **Outdoor unit temperature correction**To be used to correct outdoor unit only

60.8 62.6 64.4 66.2 68 16 17 18 19 20

(5) Outdoor Unit Correction Calculation

Outdoor Design Wet Bulb Temperature Correction (35.6°F)

Piping Length Correction (328 ft)

Defrost Correction

1.0 (Refer to Figure 5)

0.94 (Refer to Figure 6)

0.89 (Refer to Table 1)

Total Outdoor Unit Capacity (CTo)

CTo = Outdoor Unit Rating \times G(CTi) *1 \times Outdoor Design Temperature Correction

× Piping Length Correction × Defrost Correction

 $= 41.0 \times 1.0 \times 0.94 \times 0.89$

= 34.3 kBtu/h

*1 G(CTi) is used only when greater than 100% indoor model size are connected in total, refer to STANDARD CAPACITY DIAGRAM.

Table 1 Table of correction factor at frost and defrost




Figure 6 Correction of refrigerant piping length

Outdoor Intake temperature <w.b.°f (°c)=""></w.b.°f>	43(6)	37(4)	36(2)	32(0)	28(-2)	25(-4)	21(-6)	18(-8)	14(-10)	5(-15)	-4(-20)	-13(-25)
Correction factor	1.00	0.98	0.89	0.88	0.89	0.90	0.95	0.95	0.95	0.95	0.95	0.95

(6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

CTi = 35.4 > CTo = 34.3, thus, select CTo.

CTx = CTo = 34.3 kBtu/h

(7) Comparison with Essential Load

Against the essential load 34.0 kBtu/h, the maximum system capacity is 34.3 kBtu/h: Proper outdoor units have been selected.

(8) Calculation of Maximum Indoor Unit Capacity of Each Room

CTx = CTo, thus, calculate by the calculation below

Room1

Maximum Capacity × Room1 Capacity after the Temperature Correction/(Room1,2 Total Capacity after the Temperature Correction

 $= 34.3 \times (17.0 \times 1.00) / (17.0 \times 1.00 + 20.0 \times 0.92)$

= 16.5 kBtu/h OK: fulfills the load 16.3 kBtu/h

Room2

Maximum Capacity × Room1 Capacity after the Temperature Correction/(Room1,2 Total Capacity after the Temperature Correction

 $= 34.3 \times (20.0 \times 0.92) / (17.0 \times 1.00 + 20.0 \times 0.92)$

= 17.8 kBtu/h OK: fulfills the load 17.7 kBtu/h

Completed selecting units since the selected units fulfill the heating loads of Room 1, 2.

3. Power input of outdoor unit

Outdoor unit: NTXMSM36A142BA

Indoor unit 1: TPEFY015 Indoor unit 2: TPEFY018

<Cooling>

(1) Rated power input of outdoor unit

2.40 kW

(2) Calculation of the average indoor temperature power input coefficient

Coefficient of the outdoor unit for indoor unit 1 (Outdoor temp. 98.6°F [37.0°C] D.B., Indoor temp. 68.0°F [20.0°C] W.B.)

1.04 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

Coefficient of the outdoor unit for indoor unit 2 (Outdoor temp. 98.6°F [37.0°C] D.B., Indoor temp. 64.4°F [18.0°C] W.B.)

0.85 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

Average indoor temp. power input coefficient $(C_{ave}) = \sum_{k=1}^{n} \{c_k \times (M_k / \sum_{k=1}^{n} M_k)\}$

n: Total number of the indoor units

k: Number of the indoor unit

ck: Outdoor unit power input coefficient of k indoor unit room temp.

Mk: Number part of the k indoor unit model (e.g. $P80 \rightarrow 80$)

Correction Coefficient of Indoor temperature = $1.04 \times 15/(15 + 18) + 0.85 \times 18/(15 + 18)$ = 0.94

(3) Coefficient of the partial load f (CTi)

Total Indoor units capacity

15 + 18 = 33, thus, f(CTi) = 0.9 (Refer to the tables in "4-4.STANDARD CAPACITY DIAGRAM".)

(4) Outdoor power input (Plo)

Maximum System Capacity (CTx) = Total Outdoor unit Capacity (CTo), so use the following formula

Plo = Outdoor unit Cooling Rated Power Input × Correction Coefficient of Indoor temperature × f (CTi)

 $= 2.40 \times 0.94 \times 0.9$

= 2.03 kW

<Heating>

(1) Rated power input of outdoor unit

3.01 kW

(2) Calculation of the average indoor temperature power input coefficient

Coefficient of the outdoor unit for indoor unit 1 (Outdoor temp. 26.6°F [-3°C] W.B., Indoor temp. 70°F [21.1°C] D.B.)

1.16 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

Coefficient of the outdoor unit for indoor unit 2 (Outdoor temp. 26.6°F [-3°C] W.B., Indoor temp. 78.8°F [26°C] D.B.)

1.09 (Refer to "4-2. CORRECTION BY TEMPERATURE".)

Average indoor temp. power input coefficient $(C_{ave}) = \sum_{k=1}^{n} \{c_k \times (M_k / \sum_{k=1}^{n} M_k)\}$

n: Total number of the indoor units

k: Number of the indoor unit

ck: Outdoor unit power input coefficient of k indoor unit room temp.

 M_k : Number part of the k indoor unit model (e.g. $P80 \rightarrow 80$)

Correction Coefficient of Indoor temperature = $1.16 \times 15/(15 + 18) + 1.09 \times 18/(15 + 18)$ = 1.12

(3) Coefficient of the partial load f(CTi)

Total indoor units capacity

15 + 18 = 33, thus, f(CTi) = 0.9 (Refer to the tables in "4-4. STANDARD CAPACITY DIAGRAM".)

(4) Outdoor power input (Plo)

Maximum System Capacity (CTx) = Total Indoor unit Capacity (CTi), so use the following formula

Plo = Outdoor unit Heating Rated Power Input × Correction Coefficient of Indoor temperature × f(CTi)

= 3.01 × 1.12 × 0.9

= 3.03 kW

4-2. CORRECTION BY TEMPERATURE

CITY MULTI could have varied capacity at different designing temperature. Using the nominal cooling/heating capacity value and the ratio below, the capacity can be observed at various temperature.

<Cooling>

Figure 7 Indoor unit temperature correction

To be used to correct indoor unit capacity only





Figure 8 Outdoor unit temperature correction

To be used to correct outdoor unit capacity only



<Heating> NTXMSM36A142BA

NTXMSM48A182BA

NTXMSM60A182BA

Figure 9 Indoor unit temperature correction

To be used to correct indoor unit capacity only





Figure 10 Outdoor unit temperature correction

To be used to correct outdoor unit capacity only



<Heating>

NTXMSH36A142BA

NTXMSH42A152BA

NTXMSH48A182BA

Figure 11 Indoor unit temperature correction

To be used to correct indoor unit capacity only





Figure 12 Outdoor unit temperature correction

To be used to correct outdoor unit capacity only



22

4-3. STANDARD OPERATION DATA (REFERENCE DATA)

Operation				NTXMSM	36A142BA	NTXMSM	48A182BA	NTXMSM6	60A182BA
Operating conditions	Ambient temperature	Indoor	DB/WB	80°F/67°F [26.7°C / 19.4°C]	70°F/60°F [21.1°C/15.6°C]	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]
		Outdoor	DD/VVD	95°F/75°F [35.0°C/23.9°C]	47°F / 43°F [8.3°C/6.1°C]	95°F/ 75°F [35.0°C / 23.9°C]	47°F/43°F [8.3°C/6.1°C]	95°F/75°F [35.0°C/23.9°C]	47°F/43°F [8.3°C/6.1°C]
	Indoor unit	No. of connected units	Unit	;	3	4	4	4	1
		No. of units in operation	Offic	;	3	4	4	4	1
		Model	_	12	× 3	12	× 4	15	× 4
	Piping	Main pipe		9.84	1 (3)	9.84	4 (3)	9.84	ł (3)
		Branch pipe	Ft (m)	14.76	6 (4.5)	14.76 (4.5)		14.76	(4.5)
		Total pipe length		54.13 (16.5)		68.90 (21)		68.90	(21)
	Fan speed		_	H	l i	F	-li	H	li
	Amount of re	efrigerant	LBS. OZ. (kg)	17 LBS. (7.7)		17 LBS. 3	3 OZ. (7.8)	19 LBS. 6	6 OZ. (8.8)
Outdoor	Electric curre	ent	A	10.2	13.3	15.6	17.1	19.3	20.4
unit	Voltage		V	23	30	23	30	23	30
	Compressor	frequency	Hz	47	66	64	81	53	64
LEV opening	Indoor unit		Pulse	268	438	247	313	386	498
Pressure	High pressur	e/Low pressure	PSIG [MPaG]	370/159 [2.55/1.10]	306/104 [2.11/0.72]	415/159 [2.86/1.09]	315/97 [2.17/0.67]	397/144 [2.75/1.02]	330/98 [2.28/0.68]
Temp. of	Outdoor	Discharge		139.1 [59.5]	118.9 [48.3]	149.5 [65.3]	135.9 [57.7]	143.2 [61.8]	121.1 [49.5]
each	unit	Heat exchanger outlet		101.3 [38.5]	34.3 [1.3]	102.2 [39.0]	32.2 [0.1]	102.9 [39.4]	32.9 [0.5]
section		Accumulator inlet	٥٥١٠٥١	56.7 [13.7]	33.4 [0.8]	57.6 [14.2]	31.3 [-0.4]	52.3 [11.3]	32.3 [0.1]
		Compressor inlet	°F[°C]	62.8 [17.1]	33.6 [0.9]	60.4 [15.8]	32.7 [0.4]	53.8 [12.1]	31.6 [-0.2]
	Indoor unit	Lev inlet		73.8 [23.2]	81.4 [27.4]	68.4 [20.2]	75.2 [24.0]	85.3 [29.6]	84.6 [29.2]
		Heat exchanger inlet		68.2 [20.1]	71.4 [21.9]	67.9 [19.9]	127.8 [53.2]	84.2 [29.0]	113.9 [45.5]

Operation				NTXMSH	36A142BA	NTXMSH	42A152BA	NTXMSH4	8A182BA
Operating conditions	Ambient temperature	Indoor	55445	80°F/67°F 70°F/ [26.7°C/19.4°C] [21.1°C/		80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]	80°F/67°F [26.7°C/19.4°C]	70°F/60°F [21.1°C/15.6°C]
		Outdoor	DB/WB	95°F/75°F [35.0°C/23.9°C]	47°F / 43°F	95°F/ 75°F [35.0°C/23.9°C]	47°F/43°F [8.3°C/6.1°C]	95°F/ 75°F [35.0°C/23.9°C]	47°F/43°F [8.3°C/6.1°C]
	Indoor unit	No. of connected units	1.1	3	3		3	4	
		No. of units in operation	Unit	3	3	(3	4	
		Model	_	12	× 3	12 × 2 -	+ 18 × 1	12	× 4
	Piping	Main pipe		9.84	ł (3)	9.84	1 (3)	9.84	(3)
		Branch pipe	Ft (m)	14.76		14.76 (4.5)		14.76 (4.5)	
		Total pipe length			54.13 (16.5)		68.90 (21)		(21)
	Fan speed		_	Hi		Hi		Н	li
	Amount of re	efrigerant	LBS. OZ. (kg)	17 LBS. (7.7)		17 LBS	S. (7.7)	17 LBS. 3	OZ. (7.8)
Outdoor	Electric curre	ent	Α	10.2	13.3	13.4	14.8	15.6	17.1
unit	Voltage		V	23		230		230	
	Compressor	frequency	Hz	47	66	58	70	64	81
LEV opening	Indoor unit		Pulse	268	438	299/414	348/520	247	313
Pressure	High pressur	re/Low pressure	PSIG [MPaG]	370/159 [2.55/1.10]	306/104 [2.11/0.72]	419/155 [2.89/1.17]	347/115 [2.39/0.79]	415/159 [2.86/1.09]	316/96 [2.18/0.66]
Temp. of	Outdoor	Discharge		139.1 [59.5]	118.9 [48.3]	142.9 [61.6]	131.7 [55.4]	149.5 [65.3]	128.1 [53.4]
each	unit	Heat exchanger outlet		101.3 [38.5]	34.3 [1.3]	100.9 [38.3]	32.9 [0.5]	102.2 [39.0]	32.4 [0.2]
section		Accumulator inlet	°F[°C]	56.7 [13.7]	33.4 [0.8]	55.4 [13.0]	31.8 [-0.1]	57.6 [14.2]	32.0 [0.0]
		Compressor inlet	1 [0]	62.8 [17.1]	33.6 [0.9]	54.5 [12.5]	31.1 [-0.5]	60.4 [15.8]	32.7 [0.4]
	Indoor unit	Lev inlet		73.8 [23.2]	81.4 [27.4]	73.8 [23.2]	79.0 [26.1]	68.4 [20.2]	68.7 [20.4]
		Heat exchanger inlet		68.2 [20.1]	71.4 [21.9]	56.5 [13.6]	123.8 [51.0]	67.9 [19.9]	122.0 [50.0]


4-4. STANDARD CAPACITY DIAGRAM

Before calculating the sum of total capacity of indoor units, please convert the value into the kBtu/h model capacity following the formula on "4-1. Method for obtaining system cooling and heating capacity".


4-4-1. NTXMSM36A142BA

NTXMSH36A142BA

<Cooling>




24




4-4-3. NTXMSH42A152BA

<Cooling>




4-4-4. NTXMSH42A152BA


<Heating>





Total capacity of indoor units (kBtu/h)

27









4-5. CORRECTING CAPACITY FOR CHANGES IN THE LENGTH OF REFRIGERANT PIPING

- (1) During cooling, obtain the ratio (and the equivalent piping length) of the outdoor units rated capacity and the total in-use indoor capacity, and find the capacity ratio corresponding to the standard piping length from Figure 13 to 17. Then multiply by the cooling capacity from Figure 7 and 8 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity.
- (2) During heating, find the equivalent piping length, and find the capacity ratio corresponding to standard piping length from Figure 18. Then multiply by the heating capacity from Figure 9 and 10 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity.

(1) Capacity Correction Curve

Figure 13 NTXMSM36A142BA NTXMSH36A142BA <Cooling>




Figure 14 NTXMSH42A152BA

<Cooling>





Figure 15 NTXMSM48A182BA NTXMSH48A182BA <Cooling>






Figure 17 NTXMSM36A142BA NTXMSH48A182BA NTXMSH48A182BA NTXMSH48A182BA NTXMSH48A182BA NTXMSH48A182BA SHeating>

Figure 18 NTXMSM60A182BA <Heating>

100

150

200

250

300

Piping equivalent length (ft)

350

400

450


500

550

600

50

0.70



(2) Method for Obtaining the Equivalent Piping Length

Equivalent length = (length of piping to farthest indoor unit) + (0.99 × number of bends in the piping) (ft)

4-5-1. Correction of Heating Capacity for Frost and Defrosting

If heating capacity has been reduced due to frost formation or defrosting, multiply the capacity by the appropriate correction factor from the following table to obtain the actual heating capacity.


Correction factor diagram

Outdoor Intake temperature <w.b.°f (°c)=""></w.b.°f>	43(6)	37(4)	36(2)	32(0)	28(-2)	25(-4)	21(-6)	18(-8)	14(-10)	5(-15)	-4(-20)	-13(-25)
Correction factor	1.00	0.98	0.89	0.88	0.89	0.90	0.95	0.95	0.95	0.95	0.95	0.95

4-6. NOISE CRITERION CURVES


NTXMSM36A142BA NTXMSH36A142BA

MODE	SPL(dB)	LINE
COOLING	49	─
HEATING	53	•—•



NTXMSH42A152BA

MODE	SPL(dB)	LINE
COOLING	50	─
HEATING	54	•—•





NTXMSM48A182BA NTXMSH48A182BA

MODE	SPL(dB)	LINE
COOLING	51	\longrightarrow
HEATING	54	•—•

NTXMSM60A182BA

MODE	SPL(dB)	LINE
COOLING	58	
HEATING	59	•—•





MICROPHONE

1 m

[3.3 ft]


UNIT

1.5 m

[4.9 ft]

OUTLINES AND DIMENSIONS

Unit: mm <inch>





WIRING DIAGRAM

NTXMSM36A142BA NTXMSM48A182BA 33H 222 111 MULTI. B. 63LS 63HS TH7 TH6 TH3 M is the switch position. CNF1 1 3 1 4 1 2 2 1 63HS TH7/6 TH3 TH4 (WH) (RD) (WH) (WH) 1 2 TH2 (BK) CN3D CN3S CN3N (WH) (RD) (BU) SWU2SWU SW5 SW6 SW9*1 1 5 CNLVB (RD) SW1 SW8*1 SW2*1 ₽ E 1 3 63LS (BU) 63H (YE) 00000 SW4*1 SW3 SW7 CN51 (WH) CN2 (RD) 1 (HD) LED1 LED2 CN4 (WH) 1 2 CN102 (WH) CNS1 CNS2 CN41 (RD) (YE) (WH) 2 1 2 1 4 [] [] [] [] LED3 ⊗ 4 1 3 SV3 1 321S4 1 3 SV2 1 3 SV1 1 3 SS/BH (GY) (WH) 1 2 CNAC (RD) 4 1 4 0000 SV1 2154 M-NET P.B. CN2 (WH) CN1 (WH) 5 3 1 M1 RD P. B. CN6 CN4 (WH) (WH) CNDC (PK) RD, M2 CNAC1 3 (WH) CNAC2 (RD) ρLI NIC 318 TB7 IC500 318 M1 YE \Rightarrow FOR CENTRALIZED CONTROL 30V DC(Non-polar) M2 YE S o-E3 4 (* TB2A TB1A TB3A TB3B TB2B TB1B \triangle CN2 TB1B B1 RD DCL1 ¥ 윤 8 M ∀ 쑮 B2 BU TO BRANCH BOX 208/230V AC 60Hz GNYE DCL2 (1) TB1 L1 RD POWER SUPPLY 208/230V AC 60Hz L2 GNYE *1 MODEL SELECTION The black square (■) indicates a switch position. ... (<u>+</u>) MODEL SW4 SW8 SW9 SW2 SW4 SW8 SW9 SW2 MODEL NTXMSM48A182BA NTXMSM36A142BA *3 When a Branch box is connected, *2 Use copper supply wires. Utiliser des fils d'alimentation en cuivre. SW2-5 should be ON

		Othisci	des ins d'animentation en cuivre.	VVZ-5 3	si iouiu	DE ON.
[LEGEND]						
SYMBOL	NAME	SYMBOL	NAME	SYN	IBOL	NAME
TB1	Terminal Block (Power Supply)	TH8	Thermistor (Heat Sink)	SW5	5	Switch (Function Selection)
TB1B	Terminal Block (Branch box)	TRS	Thermal Protector	SW6	3	Switch (Function Selection)
TB3	Terminal Block (Indoor/Outdoor, Branch	LEV-A, LEV-E	Linear Expansion Valve	SW7	7	Switch (Function Selection)
	box/Outdoor Transmission Line>	DCL1, DCL2, DCL3	Reactor	SW8	3	Switch (Model Selection)
TB7	Terminal Block	P.B.	Power Circuit Board	SWS	9	Switch (Function/Model Selection)
	(Centralized Control Transmission Line)	U/V/W	Connection Terminal (U/V/W-Phase)	SWI	J1	Switch (Unit Address Selection, ones digit)
FUSE1, FUSE2	Fuse (T20A L250V)	LI	Connection Terminal (L1-Phase)	SWI	J2	Switch (Unit Address Selection, tens digit)
MC	Motor for Compressor	NI	Connection Terminal (L2-Phase)	SS/	BH	Connector (Connection for Option)
MF1, MF2	Fan Motor	TB1A, TB2A, TB3A	Connection Terminal (Reactor)	CN3	BD	Connector (Connection for Option)
21S4	Solenoid Valve Coil (4-Way Valve)	TB1B, TB2B, TB3E		CN3	3S	Connector (Connection for Option)
63H	High Pressure Switch	IC500	Converter	CN3	BN	Connector (Connection for Option)
63HS	High Pressure Sensor	IC600	Inverter	CN5	51	Connector (Connection for Option)
63LS	Low Pressure Sensor	El, E3, E4	ConnectionTerminal (Electrical Parts Box)	LED.	1, LED2	LED (Operation Inspection Display)
SV1	Solenoid Valve Coil (Bypass Valve)	MULTI.B.	Multi Controller Circuit Board	LED	3	LED (Power Supply to Main Microcomputer)
TH2	Thermistor (HIC Pipe)	SW1	Switch (Display Selection)	F1,	F2	Fuse (T6.3A L250V)
TH3	Thermistor (Outdoor Liquid Pipe)	SW2	Switch (Function/Model Selection)	X501	~X505	Relay
TH4	Thermistor (Compressor)	SW3	Switch (Test Run)	M-NE	T P.B.	M-NET Power Circuit Board
TH6	Thermistor (Suction Pipe)	SW4	Switch (Model Selection)	TB1		ConnectionTerminal (Electrical Parts Box)
TH7	Thermistor (Ambient)					


NTXMSM60A182BA





NECESSARY CONDITIONS FOR SYSTEM CONSTRUCTION

7-1. TRANSMISSION SYSTEM SETUP




7-2. Special Function Operation and Settings for M-NET Remote Controller

For the detailed procedure of "group settings" and "paired settings", refer to the remote controller's manuals.


7-3. REFRIGERANT SYSTEM DIAGRAM

NTXMSM36A142BA NTXMSM48A182BA



Capillary tube for oil separator [inch(mm)]: ø0.098 × ø0.031 × L39.37 (ø2.5 × ø0.8 × L1000)


NTXMSH36A142BA NTXMSH42A152BA NTXMSH48A182BA



Refrigerant flow in cooling


Refrigerant flow in heating

Capillary tube for oil separator [inch(mm)]: ø0.098 × ø0.031× L39.37 (ø2.5 × ø0.8 × L1000)



Capillary tube for oil separator [inch(mm)]: $\emptyset 0.098 \times \emptyset 0.031 \times L31.50$ ($\emptyset 2.5 \times \emptyset 0.8 \times L800$) Capillary tube for solenoid valve [inch(mm)]: $\emptyset 0.157 \times \emptyset 0.117 \times L19.685$ ($\emptyset 4.0 \times \emptyset 3.0 \times L500$)

NTXMSM36A142BA NTXMSM48A182BA




		Unit: inch (mm)
	Capillary tube 1 (For return of oil from oil separator)	Capillary tube 2 behind LEV (in cooling mode)
Outdoor unit	ø0.098 × ø0.031 × L(39-1/2) (ø2.5 × ø0.8 × L1000)	
Branch box		(Ø0.157 × Ø0.117 × L(5-1/8)) × 5 ((Ø4.0 × Ø3.0 × L130) × 5)
Branon box		(Ø0.157 × Ø0.117 × L(5-1/8)) × 3 ((Ø4.0 × Ø3.0 × L130) × 3)

NTXMSH36A142BA


NTXMSH42A152BA

NTXMSH48A182BA



	Capillary tube 1 (For return of oil from oil separator)	Capillary tube 2 behind LEV (in cooling mode)		
Outdoor unit	ø0.098 × ø0.031 × L(39-1/2) (ø2.5 × ø0.8 × L1000)			
Branch box		(Ø0.157 × Ø0.117 × L(5-1/8)) × 5 ((Ø4.0 × Ø3.0 × L130) × 5)		
Branch box	 .	(Ø0.157 × Ø0.117 × L(5-1/8)) × ((Ø4.0 × Ø3.0 × L130) × 3)		

NTXMSM60A182BA




	Capillary tube 1 (For return of oil from oil separator)	Capillary tube 2 (For solenoid valve (SV1))	Capillary tube 3 behind LEV (in cooling mode)
Outdoor unit	ø0.098 × ø0.031 × L(39-1/2) (ø2.5 × ø0.8 × L800)	Ø0.157 × Ø0.117 × L(19-5/8) (Ø4.0 × Ø3.0 × L500)	
Branch box			(ø0.157 × ø0.117 × L(5-1/8)) × 5 ((ø4.0 × ø3.0 × L130) × 5)
Branon box		. ———	(ø0.157 × ø0.117 × L(5-1/8)) × 3 ((ø4.0 × ø3.0 × L130) × 3)


7-4. SYSTEM CONTROL

7-4-1. Example for the System

- Example for wiring control cables, wiring method and address setting, permissible lengths, and the constraint items are listed in the standard system with detailed explanation.
- A. Example of an M-NET remote controller system (address setting is necessary.)



- 1 M-NET remote controller for each CITY MULTI series indoor unit
- There is no need for setting the 100 position on the M-NET remote controller.
 - 2. Operation using 2 M-NET remote controllers



 Using 2 M-NET remote controllers for each CITY MULTI series indoor unit.

- Wiring Method and Address Setting
- a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each CITY MULTI series indoor unit (M-IC). Use non-polarized 2-core wire.
- b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) for each indoor unit with the terminal block (TB6) for M-NET the remote controller (M-NET RC).
- c. Set the address setting switch (on outdoor unit P.C.B) as shown below.

Unit	Range	Setting Method		
CITY MULTI series indoor unit (M-IC)	001 to 050	_		
Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor unit plus 50.		
M-NET Remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100		

- a. Same as above 1.a
- b. Same as above 1.b
- c. Set address switch (on outdoor unit P.C.B) as shown below.

Unit	Range	Setting Method		
CITY MULTI series indoor unit (M-IC)	001 to 050	_		
Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor units plus 50.		
Main M-NET Remote Controller (M-NET RC)	101 to 150	Indoor unit address plus 100		
Sub M-NET Remote Controller (M-NET RC)	151 to 200	Indoor unit address plus 150		

- 3. Group operation
 - ОС M-IC(Main) M-IC(Sub) (51)(01)(02)TB5 TB15 TB15 TB5 M1 M2 S M1M2 S M1M2 S 1 2 M1M2S 1 2 ÁΒ (101)
- Multiple CITY MULTI series indoor units operated together by 1 M-NET remote controller

- a. Same as above 1.a
- b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) of the M-IC main unit with the most recent address within the same CITY MULTI series indoor unit (M-IC) group to terminal block (TB6) on the M-NET remote controller.
- c. Set the address setting switch (on outdoor unit P.C.B) as shown below.

Unit	Range	Setting Method		
M-IC (Main)	001 to 050	Use the smallest address within the same group of CITY MULTI series indoor units.		
M-IC (Sub) 001 to 050		Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).		
Outdoor unit 051 to 100		Use the smallest address of all the CITY MULTI series indoor units plus 50.		
Main M-NET Remote Controller (M-NET RC)		Set at an M-IC (Main) address within the same group plus 100.		


 d. Use the CITY MULTI series indoor unit (M-IC) within the group with the most functions as the M-IC (Main) unit.

Combinations of 1 through 3 above are possible.


45

• Name, Symbol and the Maximum Remote controller Units for Connection

Name Symbol		Maximum units for connection
Outdoor unit	OC	_
CITY MULTI series indoor unit	M-IC	Refer to "3. SPECIFICATIONS".
M-NET remote controller	M-NET RC	Maximum 2 M-NET RC for 1 indoor unit, Maximum 12 M-NET RC for 1 OC



B. Example of a group operation system with 2 or more outdoor units and an M-NET remote controller. (Address settings are necessary.)



- a. Always use shielded wire when making connections between the outdoor unit (OC) and the CITY MULTI series indoor unit (M-IC), as well for all OC-OC, and IC-IC wiring intervals.
- b. Use feed wiring to connect terminals M1 and M2 and the ground terminal on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1 and M2 on the terminal S on the transmission cable terminal block of the CITY MULTI series indoor unit (M-IC).
- c. Connect terminals M1 and M2 on the transmission cable terminal block of the CITY MULTI series indoor unit (M-IC) that has the most recent address within the same group to the terminal block on the M-NET remote controller (M-NET RC).
- d. Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
- e. DO NOT change the jumper connector CN41 on outdoor multi controller circuit board.
- f. The earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit with the earth.
- g. Set the address setting switch as follows.

Unit	Range	Setting Method			
M-IC (Main) 01 to 50		Use the smallest address within the same group of CITY MULTI series indoor units.			
M-IC (Sub)	01 to 50	Use an address, other than the M-IC (Main) in the same group of CITY MULTI			
W-IC (Sub)	01 10 50	Use an address, other than the M-IC (Main) in the same group of CITY MULTI series indoor units. This must be in sequence with the M-IC (Main). Use the smallest address of all the CITY MULTI series indoor units plus 50. The address automatically becomes "100" if it is set as "01–50".			
Outdoor Unit	51 to 100	Use an address, other than the M-IC (Main) in the same group of CITY MULTI series indoor units. This must be in sequence with the M-IC (Main). Use the smallest address of all the CITY MULTI series indoor units plus 50.			
Outdoor Offic	31 10 100				
Main M-NET Remote Controller	101 to 150	Set at an M-IC (Main) address within the same group plus 100.			
Sub M-NET Remote Controller	151 to 200	Set at an M-IC (Main) address within the same group plus 150.			
MA Remote Controller	_	Address setting is not necessary. (Main/sub setting is necessary.)			


h. The group setting operations among the multiple CITY MULTI series indoor units are done by the M-NET remote controller (M-NET RC) after the electrical power has been turned on.

• Name, Symbol, and the Maximum Units for Connection

Permissible

- Maximum line length via outdoor unit: L1+L2+L3+L4, L3+L4+L5+L6, L1+L2+L5+L6 ≤ 1640 ft [500 m] (AWG16 [1.25 mm²])
- Indoor/outdoor transmission line Maximum length: L1, L3+L4, L2+L5, L6 ≤ 656 ft [200 m] (AWG16 [1.25 mm²])
- M-NET Remote controller cable length: ℓ1,ℓ2+ℓ3 ≤ 33 ft [10 m] (AWG20 to AWG16 [0.5 to 1.25 mm²])

If the length exceeds 33 ft [10 m], use an AWG16 [1.25 mm²] shielded wire. The section of the cable that exceeds 33 ft [10 m] must be included in the max length via outdoor units and max transmission cable length.




- A: Group
- B: Group
- ©: Group
- Shielded Wire
- **(E):** Sub M-NET Remote Controller
- (): Address example
- · Never connect together the terminal blocks (TB5) for transmission wires for CITY MULTI series indoor unit (M-IC) that have been connected to different outdoor units (OC).
- Set all addresses to ensure that they are not overlapped.
- · M-NET remote controller and MA remote controller cannot be connected with the CITY MULTI series indoor unit of the same group wiring together.


C. Example of an MA remote controller system (address setting is not necessary.)

NOTE: In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit.

Example of wiring control cables Wiring Method and Address Setting 1. Standard operation a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmis-ОС sion cable block (TB5) of each CITY MULTI series (00)M-IC M-IC indoor unit (M-IC). Use non-polarized 2-core wire. b. Connect terminals 1 and 2 on transmission cable (00)(00)terminal block (TB15) for each CITY MULTI series TB15 TB3) TB7 TB5 TB5 TB15 indoor unit with the terminal block for the MA M1M2 S M1M2 S 1 2 M1M2 S 1 2 remote controller (MA-RC). 7 ΑВ АВ 1 MA remote controller for MA-RC MA-RC each indoor unit 2. Operation using 2 remote controllers a. The same as above a b. The same as above b (00)M-IC M-IC c. In the case of using 2 remote controllers, connect (00)(00)terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal TB5 TB15 TB5 TB15 11M2 S M1M2 S M1M2S 12 block for 2 MA remote controllers. · Set either one of the controllers to "sub remote controller". Refer to the installation manual of MA remote con-АВ ÀВ ÁΒ troller. · Using 2 MA remote controllers for each CITY MULTI MA-RC MA-RC MA-RC series indoor unit 3. Group operation a. The same as above a b. The same as above b OC c. In the case of group operation using MA remote (00)M-IC M-IC controller (MA-RC), connect terminals 1 and 2 on (00)(00)transmission cable terminal block (TB15) of each CITY MULTI series indoor unit. Use non-polarized TB15 TB5 TB3 TB7 TB5 TB15 2-core wire. M1 M2 S 1 2 M1 M2 S M1M2S 1 2 d. In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit. Please set the smallest address within number 90 01-50 of the CITY MULTI series indoor unit with the A B most functions in the same group. · Multiple indoor units operated MA-RC together by 1 MA remote controller Combinations of 1 through 3 above are possible.



D. Example of a group operation with 2 or more outdoor units and an MA remote controller. (Address settings are necessary.)



- a. Always use shielded wire when making connections between the outdoor unit (OC) and the CITY MULTI series indoor unit (M-IC), as well for all OC-OC, and IC-IC wiring intervals.
- b. Use feed wiring to connect terminals M1 and M2 and the ground terminal on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1 and M2 on the terminal S on the transmission cable terminal block of the CITY MULTI series indoor unit (M-IC).
- c. Connect terminals 1 and 2 on the terminal block for MA remote controller line (TB15) on the indoor unit (IC) to the terminal block on the MA remote controller (MA). (Nonpolarized two-wire).
- d. Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
- e. DO NOT change the jumper connector CN41 on outdoor multi controller circuit board.
- f. The earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit with the earth.
- g. Set the address setting switch as follows.

Unit	Range	Setting Method			
M-IC (Main)	01 to 50	Use the smallest address within the same group of indoor units.			
M-IC (Sub)	01 to 50	Use the smallest address within the same group of indoor units. Use an address, other than the M-IC (Main) in the same group of CITY MULTI series indoor units. This must be in sequence with the M-IC (Main). Use the smallest address of all the indoor units plus 50. The address automatically becomes "100" if it is set as "01–50". Set at an M-IC (Main) address within the same group plus 100. Set at an M-IC (Main) address within the same group plus 150.			
W-IC (Sub)	01 10 30	Use the smallest address within the same group of indoor units. Use an address, other than the M-IC (Main) in the same group of CITY MULTI series indoor units. This must be in sequence with the M-IC (Main). Use the smallest address of all the indoor units plus 50. The address automatically becomes "100" if it is set as "01–50". Set at an M-IC (Main) address within the same group plus 100. Set at an M-IC (Main) address within the same group plus 150.			
Outdoor Unit	51 to 100	' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '			
Odtdoor Offic	31 10 100	series indoor units. This must be in sequence with the M-IC (Main). Use the smallest address of all the indoor units plus 50. The address automatically becomes "100" if it is set as "01–50". Set at an M-IC (Main) address within the same group plus 100. Set at an M-IC (Main) address within the same group plus 150.			
Main M-NET Remote Controller	101 to 150	Set at an M-IC (Main) address within the same group plus 100.			
Sub M-NET Remote Controller	151 to 200	Set at an M-IC (Main) address within the same group plus 150.			
MA Remote Controller	_	Address setting is not necessary. (Main/sub setting is necessary.)			

h. The group setting operations among the multiple CITY MULTI series indoor unit is done by the M-NET remote controller (M-NET RC) after the electrical power has been turned on.

Wiring Method Address Settings


• Name, Symbol, and the Maximum Units for Connection

Permissible Length

Prohibited items


Maximum line length via outdoor unit (M-NET cable): $L_{1}+L_{2}+L_{3}+L_{4}$ and $L_{1}+L_{2}+L_{6}+L_{7} \le 1640$ ft [500 m] (AWG 16 [1.25 mm²] or more) Indoor/outdoor transmission line Maximum length (M-NET cable): L_{1} and $L_{3}+L_{4}$ and $L_{2}+L_{6}$ and $L_{7} \le 656$ ft [200 m] (AWG 16 [1.25 mm²] or more)

MA Remote controller cable length: m₁ and m₁+m₂+m₃ and m₁+m₂+m₃+m₄ ≤ 656 ft [200 m] (AWG 22 to AWG 16 [0.3 to 1.25 mm²])



- © L Croup
- B: Group
- ©: Group
- Shielded Wire
- ©: Sub MA Remote Controller
- (): Address example
- Never connect together the terminal blocks (TB5) for transmission wires for CITY MULTI series indoor unit (M-IC) that have been connected to different outdoor units (OC).
- M-NET remote controller and MA remote controller cannot be connected with the CITY MULTI series indoor unit of the same group wiring together.

E. Example of a system using Branch Box and A-Control indoor unit




- a. Always use shielded wire when making connections between the outdoor unit (OC) and the Branch Box, as well for all OC-OC wiring intervals.
- b. Use feed wiring to connect terminals M1 and M2 and the ground terminal on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1 and M2 on the terminal S on the transmission cable terminal block (TB5) of the Branch Box.
- c. Connect terminals 1 and 2 on the transmission cable terminal block (TB5/TB15) of the A-control indoor unit (A-IC), to the terminal block on the MA remote controller (MA-RC).
- d. Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
- e. DO NOT change the jumper connector CN41 on outdoor multi controller circuit board.
- f. The earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit to the earth.
- g. Set the address setting switch as follows.

Unit	Range	Setting Method		
		According to the set address of connected Branch Box, set the A-IC addresses		
A-IC	01 to 50			
A-IC	011030	(For example, when setting the Branch Box address to 01, A-IC addresses set		
		According to the set address of connected Branch Box, set the A-IC addresse sequentially by SW1 on Branch Box.		
Branch Box	01 to 50	Use a number within the range 1–50, but it should not make the highest		
Branch Box	01 10 30	address of connected A-IC exceed 50.		
Outdoor Unit	51 to 100	Use the smallest address of all the Branch Box plus 50.		
Outdoor Offic	31 10 100	According to the set address of connected Branch Box, set the A-IC addresses sequentially by SW1 on Branch Box. (For example, when setting the Branch Box address to 01, A-IC addresses set 02,03,04, and 05.) Use a number within the range 1–50, but it should not make the highest address of connected A-IC exceed 50. Use the smallest address of all the Branch Box plus 50. The address automatically becomes "100" if it is set as "01–50".		
MA Remote Controller –		Address setting is not necessary.		

• Name, Symbol, and the Maximum Units for Connection

Permissible Length

Maximum line length via outdoor unit (M-NET cable): $L_1+L_2+L_3+L_4+L_5 \le 1640$ ft [500 m] (AWG16 [1.25mm²] or more) Branch box/outdoor transmission line Maximum length (M-NET cable): L_1+L_2 , L_3+L_4 , $L_5 \le 656$ ft [200 m] (AWG16 [1.25 mm²] or more) Indoor/branch box transmission line Maximum length (A-Control cable): $L_6 \le 82$ ft [25 m] (AWG14 [1.5] mm²) Remote controller cable length: $m_1 \le 656$ ft [200 m] (AWG22 to AWG16 [0.3 to 1.25 mm²])



- A: Shielded wire
- (): Address example
- Plural indoor units cannot be operated by an MA single remote controller.
- Different refrigerant systems cannot be connected together.
- M-NET Remote controller cannot be connected to this system.

TROUBLESHOOTING

8

8-1. CHECKPOINTS FOR TEST RUN

8-1-1. Procedures before test run

- (1) Before a test run, make sure that the following work is completed.
 - · Installation related:

Make sure that the panel of cassette type and electrical wiring are done.

Otherwise electrical functions like auto vane will not operate normally.

· Piping related:

Perform leakage test of refrigerant and drain piping.

Make sure that all joints are perfectly insulated.

Check stop valves on both liquid and gas side for full open.

• Electrical wiring related:

Check ground wire, transmission cable, remote controller cable, and power supply cable for secure connection.

Make sure that all switch settings of address or adjustments for special specification systems are correctly settled.

(2) Safety check:

With the insulation tester of 500 V, inspect the insulation resistance.

Do not touch the transmission cable and remote controller cable with the tester.

The resistance should be over 1.0 M Ω . Do not proceed inspection if the resistance is less than 1.0 M Ω .

Inspect between the outdoor unit power supply terminal block and ground first, metallic parts like refrigerant pipes or the electrical box next, then inspect all electrical wiring of outdoor unit, indoor unit, and all linked equipment.

- (3) Before operation:
 - a) Turn the power supply switch of the outdoor unit to on for compressor protection. For a test run, wait at least 12 hours from this point.
 - b) Register control systems into remote controller(s). Never touch the ON/OFF switch of the remote controller(s). Refer to "7-2. Special Function Operation and Settings for M-NET Remote Controller" as for settings. In MA remote controller(s), this registration is unnecessary.
- (4) More than 12 hours later from power supply to the outdoor unit, turn all power switch to on for the test run. Perform test run according to the "Operation procedure" table of the bottom of this page. While test running, make test run reports.

8-1-1-1. Test run for M-NET Remote controller

Refer to "12-4. TEST RUN" for operation procedure.

8-1-2. Countermeasures For Error During Test Run

If a problem occurs during test run, a code number will appear on the remote controller (or LED on the outdoor unit), and the air conditioning system will automatically cease operating.

Determine the nature of the abnormality and apply corrective measures.

Check	Check			etected Un	it	Remarks
code (2 digits)	le code jits) (4 digits) Trouble		Indoor	Outdoor	Remote Controller	Remarks
Ed	0403	Serial communication error or Model selection SW error		0		Outdoor unit Multi controller board–Power board communication trouble
U2	1102	Compressor temperature trouble		0		Check delay code 1202
UE	1302	High pressure trouble or thermal protector trouble		0		Check delay code 1402
U7	1500	Superheat due to low discharge temperature trouble			İ	Check delay code 1600
		Refrigerant shortage trouble			İ	Check delay code 1601
U2	1501	Closed valve in cooling mode		0		Check delay code 1501
P6	1503	Freeze protection of Branch box or Indoor unit	0			,
EF	1508	4-way valve trouble in heating mode				Check delay code 1608
L6	2135	Circulation water freeze protection	0	Ť		, , , , , , , , , , , , , , , , , , , ,
PA	2500	Water leakage	Ō			
P5	2502	Drain overflow protection	Ö			
P4	2503	Drain sensor abnormality	Ö			
	3121	Out-of-range outside air temperature				
UF	4100	Compressor current interruption (Locked compressor)		 0		Check delay code 4350
Pb	4114	Fan trouble (Indoor)	0	\vdash		Check delay code 4000
FD	4114	Compressor overcurrent interruption/failure in 12 VDC power			-	
UP	4210	supply circuit on power circuit board				
U9	4220	Voltage shortage/overvoltage/PAM error/L1open phase/power synchronization signal error		0		Check delay code 4320
U5	4230	Heat sink temperature trouble				Check delay code 4330
U6	4250	Power module trouble or overcurrent trouble				Check delay code 4350
U8	4400	Fan trouble (Outdoor)		0		Check delay code 4500
	5404	Air inlet thermistor (TH21) open/short	0			
U3	5101	Compressor temperature thermistor (TH4) open/short		0		Check delay code 1202
		Liquid pipe temperature thermistor (TH22) open/short	0			
U4	5102	Suction pipe temperature thermistor (TH6) open/short				Check delay code 1211
U4	5103	Gas pipe temperature thermistor (TH23) open/short	0	Ť		,
U4	5105	Outdoor liquid pipe temperature thermistor (TH3) open/short				Check delay code 1205
U4	5106	Ambient temperature thermistor (TH7) open/short		Ŏ		Check delay code 1221
U4	5109	HIC pipe temperature thermistor (TH2) open/short		Ŏ		Check delay code 1222
U4	5110	Heat sink temperature thermistor (TH8) open/short		Ŏ		Check delay code 1214
F5	5201	High pressure sensor (63HS) trouble		0		Check delay code 1402
F3	5202	Low pressure sensor (63LS) trouble		 	 	Check delay code 1400
UH	5300	Primary current error		<u> </u>	-	Check delay code 4310
P4	5701	Contact failure of drain float switch	0	\vdash	-	Check delay code 4010
A0	6600	Duplex address error			0	Only M-NET Remote controller is detected.
A2	6602	•	$\frac{\circ}{\circ}$	<u> </u>	<u> </u>	Only M-NET Remote controller is detected.
A2 A3	6603	Transmission processor hardware error Transmission bus BUSY error				- 3
		-				Only M NET Remote controller is detected.
A6	6606	Signal communication error with transmission processor	0	0	0	Only M-NET Remote controller is detected.
A7	6607	No ACK error	0		0	Only M-NET Remote controller is detected.
A8	6608	No response frame error	<u> </u>	-		Only M-NET Remote controller is detected.
E0/E4		MA communication receive error	0	-	0	Only MA Remote controller is detected.
E3/E5	6832	MA communication send error	<u> </u>		0	Only MA Remote controller is detected.
E3/E5	6833	MA communication send error	0		0	Only MA Remote controller is detected.
E0/E4	6834	MA communication receive error	0	L		Only MA Remote controller is detected.
EF	7100	Total capacity error		0		
EF	7101	Capacity code error	0	0		
EF	7102	Connecting excessive number of units and branch boxes		0		
EF	7105	Address setting error		0		
EF	7130	Incompatible unit combination error		0		

NOTES:

- 1. When the outdoor unit detects No ACK error/No response error, an object indoor unit is treated as a stop, and not assumed to be abnormal.
- 2. The check codes displayed on the units may be different between the error source and others. In that case, please refer to the check code of error source by displayed attribute and address.
- 3. Refer to the service manual of indoor unit or remote controller for the detail of error detected in indoor unit or remote controller.
 - Self-diagnosis function


The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1) and LED indication (LED1, LED2) found on the outdoor multi controller circuit board. LED indication: Set all contacts of SW1 to OFF.

• During normal operation

The LED indicates the drive state of outdoor unit.

Bit	1	2	3	4	5	6	7	8
Indication	Compressor operated	52C	21S4	SV1	(SV2)	_	_	Always lit

[Example] When the compressor and SV1 are on during cooling operation.




8-1-3. SELF-DIAGNOSIS ACTION BY FLOWCHART

Check code 0403 (Ed)

Serial communication error or Model selection SW error

Abnormal points and detection methods	Causes and checkpoints
If serial communication between the outdoor multi controller circuit board and outdoor power circuit board is defective.	Wire breakage or contact failure of connector CN2 or CN4 Malfunction of communication circuit to power circuit board on outdoor multi controller circuit board Malfunction of communication circuit on outdoor power circuit board

Diagnosis of defects




Compressor temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
(1) If the TH4 temperature becomes conditions as follows: •exceeds 230°F [110°C] continuously for 5 minutes •exceeds 257°F [125°C]	Malfunction of stop valve Over-heated compressor operation caused by shortage of refrigerant
(2) If a pressure detected by the high pressure sensor and converted to saturation temperature exceeds 104°F [40°C] during defrosting, and TH4 exceeds 230°F [110°C].	 ③ Defective thermistor ④ Defective outdoor controller board ⑤ LEV performance failure ⑥ Defective indoor controller board
TH4: Thermistor <compressor> LEV: Linear expansion valve</compressor>	Clogged refrigerant system caused by foreign object Refrigerant shortage while in heating operation (Refrigerant liquid accumulation in compressor while indoor unit is OFF/thermo-OFF.)

Diagnosis of defects






Compressor temperature trouble

Chart 2 of 2

Diagnosis of defects




1302 (UE)

High pressure trouble or thermal protector trouble

Chart 1 of 4

Abnormal points and detection methods	Causes and checkpoints
(1) High pressure abnormality (63H operation) If 63H operates(*) during compressor operation. (*602 PSIG [4.15 MPaG])	Defective operation of stop valve (not fully open) Clogged or broken pipe Malfunction or locked outdoor fan motor Short-cycle of outdoor unit
 (2) High pressure abnormality (63HS detected) If a pressure detected by 63HS is 625 PSIG [4.31 MPaG]or more during compressor operation. If a pressure detected by 63HS is 600 PSIG [4.14 MpaG] or more for 3 minutes during compressor operation. (3) Compressor temperature abnormality (TRS operation) If TRS operates(*) during compressor operation. (*266°F[130°C]) 	Dirt of outdoor heat exchanger Remote controller transmitting error caused by noise interference Contact failure of the outdoor controller board connector Defective outdoor controller board Short-cycle of indoor unit Decreased airflow, clogged filter, or dirt on indoor unit. Malfunction or locked indoor fan motor Decreased airflow caused by defective inspection of outdoor temperature thermistor (It detects lower temperature than actual temperature.) Indoor LEV performance failure


Diagnosis of defects





High pressure trouble or thermal protector trouble


Chart 2 of 4





High pressure trouble or thermal protector trouble


Chart 3 of 4





High pressure trouble or thermal protector trouble

Chart 4 of 4




1500 (U7)

Superheat due to low discharge temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
If the discharge superheat is continuously detected -27°F [-15°C](*) or less for 5 minutes even though the indoor LEV has minimum open pulse after the compressor starts operating for 10 minutes. LEV: Linear expansion valve TH4: Thermistor <compressor> 63HS: High pressure sensor *At this temperature, conditions for the abnormality detection will not be satisfied if no abnormality is detected on either TH4 or 63HS.</compressor>	Disconnection or loose connection of TH4 Defective holder of TH4 Disconnection of LEV coil Disconnection of LEV connector EEV performance failure






Superheat due to low discharge temperature trouble

Chart 2 of 2

Diagnosis of defects




Refrigerant shortage trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
 (1) When all of the following conditions have been satisfied for 15 consecutive minutes: 1. The compressor is operating in HEAT mode. 2. Discharge super heat is 176°F [80°C] or more. 3. Difference between TH7 and the TH3 applies to the formula of (TH7-TH3 < 9°F [5°C]). 4.The saturation temperature converted from a high pressure sensor detects below 95°F [35°C]. 	① Defective operation of stop valve (not fully open) ② Defective thermistor ③ Defective outdoor controller board ④ Indoor LEV performance failure ⑤ Gas leakage or shortage ⑥ Defective 63HS
(2) When all of the following conditions have been satisfied: 1.The compressor is in operation. 2.When cooling, discharge superheat is 144°F [80°C] or more, and the saturation temperature converted from a high pressure sensor is over -40°F [-40°C]. When heating, discharge superheat is 162°F [90°C] or more.	TH3: Thermistor <outdoor liquid="" pipe=""> TH7: Thermistor <ambient> LEV: Linear expansion valve 63HS: High pressure sensor</ambient></outdoor>

Diagnosis of defects






Refrigerant shortage trouble

Chart 2 of 2


Diagnosis of defects



Closed valve in cooling mode

Abnormal points and detection methods	Causes and checkpoints
If stop valve is closed during cooling operation. When both of the following temperature conditions have been satisfied for 20 minutes or more during cooling operation. 1. TH22j − TH21j ≥ −3.6°F [−2°C]	① Outdoor liquid/gas valve is closed. ② Mulfunction of outdoor LEV (LEV-A) (blockage)
2. TH23j - TH21j ≥ -3.6°F [-2°C] Note: For indoor unit, the abnormality is detected if an operating unit satisfies the condition.	TH21: Indoor intake temperature thermistor TH22: Indoor liquid pipe temperature thermistor TH23: Indoor gas pipe temperature thermistor LEV: Linear expansion valve


Diagnosis of defects



Freeze protection of Branch box or Indoor unit

Abnormal points and detection methods	Causes and checkpoints
dew condensation which is caused when a refrigerant keeps flowing into	①Wrong piping connection between indoor unit and branch box②Miswiring between indoor unit and branch box
When all of the following conditions are satisfied: 1. The compressor is operating in COOL mode.	③Miswiring of LEV in branch box⊕Malfunction of LEV in branch box
 2. 15 minutes have passed after the startup of the compressor, or the change in the number of operating indoor units is made (including a change by turning thermo-ON/OFF). 3. After the condition 2 above is satisfied, the thermistor of indoor unit in STOP detects TH22j ≤ 23°F [-5°C] for 5 consecutive minutes. 	LEV: Linear expansion valve


Diagnosis of defects



4-way valve trouble in heating mode

Abnormal points and detection methods	Causes and checkpoints
If 4-way valve does not operate during heating operation.	①4-way valve failure
	② Disconnection or failure of 4-way valve coil
When any of the following temperature conditions is satisfied for 3 minutes	③ Clogged drain pipe
or more during heating operation when the outdoor temperature is -4°F [-20°C] or more:	Disconnection or loose connection of connectors
1. TH22j − TH21j ≤ −18°F [−10°C]	⑤ Malfunction of input circuit on outdoor multi controller circuit board
2. TH23j = TH21j ≤ −18°F [−10°C]	© Defective outdoor power circuit board
3. TH22j ≤ 37.4°F [3°C]	'
4. TH23j ≤ 37.4°F [3°C]	TH21: Indoor intake temperature thermistor (RT11 or TH1)
	TH22: Indoor liquid pipe temperature thermistor (RT13 or TH2)
Note:	TH23: Indoor gas pipe temperature thermistor (TH-A to E)
For indoor unit, the abnormality is detected if an operating unit satisfies the condition.	3 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1


Diagnosis of defects



Out-of-range outside air temperature

Abnormal points and detection methods	Causes and checkpoints
When the thermistor temperature of -24°F[-31.1°C] or below has continuously been detected for 3 minutes during heating operation (during compressor operation), the unit makes an error stop and "3121" appears on the LED1 and LED2. The compressor restarts when the thermistor temperature is -14°F [-25.6°C] or above. If the unit is turned OFF, the outdoor temperature error will be canceled.	Outdoor air temperature Thermistor failure Wire failure Defective outdoor controller board

Diagnosis of defects




4100 (UF)

Compressor current interruption (Locked compressor)

Chart 1 of 2


Abnormal points and detection methods	Causes and checkpoints
If overcurrent of DC bus or compressor is detected before 30 seconds after the compressor starts operating.	Closed stop valve Decrease of power supply voltage Looseness, disconnection, or wrong phase of compressor wiring connection Incorrect DIP-SW setting of model selection on the outdoor controller board Defective compressor Defective outdoor power circuit board





Compressor current interruption (Locked compressor)

Chart 2 of 2




Check code 4210 (UP)

Compressor overcurrent interruption/failure in 12 VDC power supply circuit on power circuit board

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
① If overcurrent of compressor is detected after 30 seconds since the compressor starts operating. ② If 12 VDC power is not supplied from the 12 VDC supply circuit on the power circuit board.	Closed outdoor stop valve Decrease of power supply voltage Looseness, disconnection or reverse phase of compressor wiring connection Malfunction of indoor/outdoor fan Short-cycle of indoor/outdoor unit Model selection error upon replacement of outdoor multi controller circuit board Malfunction of input circuit on outdoor multi controller circuit board Defective compressor Defective outdoor power circuit board

Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Check code 4210 (UP)

Compressor overcurrent interruption/failure in 12 VDC power supply circuit on power circuit board

Chart 2 of 2

Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



4220 (U9)


Voltage shortage /Overvoltage/PAM error/L1 open phase/ Primary current sensor error/Power synchronization signal error

Chart 1 of 2

Abnormal points and detection methods Causes and checkpoints If any of following symptoms are detected; ① Decrease/increase of power supply voltage ②L1 open-phase (3-phase only) •Decrease of DC bus voltage to 200 V (Single-phase), 350 V (3-phase) ③ Primary current sensor failure •Increase of DC bus voltage to 400 V (Single-phase), 760 V (3-phase) 4 Disconnection of compressor wiring •DC bus voltage stays at 310 V or less for consecutive 30 seconds when ⑤ Malfunction of 52C relay the operational frequency is over 20 Hz. 6 Defective outdoor power circuit board Malfunction of 52C relay driving circuit on outdoor •When any of following conditions is satisfied while the detections value of multi controller circuit board primary current is 0.1 A or less. ® Disconnection of CN5 (3-phase only) Disconnection of CN2 1. The operational frequency is 40 Hz or more. Malfunction of primary current detecting circuit on 2. The compressor current is 6 A or more. outdoor power circuit board (ii) Malfunction of resistor connected to 52C relay on outdoor power circuit board (3-phase only)

Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Single phase: single phase model 3-phase: three phase for wire model




4220 (U9)

Voltage shortage/overvoltage/PAM error/L1 open phase/primary current sensor error/power synchronization signal error

Chart 2 of 2


 Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Heat sink temperature trouble

Abnormal points and detection methods	Causes and checkpoints
If TH8 detects a temperature outside the specified range during	① Blocked outdoor fan
compressor operation.	②Malfunction of outdoor fan motor
	③ Blocked airflow path
TH8: Thermistor <heat sink=""></heat>	④Rise of ambient temperature
	⑤ Characteristic defect of thermistor
	Malfunction of input circuit on outdoor power board


Diagnosis of defects



Power module trouble or overcurrent trouble

Abnormal points and detection methods	Causes and checkpoints
If overcurrent of DC bus or compressor is detected 30 seconds after the compressor starts operating. To determine the source of abnormality, either the compressor or the power module, drive the power module forcedly.	Closed outdoor stop valve Decrease of power supply voltage Disconnection, looseness or conversed connection of compressor wiring Defective compressor Defective outdoor power circuit board


Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Fan trouble

Abnormal points and detection methods	Causes and checkpoints
If no rotational frequency is detected, or detected a value outside the specified range during fan motor operation.	Malfunction of fan motor Disconnection of CNF connector Defective outdoor controller board

Diagnosis of defects




Compressor temperature thermistor (TH4) open/short

<Detected in outdoor unit>

Abnormal points and detection methods	Causes and checkpoints
If TH4 detects to be open/short. (The open/short detection is disabled for 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation. The detection is also disabled when the outdoor temperature is 41°F [5°C] or less in cooling operation, and -4°F [-20°C] or less in heating.) Open: 37.4°F [3°C] or less Short: 422.6°F [217°C] or more TH4: Thermistor < Compressor>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board

Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Suction pipe temperature thermistor (TH6) open/short

<Detected in outdoor unit>

Abnormal points and detection methods	Causes and checkpoints
If TH6 detects to be open/short. (The open/short detection is disabled during 10 seconds to 10 minutes. after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH6: Thermistor <suction pipe=""></suction>	Disconnection or contact failure of connectors Characteristic defect of thermistor Defective outdoor controller board

Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




5105 (U4)

Outdoor liquid pipe temperature thermistor (TH3) open/short

Abnormal points and detection methods	Causes and checkpoints
If TH3 detects to be open/short. (The open/short detection is disabled during 10 seconds to 10 minutes. after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH3: Thermistor <outdoor liquid="" pipe=""></outdoor>	Disconnection or contact failure of connectors Characteristic defect of thermistor Defective outdoor controller board

Diagnosis of defects


Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Ambient temperature thermistor (TH7) open/short

Abnormal points	and detection methods	Causes and checkpoints
If TH7 detects to be open/short Open: -40°F [-40°C] or less Short: 194°F [90°C] or more	TH7: Thermistor <ambient></ambient>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board

Diagnosis of defects




HIC pipe temperature thermistor (TH2) open/short

Abnormal points and detection methods	Causes and checkpoints
If TH2 detects to be open/short. Open: -40°F [-40°C] or less Short: 194°F [90°C] or more TH2: Thermistor <hic pipe=""></hic>	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board

Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Heat sink temperature thermistor(TH8) open/short

Abnormal points and detection methods	Causes and checkpoints
If TH8 detects to be open/short. Open: -31.2°F [-35.1°C] or less Short: 338.5°F [170.3°C] or more	① Disconnection or contact failure of connectors ② Characteristic defect of thermistor ③ Defective outdoor controller board
TH8: Thermistor <heat sink=""></heat>	

Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




5201 (F5)

High pressure sensor (63HS) trouble

Abnormal points and detection methods	Causes and checkpoints
①When the detected pressure in the high pressure sensor is 14 PSIG or less during operation, the compressor stops operation and enters into an anti-restart mode for 3 minutes.	Defective high pressure sensor Decrease of internal pressure caused by gas leakage
②When the detected pressure is 14 PSIG or less immediately before restarting, the compressor falls into an abnormal stop with a check code <5201>.	Disconnection or contact failure of connector Malfunction of input circuit on outdoor controller board
③ For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.	

Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




Low pressure sensor (63LS) trouble

Abnormal points and detection methods	Causes and checkpoints
① When the detected pressure in the low pressure sensor is −33 PSIG or less, or 329 PSIG or more during operation, the compressor stops operation with a check code <5202>.	Defective low pressure sensor Decrease of internal pressure caused by gas leakage
② For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.	Disconnection or contact failure of connector Malfunction of input circuit on outdoor controller board

Diagnosis of defects


Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Primary current error

	Abnormal poin	ts and detection	on methods	Causes and checkpoints
If any of the following conditions is detected: ① Primary current sensor detects any of the following conditions (single phase unit only):			Decrease/trouble of power supply voltage Disconnection of compressor wiring Current sensor trouble on outdoor power circuit	
	Model name	10 consecutive- second detection	One-time detection	board ① Wiring through current sensor (penetration type) is
	NTXMSM36/48	34 A	38 A	
	NTXMSH36/42/48 NTXMSM60	37 A	40 A	not done.
	ondary current sensor dondary current sensor d			


Diagnosis of defects



Duplex address error

Abnormal points and detection methods	Causes and checkpoints
If 2 or more units with the same address are existing.	①There are 2 units or more with the same address in their controller among outdoor unit, indoor unit, Fresh Master, Lossnay or remote controller ② Noise interference on indoor/outdoor connectors


Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Transmission processor hardware error

Abnormal points and detection methods	Causes and checkpoints
If the transmission line shows "1" although the transmission processor transmitted "0".	 A transmitting data collision occurred because of a wiring work or polarity change has performed while the power is ON on either of the indoor/outdoor unit, Fresh Master or Lossnay
	Malfunction of transmitting circuit on transmission processor Noise interference on indoor/outdoor connectors


Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Transmission bus BUSY error

Abnormal points and detection methods	Causes and checkpoints
An abnormality when no transmission status caused by transmitting data collision continues for 8 to 10 minutes. An abnormality when data cannot be output on the transmission line consecutively because of noise etc. for 8 to 10 minutes.	 The transmission processor is unable to transmit due to a short-cycle voltage such as noise is mixed on the transmission line. The transmission processor is unable to transmit due to an increase of transmission data amount caused by a miswiring of the terminal block (transmission line) (TB3) and the terminal block (centralized control line) (TB7) on the outdoor unit. The share on transmission line becomes high due to a mixed transmission caused by a malfunction of repeater on the outdoor unit, which is a function to connect/disconnect transmission from/to control system and centralized control system.

Diagnosis of defects



Signal communication error with transmission processor

Abnormal points and detection methods	Causes and checkpoints
If the data of unit/transmission processor were not normally transmitted. If the address transmission from the unit processor was not normally transmitted.	Accidental disturbance such as noise or lightning surge Bernard Bernard

Diagnosis of defects




Chart 1 of 4

	Chart 1 of 4
Abnormal points and detection methods	Causes and checkpoints
Represents a common error detection An abnormality detected by the sending side controller when receiving no ACK from the receiving side, though signal was once sent. The sending side searches the error in 30 seconds interval for 6 times continuously.	The previous address unit does not exist since the address switch was changed while in electric continuity status. Decline of transmission voltage/signal caused by tolerance over on transmission line At the furthest end: 656 ft [200 m] On remote controller line: 39 ft [12 m] Decline of transmission voltage/ signal due to unmatched transmission line types Types for shield line: CVVS, CPEVS, or MVVS Line diameter: AWG 16 [1.25 mm²] Decline of transmission voltage/ signal due to excessive number of connected units Malfunction due to accidental disturbance such as noise or lightning surge Defect of error source controller
② The cause of displayed address and attribute is on the outdoor unit side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the outdoor unit.	Contact failure of indoor/outdoor unit transmission line Disconnection of transmission connector (CN2M) on indoor unit Malfunction of sending/receiving circuit on indoor/outdoor unit Disconnection of the connectors on the circuit board Cut off of power supply for outdoor unit caused by high pressure protection(63H).
③ The cause of displayed address and attribute is on the indoor unit side. An abnormality detected by the remote controller if receiving no ACK when sending data from the remote controller to the indoor unit.	While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON. Contact failure of indoor unit or remote controller transmission line Disconnection of transmission connector (CN2M) on indoor unit Malfunction of sending/receiving circuit on indoor unit or remote controller
The cause of the displayed address and attribute is on the remote controller side An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the remote controller.	While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON. Contact failure of indoor unit or remote controller transmission line Disconnection of transmission connector (CN2M) on indoor unit Malfunction of sending/receiving circuit on indoor unit or remote controller

Chart 2 of 4

	Chart 2 of 4
Abnormal points and detection methods	Causes and checkpoints
⑤ The cause of displayed address and attribute is on the Fresh Master side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the Fresh Master.	While the indoor unit is operating with multi refrigerant system Fresh Master, an abnormality is detected when the indoor unit transmits signal to the remote controller while the outdoor unit with the same refrigerant system as the Fresh Master is turned OFF, or within 2 minutes after it turned back ON.
	© Contact failure of indoor unit or Fresh Master transmission line
	③ Disconnection of transmission connector (CN2M) on indoor unit or Fresh Master
	Malfunction of sending/receiving circuit on indoor unit or Fresh Master
® The cause of displayed address and attribute is on Lossnay side. An abnormality detected by the indoor unit if receiving no ACK when the indoor unit transmit signal to the Lossnay.	① An abnormality is detected when the indoor unit transmits signal to Lossnay while the Lossnay is turned OFF.
	②While the indoor unit is operating with the other refrigerant Lossnay, an abnormality is detected when the indoor unit transmits signal to the Lossnay while the outdoor unit with the same refrigerant system as the Lossnay is turned OFF, or within 2 minutes after it turned back ON.
	③ Contact failure of indoor unit or Lossnay transmission line
	Disconnection of transmission connector (CN2M) on indoor unit
	Malfunction of sending/receiving circuit on indoor unit or Lossnay
⊕The controller of displayed address and attribute is not recognized.	① The previous address unit does not exist since the address switch was changed while in electric continuity status.
	② An abnormality detected at transmitting from the indoor unit since the Fresh Master/Lossnay address are changed after synchronized setting of Fresh Master/Lossnay by the remote controller.

Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Chart 3 of 4

When the address of the outdoor unit is displayed as abnormal, the outdoor circuit board may be faulty. If the unit is not restored after conducting the following procedure, check the outdoor circuit board.





Chart 4 of 4


Diagnosis of defects



No response frame error

Abnormal points and detection methods	Causes and checkpoints
If receiving no response command while already received ACK. The sending side searches the error in 30 seconds interval for 6 times continuously.	① Continuous failure of transmission due to noise etc ② Decline of transmission voltage/signal caused by tolerance over on transmission line ·At the furthest end: 656 ft [200 m] ·On remote controller line: 39 ft [12 m]
	 ③ Decline of transmission voltage/signal due to unmatched transmission line types Types for shield line: CVVS, CPEVS, or MVVS Line diameter: AWG 16 [1.25 mm²] ④ Accidental malfunction of error source controller

Diagnosis of defects




MA communication receive error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
Detected in remote controller or indoor unit: ① When the main or sub remote controller cannot receive signal from indoor unit which has the "0" address. ② When the sub remote controller cannot receive signal. ③ When the indoor controller board cannot receive signal from remote controller or another indoor unit. ④ When the indoor controller board cannot receive signal.	Contact failure of remote controller wirings Irregular Wiring (A wiring length, number of connecting remote controllers or indoor units, or a wiring thickness does not meet the conditions specified in the chapter "Electrical Work" in the indoor unit Installation Manual.) Malfunction of the remote controller sending/receiving circuit on indoor unit with the LED2 is blinking. Malfunction of the remote controller sending/receiving circuit Remote controller transmitting error caused by noise interference

Diagnosis of defects






MA communication receive error

Chart 2 of 2

Diagnosis of defects




MA communication send error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
Detected in remote controller or indoor unit.	There are 2 remote controllers set as main. Malfunction of remote controller sending/receiving circuit Malfunction of sending/receiving circuit on indoor controller board Remote controller transmitting error caused by noise interference

Diagnosis of defects






MA communication send error

Chart 2 of 2


Diagnosis of defects



Total capacity error

Abnormal points and detection methods	Causes and checkpoints
When the total capacity of connected indoor units exceeds the specified capacity (130% of the outdoor unit capacity), a check code <7100> is displayed.	The total capacity of connected indoor units exceeds the specified capacity (without Branch Box / with Branch Box). NTXMSM36/NTXMSH36: up to code 32/29 NTXMSH42: up to code 39/35 NTXMSM48/NTXMSH48: up to code 43/40 NTXMSM60: up to code 56/53 The model name code of the outdoor unit is registered wrongly.


Diagnosis of defects



Capacity code error

Abnormal points and detection methods	Causes and checkpoints
When the capacity of connected indoor unit is over, check code <7101> is displayed.	The model name of connected indoor unit (model code) is read as incompatible.


Diagnosis of defects



Connecting excessive number of units and branch boxes

Abnormal points and detection methods	Causes and checkpoints
When the connected indoor units exceed the limit, a check code <7102> is displayed.	Connecting more indoor units than the limit. Abnormal if connecting status does not comply with the following limit; ① Maximum connectable indoor unit. ② Connect at least 1 indoor unit (Abnormal if connected none). ③ Connectable up to 2 branch boxes.


Diagnosis of defects



Address setting error

Abnormal points and detection methods	Causes and checkpoints
The address setting of outdoor unit or branch box is wrong.	Wrongly set address of branch box The outdoor unit is not set in 000, or in the range of 51 to 100.


Diagnosis of defects
 Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Incompatible unit combination error

Abnormal points and detection methods	Causes and checkpoints
When the connected indoor unit is not compatible with the outdoor unit, the outdoor unit detects the error at startup.	Connecting indoor unit(s) which is not authorized to connect to the outdoor unit.

Diagnosis of defects



8-2. REMOTE CONTROLLER DIAGNOSIS

Refer to "12-8. REMOTE CONTROLLER CHECK" for MA remote controller system.

8-3. REMOTE CONTROLLER TROUBLE

For the troubleshooting, refer to the remote controller's manuals.

8-4. THE FOLLOWING SYMPTOM DO NOT REPRESENT TROUBLE (EMERGENCY)

Symptom	Display of remote controller	CAUSE
Even the cooling (heating) operation selection button is pressed, the indoor unit cannot be operated.	"Cool (Heat)" blinks	The indoor unit cannot cool (Heat) if other indoor units are heating (Cooling).
The auto vane runs freely.	Normal display	Because of the control operation of auto vane, it may change over to horizontal blow automatically from the downward blow in cooling because the downward blow operation has been continued for 1 hour. At defrosting in heating, hot adjusting and thermostat OFF, it automatically changes over to horizontal blow.
Fan setting changes during heating.	Normal display	Ultra-low speed operation is commenced at thermostat OFF. Light air automatically change over to set value by time or piping temperature at thermostat ON.
Fan stops during heating operation.	"Heat Defrost 🗘 "	The fan stops during defrosting.
Fan does not stop while operation has been stopped.	Light out	Fan runs for 1 minute after stopping to exhaust residual heat (only in heating).
No setting of fan while start SW has been turned on.	"Heat Standby 🌣 "	Ultra-low speed operation for 5 minutes after SW ON or until piping temperature reaches 95°F [35°C]. Then low speed operates for 2 minutes and operates at the normal set air volume. (Hot adjust control)
Indoor unit remote controller shows "Please Wait" indicator for about 2 minutes when turning ON power supply.	"Please Wait" blinks	The system is in the process of startup. Operate remote controller again after "Please Wait" disappears.
Drain pump does not stop while unit has been stopped.	Light out	After a stop of cooling operation, unit continues to operate drain pump for 3 minutes and then stops.
Drain pump continues to operate while unit has been stopped.	_	Unit continues to operate drain pump if drainage is generated, even during a stop.

8-5. INTERNAL SWITCH FUNCTION TABLE

The black squ	uare	(■) indicates a	Opera	Operation in Each Switch Setting	witch Setting			
Switch	Step	Function	NO	OFF	When to Set	Remarks	Purpose	Additional Information
SWU1 ones digit SWU2 tens digit	Rotary switch	(hilip saua) (hili	en en en en en en en en en en en en en e		Before turning the power ON	Initial settings> SWU2 SWU3 (tens digit) (ones digit)	I	I
SW1 Digital Display Switch	1–8	ON	6 7 8		Can be set either during operation or not.	cInitial settings> ON TITITIAL OFF 1 2 3 4 5 6 7 8	I	I
	_	Selects operating system startup	With centralized controller	Without centralized controller	Before turning the power ON	Clnitial settings> ON TITEL OFF 1 2 3 4 5 6	Tum ON when the centralized controller is connected to the outdoor unit.	SW2-1 must be turned ON if a central controller is connected to the system. An example of this would be a TC-24, EW50A, AG510, AE50 or AE200 if SW2-1 is not tumed on while using a central controller, in rare dircumstances problems may be encountiered such as indoor units not been countied out on proposition by group commands. Therefore, turning SW2-1 ON is recommended if a central controller is used.
SWZ	2	Connection Information Clear Switch	Clear	Do not clear) - -	When relocating units or connecting additional units.	
Switch	က	Abnormal data clear switch input	Clear abnormal data	Normal	OFF to ON any time after the power is turned on.		To delete an error history.	
	4	Pump down	NO	OFF	During compressor running		To facilitate outdoor unit the pumping down operation. Frequency = Fixed to 65 Hz Indoor-linear expansion valve = Fully open Outdoor fan step = Fixed to 10	Please refer to a section referring to the pumping down on outdoor units Installation Manuals. It might not be possible to collect all the refrigerant if the amount is excessive.
	5	Connect branch box	Connect	Not connect	Before the power is turned ON.	<lu>lnitial settings></lu> OFF	I	I
	9	1		I	I	ı	I	I
		MODEL SELECTION 1:ON 0:OFF						
SW2/ SW4/ SW8/ SW9 Model Switch	9–1	MODELS SW7 SW4 SW8 SW8 SW8 WODELS SW8 WODELS SW8 WODELS SW8 SW8 SW8 SW8 SW8 WODELS SW8 SW8 SW8 SW8 WODELS SW8 SW8 SW8 SW8 WODELS SW8 SW8 SW8 SW8 SW8 WODELS SW8	MODELS SNY SNA SNA SNA SNA SNA SNA SNA SNA SNA SNA	8/8/8 8/	Before the power is turned ON.	Initial settings> Set for each capacity.	l	I
SW3 Trial	1	ON/OFF from outdoor unit	NO	OFF	Any time after the	<pre><initial settings=""> on </initial></pre>	I	I
operation	2	Mode setting	Heating	Cooling	power is turned Oin.	0FF 1 2	I	I
	_	1	1	1			ı	1
, l	7	Change the indoor unit's LEV opening at startup	Enable	Normal	Can be set when off or during operation		To set the LEV opening at startup higher than usual. (+150 pulses) To improve the operation with the LEV almost clogged.	The refrigerant flow noise at start- up become louder.
	3	1	I	I			1	1
SW5	4	Auxiliary heater	Enable	Disable	Before the power is turned ON.	<initial settings=""></initial>	Turn ON when an auxiliary heafer is connected. (It transmits a connection permission signal of the auxiliary heater to the connected CITY MULTI indoor unit.)	Turn ON only when the auxiliary heater is connected and operated.
Function	2	Change the indoor unit's LEV opening at defrost	Enable	Normal	et when uring	OFF 1 2 3 4 5 6 7 8	To set the LEV opening higher than usual during defrosting operation. (Only Qi ≤ 10 is valid, + 300 pulses) To avoid the discharge temperature increase and provide efficient defrosting operation.	The refrigerant flow noise during the defrosting operation becomes louder.
	9	Switching the target sub cool (Heating mode)	Enable	Normal	operation		To decrease the target sub cool value. To reduce the discharge temperature decrease due to refrigerant liquid accumulation in the units.	A refrigerant flow noise might be generated if the sub cool value is too small.

Switch	Step	Function	Operatio ON	Operation in Each Syon	Switch Setting When to Set	Remarks	Purpose	Additional Information
SW5 Function switch	7	During the outdoor unit is in HEAT operation, additionally increase about 50 to 70 pulses of the LEV opening on the indoor unit which is in FAN, STOP, COOL or thermo-OFF*1.	Active	Inactive	Can be set when OFF or during operation	<pre></pre>	To additionally increase about 50 to 70 pulses of the LEV opening for units other than in HEAT operation. To avoid a refrigerant shortage (less capacity) due to refrigerant liquid accumulation in the units which is not in operation.	A refrigerant flow noise might be generated in units other than the one in operation.
	∞	During the outdoor unit is in operation, fully closing the linear expansion valve on the indoor unit which is in FAN or COOL.*2	Enable	Normal	Before turning the power ON.	12345678	To reduce the room temperature increase by setting the LEV opening lower for the units in thermo-OFF operation.	The refrigerant is more likely to collect in the units with thermo-OFF operation, and causing the units refrigerant shortage. (Results in less capacity and increase of discharge temperature.)
	-	I	I	ı	ı		ı	ı
	2		1	1	1	<initial settings=""></initial>	1	
	3		I	I		NO	I	-
SW6	4	Change of defrosting control	Enable (For high humidity)	Normal	Can be set	OFF 1 2 3 4 5 6 7 8	To shorten the defrosting prohibition time in high humidity (or heavy snow) region, in order to reduce malfunctions caused by frost.	The performance of the HEAT operation is somewhat reduced since the defrosting operation is frequently performed.
Function	2	_	1	Ι	when OFF		-	_
MICI	9	Switching the target discharge pressure (Pdm)	Enable	Normal	or during operation	SW6-6 OFF ON Tarnet Ddm (knlm2) 31.5, 33.5.	To raise the performance by setting the Pdm higher during HEAT operation.	Power consumption is raised due to a higher frequency. (The performance would not be raise at the maximum operating frequency.)
	7	Switching (1) the target evaporation temperature (ETm)	Enable	Normal	SW6-7	⊣ । ।	To raiselreduce the performance by changing the target ETm during COOL operation.	Switching it to raise the performance, it raises the power consumption, and produces more dew condensation.
	∞	Switching (2) the target evaporation temperature (ETm)	Enable	Normal	Target ETm (°F(°C)	Target ETm (°F(°C)) 48(9) 52(11) 43(6) 57(14)	Switch to raise the performance: raises the performance Switch to reduce the performance; prevents dew condensation	Switching it to reduce the performance, it makes the performance insufficient.
	-	Ignore current sensor abnormality and rotational frequency abnormality of outdoor fan motor	Enable	Normal	After turning the power ON	Initial settings>NTXMSM36/48/60>	To perform a test run for electrical parts alone without running the compressor. Also, to perform the troubleshooting of electrical parts without operating the outdoor unit's fan.	Make sure to connect the connectors to the compressor after checking the electrical parts. Be careful not to get electrical shock while working on electrical parts.
	2	Setting to energize the freeze stat heater (optional part)	During heating operation only*3	Include when the heating operation is OFF.*4	Can be set when OFF or during operation	ONF 123456	It reduces snow on the base, even it blows inside the unit, by setting the base heater ON while the HEAT operation is stopped.	Power consumption raises while the operation is stopped.
SW7 Function switch	8	High heating performance mode (except for NAMHZ2 model)	Enable	Normal	Anytime	<ntxmsh36 42="" 48=""></ntxmsh36>	To raise the performance of HEAT operation if it is insufficient.	The performance may not be raised depending on the capacity of indoor units in operation, or outside air temperature.
	4	Maximum frequency down at 1 hour after COOL operation	Enable	Normal	Can be set when OFF or during operation		To reduce dew condensation on the indoor unit by lowering the frequency.	The performance might be insufficient.
	5	Simultaneous cooling and heating with external heater	Enable	Disable	Anytime	123456	The simultaneous operation of cooling and heating will be possible by installing an external heater to the CITY MULTI indoor unit.	For the installation of external heater and the indoor unit setting, refer to the indoor unit service manual.
	9	Manual defrost	Manual defrost	Normal	During compressor running in HEAT mode.		Tum ON when it is necessary to perform the defrosting operation forcedly. (Effective only at startup, or 10 minutes after the last defrosting operation)	It performs the defrosting operation forcedly. (HEAT operation is stopped temporarily.)
	~	Auto change over from remote controller (IC with the minimum address)	Enable	Disable	Before turning the power ON	clnitial settings> cNTXMSM36/48, NTXMSH36/42/48> ON	Enables the indoor unit with the minimum address to select AUTO mode, and switches the operation mode of the other indoor units to the same mode.	Cannot be set when the centralized control is ON.
SW9 Function	7	Switching the Silent/ Demand mode	Demand control	Silent mode	Can be set when OFF or during operation	1 2 3 4 5 6 <ntxmsm60></ntxmsm60>	I	About the Silent mode/Demand control setting, refer to "8-6. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR".
Switch	3	*	I	I	ı	O C	I	I
	4	I	I	I	I	123456	I	I
	2	1	I	I	I	I	I	I
	٥	1	I	I	I	I		1

^{*1} SW5-7 Opens the indoor-linear expansion valve as a countermeasure against the indoor unit in FAN, COOL, STOP, or thermo-OFF operation with refrigerant-shortage status due to an accumulation of liquid refrigerant in the indoor unit. *2 SW5-8 Countermeasure against room temperature rise for indoor unit in FAN and COOL mode.


*3 During heating operation and the ambient temperature is 39°F (4°C) or below, the freeze prevention heater is energized.

*4 During heating mode is OFF (include thermo-OFF in cooling mode), and the ambient temperature is 39°F (4°C) or below, the freeze prevention heater is energized.

*5 Use it for Model Switch. ((H)P36/48)

8-6. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR

• State (CN51)



- A Distant control board
- ® Relay circuit
- © External output adapter
- (PAC-SA88HA-E)
- D Outdoor unit control board
- L₁: Error display lamp
- L2: Compressor operation lamp
- X, Y: Relay (coil rating: ≤ 0.9 W, 12 V DC)

ELamp power supply

©Relay power supply

ERelay power supply

© Procure locally

@Max. 33 ft [10 m]


Procure locally

@Max. 33 ft [10 m]

Procure locally

@Max. 33 ft [10 m]

• Auto change over (CN3N)




- A Remote control panel
- ® Relay circuit
- © External input adapter
- (PAC-SC36NA-E)
- DOutdoor unit control board

SW1: Switch SW2: Switch

X, Y: Relay (contact rating: ≥ 0.1 A, 15 V DC) (min. applicable load: ≤ 1 mA)

	ON	OFF
SW1	Heating	Cooling
SW2	Validity of SW1	Invalidity of SW1

• Silent Mode/Demand Control (CN3D)



- A Remote control panel
- B Relay circuit
- © External input adapter
- (PAC-SC36NA-E)
- DOutdoor unit control board

SW1: Switch SW2: Switch

X, Y: Relay (contact rating: ≥ 0.1 A, 15 V DC) (min. applicabl load: ≤ 1 mA)

The silent mode and the demand control are selected by switching the DIP switch 9-2 on outdoor controller board. It is possible to set it to the following power consumption (compared with ratings) by setting SW1, 2.

	Outdoor controller board DIP SW9-2	SW1	SW2	Function
Silent mode	OFF	ON	_	Silent mode operation
Demand control	ON	OFF	OFF	100% (Normal)
		ON	OFF	75%
		ON	ON	50%
		OFF	ON	0% (Stop)


8-7. HOW TO CHECK PARTS

Parts name					Checkpoii	nts		
Thermistor (TH2) <hic pipe=""></hic>	Disconnect the co					with a	multimeter.	
Thermistor (TH3) < Outdoor liquid pipe>		Norr	nal		Abnor	mal		
Thermistor (TH4)	TH4	160 to 4	410 kΩ					
<compressor> Thermistor (TH6) <suction pipe=""> Thermistor (TH7)</suction></compressor>	TH2 TH3 TH6 TH7	4.3 to 9	9.6 kΩ		Open or	short		
<ambient></ambient>	TH8	39 to 1	05 kΩ					
Thermistor (TH8) <heat sink=""></heat>								
Fan motor (MF1, MF2)	Measure the resi (At the ambient t				tor pins wi	th a m	ultimeter.	
M 3 4		Norma	al			Ab	normal	Model name of fan motor
M 4 5 6	1 - 4	5 - 4	6 - 4		7 - 4			CIC 00VV / CIC 00VV
7	1.1 ± 0.05 MΩ	40 ± 4 kΩ	220 ± 22	2 kΩ	Open		n or short t, for 7 - 4)	SIC-82XX / SIC-88XX
	Open	150 ± 15kΩ	55 ± 11	kΩ	Open	(01.01	., 101 / 1/	SIC-71XX / SIC-81XX
	* See the spec name p * Where "X" in model r						notor	
Solenoid valve coil	Measure the resi (At the ambient to	stance betweenperature 6	een the te 88°F [20°0	erminal C)	ls with a m	nultime	ter.	
(21S4)	Norn	nal		Ak	normal			
	1567.5 ±	156.8Ω		Ope	n or short			
Motor for compressor (MC)	Measure the resis (Winding tempera			rminal	s with a m	ultimet	er.	
	No	rmal		Al	onormal			
W V	0.305	± 0.015Ω		Оре	en or short			
Solenoid valve coil <bypass valve=""></bypass>	Measure the resis (At the ambient to				s with a m	ultimet	er.	
(SV1) <switching valve=""></switching>	Norm				normal			
(SV2)*2 2 Only NAMHZ2 model.	1197 ±	10Ω		Ope	n or short			
inear Expansion Valve LEV A)								
			Nori	mal				Abnormal
M F Gray 1 Orange 2 Red 3	Gray - Black	Gray -			y - Yellow	G	ray - Orang	e Open or short
Yellow 4 Black 5			46 ±	275				
Linear Expansion Valve								
(LEV B)			Nor	mal				Abnormal
M Blue 2 Orange 3	Red - White	Red - C	orange 46 ±		d - Yellow		Red - Blue	Open or short
Orange 3 Yellow 4 White 5								

Check method of DC fan motor (fan motor/outdoor multi controller circuit board)

- 1. Notes
 - High voltage is applied to the connecter (CNF1, 2) for the fan motor. Pay attention to the service.
 - Do not pull out the connector (CNF1, 2) for the motor with the power supply on. (It causes trouble of the outdoor multi controller circuit board and fan motor.)
- 2 Self check


Symptom: The outdoor fan cannot rotate.



Note: Turn SW7-1 OFF after the troubleshooting completes.


The fan sometimes starts on-off cycle operation during low-load operation or cooling at low ambient temperature. It is not abnormal; the operation ensures reliability of the product.


Check method of multi controller circuit board




208/230V AC ± 10%


Check method of power circuit board





Check method of M-NET power circuit board





8-8. HOW TO CHECK COMPONENTS

<Thermistor feature chart>

Low temperature thermistors

- Thermistor <Hic pipe> (TH2)
- Thermistor < Outdoor liquid pipe> (TH3)
- Thermistor <Suction pipe> (TH6)
- Thermistor < Ambient > (TH7)

Thermistor R0 = 15 k Ω ± 3 % B constant = 3480 ± 1 %

Rt =15exp{3480($\frac{1}{273+t} - \frac{1}{273}$)}

32°F [0°C] 15 kΩ 86°F [30°C] 4.3 kΩ 50°F [10°C] 9.6 kΩ 104°F [40°C] 3.0 kΩ

68°F [20°C] 6.3 kΩ 77°F [25°C] 5.2 kΩ

Medium temperature thermistor

• Thermistor <Heat sink> (TH8)

Thermistor R50 = 17 k Ω ± 2 % B constant = 4150 ± 3 %

Rt =17exp{4150($\frac{1}{273+t} - \frac{1}{323}$)}

 $\begin{array}{cccc} 0 \ ^{\circ}C & 180 \ k\Omega \\ 25 \ ^{\circ}C & 50 \ k\Omega \\ 50 \ ^{\circ}C & 17 \ k\Omega \\ 70 \ ^{\circ}C & 8 \ k\Omega \\ 90 \ ^{\circ}C & 4 \ k\Omega \\ \end{array}$


High temperature thermistor


• Thermistor < Compressor> (TH4)


Thermistor R120 = 7.465 k Ω ± 2 % B constant = 4057 ± 2 %

Rt =7.465exp{4057($\frac{1}{273+t} - \frac{1}{393}$)}

68°F [20°C]	250 kΩ	158°F [70°C]	34 kΩ
86°F [30°C]	160 kΩ	176°F [80°C]	24 kΩ
104°F [40°C]	104 kΩ	194°F [90°C]	17.5 kΩ
122°F [50°C]	70 kΩ	212°F [100°C]	13.0 kΩ
140°F [60°C]	48 kΩ	230°F [110°C]	9.8 kΩ







<LOW PRESSURE SENSOR>

Comparing the Low Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the low pressure sensor appears on the LED1 on the control board.





The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

(1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.

- 1) When the gauge pressure is between 0 and 14 PSIG [0.098 MPaG], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 14 PSIG [0.098 MPaG], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the outdoor temperature is 86°F [30°C] or less, and the pressure displayed on self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], go to (3).

When the outdoor temperature exceeds 86°F [30°C], and the pressure displayed on self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], go to (5).

- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).
- (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2 after 15 minutes have passed since the start of operation. (Compare them by PSIG [MPaG] unit.)
 - 1) When the difference between both pressures is within 29 PSIG [0.2MPaG], both the low pressure sensor and the control board are normal.
 - When the difference between both pressures exceeds 29 PSIG [0.2MPaG], the low pressure sensor has a problem. (performance deterioration)
 - 3) When the pressure displayed on the self-diagnosis LED1, 2 does not change, the low pressure sensor has a problem.
- (3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1, 2 display.
 - 1) When the pressure displayed on the self-diagnosis LED1,2 is between 0 and 14 PSIG [0.098 MPaG], the low pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is approximately 247 PSIG [1.7 MPaG], the control board has a problem.
- (4) Remove the low pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63LS) to check the pressure with the self-diagnosis LED1, 2.
- 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.
- (5) Remove the high pressure sensor (63HS) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis LED1, 2.
 - 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 247 PSIG [1.7 MPaG], the control board has a problem.
- 2) If other than 1), go to (2).


Low Pressure Sensor Configuration (63LS)

The low pressure sensor consists of the circuit shown in the figure below. If 5 V DC is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173 V per 14 PSIG [0.098 MPaG].


Note:


The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



③−① : 5 V (DC)
②−① : Output Vout (DC)





<HIGH PRESSURE SENSOR>

• Comparing the High Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the high pressure sensor appears on the LED1, 2 on the control board.





The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

(1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.

- 1) When the gauge pressure is between 0 and 14 PSIG [0.098 MPaG], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is between 14 PSIG [0.098 MPaG], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1, 2 exceeds 725 PSIG [5.0 MPaG], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

(2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1,2 after 15 minutes have passed since the start of operation. (Compare them by PSIG [MPaG] unit.)

- 1) When the difference between both pressures is within 36 PSIG [0.25 MPaG], both the high pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 36 PSIG [0.25 MPaG], the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on self-diagnosis LED1, 2 does not change, the high pressure sensor has a problem.
- (3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1, 2.
 - 1) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 14 PSIG [0.098 MPaG], the high pressure sensor has a problem.
 - 2) When the pressure displayed on self-diagnosis LED1, 2 is approximately 725 PSIG [5.0 MPaG], the control board has a problem.
- (4) Remove the high pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63HS) to check the pressure with self-diagnosis LED1, 2.
 - 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 725 PSIG [5.0 MPaG], the high pressure sensor has a problem.
 - 2) If other than 1), the control board has a problem.


High Pressure Sensor Configuration (63HS)

The high pressure sensor consists of the circuit shown in the figure below. If 5 V DC is applied between the white and the black wires, voltage corresponding to the pressure between the blue and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.078 V per 14 PSIG [0.098 MPaG].

Note:

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



OCHT810C

8-9. TEST POINT DIAGRAM

Outdoor multi controller circuit board <CAUTION> TEST POINT (1) is high voltage. SW2 SW3 SW7 SW4 CN51 SW8 External signal Model selection Pump down Test run Manual defrost Model selection output CN102 Connect to the M-P.B (CN2) SW6 (M-NET power circuit board) Function selection SW5 CN40.CN41 Centralized control power Function selection supply/ For storing SW9 jumper connector selection Function selection/ Model selection CNS₂ SW1 Transmission wire of Display selection centralized control (Self diagnosis) SWU2, SWU1 CNS₁ Address setting Branch box/ indoor unit /out-CNLVB door unit Linear expansion valve connecting wire CNLVA Linear expansion valve Connect to the outdoor power circuit board (CN4) Connect to the outdoor power circuit board (CN2) CN3N Auto change over Power circuit board → Transmitting signal to High pressure switch the multi controller board (0-5 V DC) 2-5: Zeró cross signal CN3D (0-5 V DC) Input of silent demand control ③-④: 15 V DC ⑥-⑤: 15 V DC TH2 Thermistor 6 ⑦-⑤: 15 V DC <Hic pipe> **TH4 Thermistor** CNAC <Compressor> Power supply for multi TH3 Thermistor controller circuit board <Outdoor liquid pipe> (CNAC2) 0 # 0 208/230 V AC TH7/TH6 Thermistor <Ambient/ Suction pipe> SS/BH 에(아바ㅇ 63HS Base heater High pressure sensor SV1 63LS ⊕ ⊕ ∘ Bypass valve Low pressure sensor NOITUAD SV2 VFG (TEST POINT4) Switching valve (Voltage between pin3 and pin4 of PC511 or PC512): (Only NAHZ2 model) (Correspond to CNF1,2 ⑦(+)–④(−)) o-‱ `o ∦ o` 4-way valve CNF1. 2 Vcc (TEST POINT⁽²⁾) Vsp VDC (TEST POINT(1)) **CNDC** (Voltage between pins of (Voltage between pins of Connect to fan motors (Voltage between pins of C510) 290V-380 V DC C82A): 15 V DC ①-④: 290V-380 V DC C515 and C516): 290V-380 V DC (①(+)-③(-)) 0 V DC (when stopped) ⑤-4: 15 V DC (Same as CNF1,2 5(+)-4(-)) Connect to the out-(Same as CNF1,2 ① 1-6.5 V DC (when operated) 6-4: 0-6.5 V DC door (+)-4(-))power circuit board

(CNDC)

0-15 V DC pulse

(when operated)

Outdoor power circuit board

NTXMSM60A182BA NTXMSH36A142BA NTXMSH42A152BA NTXMSH48A182BA

Brief Check of POWER MODULE

If they are short-circuited, it means that they are broken. Measure the resistance in the following points (connectors, etc.).

1. Check of POWER MODULE

① Check of DIODE circuit

R_L1 S_L1 R_N1 S_N1


② Check of IGBT circuit

L2 _ N1

3 Check of INVERTER circuit

P-U, P-V, P-W, N1-U, N1-V, N1-W

Note: The marks R, S, L1, L2, P, N1, U, V and W shown in the diagram are not actually printed on the board.



Outdoor power circuit board

NTXMSM36A142BA NTXMSM48A182BA

CN2

Connect to the outdoor multi controller circuit board (CN2)

①-⑤: Transmitting

signal to outdoor controller circuit board ((0-5 V DC)

Brief Check of POWER MODULE

If they are short-circuited, it means that they are broken. Measure the resistance in the following points (connectors, etc.).

1. Check of POWER MODULE

① Check of DIODE circuit

R _ P1 S _ P1 R _ N1 S _ N1


② Check of IGBT circuit

P2 _ L1 P2 _ L2 N2 _ L1 N2 _ L2

3 Check of INVERTER circuit

P3 _ U _ P3 _ V _ P3 _ W _ N3 _ U _ N3 _ V _ N3 _ W

Note: The marks R S L1 L2 P1 N1 U V and W shown in the diagram are not actually printed on the board.




El. E3. E4 Connect to the electrical parts box

Outdoor noise filter circuit board

NTXMSM60A182BA NTXMSH36A142BA NTXMSH42A152BA NTXMSH48A182BA


LI, NI POWER SUPPLY Voltage of 208/230 V AC is input (Connect to the terminal block (TB1)) M6 2.8±0.2 N·m



123

Voltage of 208/230 V AC (Connect to the outdoor power circuit board (TB3, TB4) M6 2.8±0.2 N⋅m

M-NET power circuit board



8-10. OUTDOOR UNIT FUNCTIONS

SW: setting 0...OFF 1...ON

	SW1	i				Display on the LEI	Display on the LED1, 2 (display data)				
Š	setting	Display mode									Notes
\exists	12345678		_	2	3	4	2	9	7	80	
_	0000000	Relay output display	Compressor operation	52C	21S4	SV1	(SV2)			Always lighting	ON: light on OFF: light off
		Check display	0000-9999 (Alter	0000-9999 (Alternating display of addresses and check code)	addresses and che	ck code)					 When abnormality occurs, check display.
1	100000000	Indoor unit check status		No.1 unit check No.2 unit check No.3	No.3 unit check	unit check No.4 unit check	No.5 unit check	No.6 unit check	No.7 unit check	No.8 unit check	Light on at time of abnormality
2	01000000	Protection input	High pressure abnormality	Superheat due to low discharge temperature	Compressor shell temperature abnormality	TH4 abnormality	TH3 abnormality	Outdoor fan rotation frequency abnormality	TH7 abnormality	TH8 abnormality	
က	11000000	Protection input	Heat sink overheating	Compressor over current interception	Voltage abnormality	Insufficient refrigerant amount abnormality	Current sensor/ primary current abnormality	63LS abnormality	63HS abnormality	start over current interception abnormality delay	Display detected microprocessor protection or abnormality
4	00100000	Protection input	Abnomality in the number of indoor units	Address double setting abnormality	Indoor unit capacity error	Over capacity	Indoor unit address error	Outdoor unit address error	Current sensor open/short	serial communication abnormality (outdoor unit)	adiloniany
2	10100000	Abnormality delay display 1	Abnormality delay display 1 High pressure abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation TH7 s frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	- - -
9	01100000	Abnormality delay display 2 Heat sink overheating delay	Heat sink overheating delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/ primary current abnormality delay	63LS abnormality delay	63HS abnormality delay		Start over current interception Display all abnormality abnormality delay delay
_	11100000	Abnormality delay display 3	3 63LS abnormality delay		4-way valve abnormality delay	Delay caused by blocked Power module valve in cooling mode abnormality del	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
- ω	00010000	Abnormality delay history 1	High pressure abnormality delay	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	- - -
6	10010000	Abnormality delay history 2	Heat sink overheating delay	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/ primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	Display all abnormalities remaining in abnormality delay
10	01010000	Abnormality delay history 3	Abnormality delay history 3 63LS abnormality delay	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by blocked Power module valve in cooling mode abnormality de	lay	TH6 abnormality Current sensor delay	Current sensor open/short delay		
7	11010000	Abnormality code history 1 (the latest)			Delay code Abn	Abnormality delay		Delay code Abnor	Abnormality delay		
12	00110000	Abnormality code history 2	21			Discharge/Comp. temperature		_	Discharge superheat (SHd)	(p	
13	\neg	Abnormality code history 3	8		The	Thermistor <compressor>(TH4)</compressor>	or>(TH4)	Over	Over charge refrigerant		of an ocition
4		Abnormality code history 4	4			Thermistor <outdoor liquid="" pipe=""></outdoor>	(TH3)	1601 Insuffi	Insufficient refrigerant		present (including
15	11110000	Abnormality code history 5	5 Alternating displa	y of addresses		Thermistor <suction pipe=""> (TH6)</suction>	16)		Closed cooling valve		abnormality
16	00001000	Abnormality code history 6	00001000 Abnormality code history 6 (including abnormality delay code	abnormality code		Thermistor <heat sink=""> (TH8)</heat>			4-way valve disconnection	_	 History record in 1 is the
17	10001000	Abnormality code history 7	2	many acidy code)		Thermistor <ambient> (TH7)</ambient>			Current sensor open/short	:	latest; records become older
0,		Abnormality and history 0				I nermistor <hic> (I HZ)</hic>			Undervoltage, overvoltage, or power module	or power module	in 10 is the oldest.
0 0		ADDIDITION CODE HISTORY C	0 6			Low pressure sensor	7		Heat sink temperature		
2	11001000		3		1402 High	High pressure (63H)			Power module		
20	0010100	Abnormality code history 10 (the oldest)			БН	High pressure sensor (63HS)		4500 Outdo	Outdoor ran motor		
21	10101000	Cumulative time	$\overline{}$								Display of cumulative
22	01101000	Cumulative time	0-9999 (unit: 10 hour)								compressor operating time
23	11101000	Outdoor unit operation displa	11101000 Outdoor unit operation display Compressor energizing	Compressor operating prohibition	Compressor operating prohibition Compressor in operation Abnormality detection	Abnormality detection					Light ON/Light OFF
24	00011000	Indoor unit operation mode No.1 unit mode	e No.1 unit mode	No.2 unit mode	No.3 unit mode	No.4 unit mode	No.5 unit mode	No.6 unit mode	No.7 unit mode	No.8 unit mode	Cooling : light on, Heating: light blinking Stop fan: light off
25	10011000	Indoor unit operation display	y No.1 unit operation	10011000 Indoor unit operation display No.1 unit operation No.2 unit operation	No.3 unit operation No.4 unit operation No.5 unit operation	No.4 unit operation		No.6 unit operation	No.6 unit operation No.7 unit operation No.8 unit operation	No.8 unit operation	Thermo ON: light on Thermo OFF: light off

N set set		•Display of indoor unit capacity code •The No. 1 unit will start from the M-NET address with the lowest number	•Display of indoor unit operating mode	Light on/light off Input: light on No input: light off	Display of communication demand capacity	Display a count of compressor operation/stop	Display detected current	Display cumulative time of thermo-ON operation	Display total capacity code of indoor units inthermo-ON	Display number of connected indoor units	Display bus voltage	Display active LEV control	Freeze prevention prevention beginning of SHd Display active compressor	frequency control		Display data at time of	abnormality								
	8												Freeze prevention control at the beginning of SHd		Power module abnormality						T	T			
	7			3-min delay/no								Correction of high compression ratio prevention		Hz-up inhibit control at the beginning of SHd	TH6 abnormality						000000	ge pressure			ge change
	9		Heating thermo-OFF	Excitation current/no								LEV opening correction depends on Td	Pd Back up control(heating)	Low pressure decrease prevention	Delay caused by blocked valve in cooling mode				nitation	emperature limitation	(e	ormal rise of dischar		2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	I due to receipt voltage
Display on the LED1, 2 (display data)	5		Heating thermo-ON	Refrigerant pull back/no CN3D1-2 input								LEV opening correction depends on Pd	Pd abnormality control (heating)	Frequency restrain of receipt voltage change	4-way valve disconnection abnormality			tent	Hz control by pressure limitation	Hz control by discharge temperature limitation	Hz control by bypass valve	Control mat restrains abnormal rise of Heat sink over heat prevention control	Secondary current control	Input current control	Max.Hz correction control due to receipt voltage change
Display on the LEI	4		Cooling thermo-OFF	DEFROST/NO CN3D1-3 input								Min.Sj correction depends on Shd	Discharge temp. (heating) backup control		Frozen protection			Content	Hz o	HZ C	Hz c	Con	Sec	ndul	Max
	3		Cooling thermo-ON	Abnormal/normal CN3S1-2 input								Min.Sj correction depends on Td		Input current control				:) control				control		9	ideaso proveinori
	2		Fan	Compressor ON/OFF Heating/Cooling CN3N1-3 input CN3N1-2 input		×10)		×10)				SHd decrease prevention	Compressor temperature control	Secondary current control	HIC abnormality			State of compressor frequency(Hz) cont	ssure control	Compressor temperature control	SV control	2	rrent control	control	Hz restrain of receipt voltage change
	1	0-255	STOP	Compressor ON/OFF CN3N1-3 input	0–255 (%)	0000–9999 (unit: x10)	0–999.9 (Arms)	0000–9999 (unit:	0–255	0–255	(V) 6.666-0	Td over heat prevention	Condensing temperature limit control	Heat sink over heat prevention control	63LS abnormality	0–999.9[Arms]	(4°) 6.999.9 (°F)	State of comp	Discharge pressure contro	Compressor t	SV control	Abnormal rise	Secondary current control	Input current control	Hz restrain of
Display mode		Capacity code (No. 1 indoor unit) Capacity code (No. 3 indoor unit) Capacity code (No. 3 indoor unit) Capacity code (No. 4 indoor unit) Capacity code (No. 5 indoor unit)	IC1 operation mode IC2 operation mode IC3 operation mode IC4 operation mode IC5 operation mode	OC operation mode External connection status	Communication demand capacity	Number of compressor ON/OFF	Compressor operating current Input current of outdoor unit	Thermo-ON operating time 0000–9999 (unit: x10)	Total capacity of themo-ON	Number of indoor units	DC bus voltage	State of LEV control	State of compressor frequency control 1	State of compressor frequency control 2	Protection input	The second current value when microprocessor of POWER BOARD abnormality is detected	Heatsink temperature when microprocessor of POWER BOARDabnormality is detected								
SW1 setting	12345678	01011000 (11011000 (00111000 (10111000 (11111000 00000100 10000100 01000100	00100100	01100100	11100100	00010100	01010100 T	11010100	00110100	10110100	01110100	11110100	00001100	10001100	01001100	11001100								
2		26 27 28 29 30	31 33 34 35 35	36	38	39	40	42	43	44	45	46	47	48	49	20	51								

Notes				Display of opening pulse of	outdoor LEV				Display of data from sensor	and thermistor		Display of actual operating frequency	Display of target frequency	Display of number of outdoor fan control steps (target)		Display of opening pulse of	indoor LEV			Display detected data of	outdoor unit sensors and thermistors				Display detected data of	indoor unit thermistor	
	8																										
	2																										
ta)	9																										
Display on the LED1, 2 (display data)	2																										
Display on the LE	4																									0.)	
	8																									i, it is displayed as 0.)	
	2							IG)	(S)										(B)							(When indoor unit is not connected, it is	
	~			(00000000000000000000000000000000000000	(period) (purse)			-99.9-999.9 (PSIG)	-99.9-999.9 (PSIG)	-99.9-999.9 (°F)	-99.9-999.9 (°F)	0–255 (Hz)	0–255 (Hz)	0–15					-99.9-999.9 (PSIG)		(4°) 6.999.9 (°F)				(±°) 6 666-6 66-	(When indoor un	
Display mode		Outdoor LEV-A opening pulse	Outdoor LEV-A opening pulse abnormality delay	Outdoor LEV-A opening pulse abnormality	Outdoor LEV-B opening pulse	Outdoor LEV-B opening pulse abnormality delay	Outdoor LEV-B opening pulse abnormality	63LS (Low pressure)	11011100 63LS abnormality delay 00111100 63 LS abnormality	TH2 (Hic pipe)	TH2(Hic) abnormality delay	Operational frequency	Target frequency	Outdoor fan control step number	IC1 LEV Opening pulse	IC2 LEV Opening pulse	00010010 IC4 LEV Opening pulse	10010010 IC5 LEV Opening pulse	High pressure sensor (Pd)	TH6(Suction pipe) (ET) data	TH7(Ambient) data	TH3(Outdoor liquid pipe) data	TH8(Heat sink) data	IC1 TH23 (Gas)	IC2 TH23 (Gas)	IC3 TH23 (Gas)	IC4 TH23 (Gas)
SW1	_	52 00101100	53 10101100	54 01101100	55 11101100	56 00011100	57 10011100	58 01011100	59 11011100 6	10111100	62 01111100	⊢	65 10000010	66 01000010	10100010	70 01100010 7	00010010	73 10010010	74 01010010	_	77 10110010	-	80 00001010	\rightarrow		-	84 00101010

4 5 6 7 8
Display of outdoor subcool (SC) data
Display of target subcool step data
-99.9–999.9 (°C) during heating: subcool (SC)/during cooling: superheat (SH) (Fixed to "0" during cooling operation)
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Display of outdoor discharge superheat (SHd) data
Display of all control target data
1 unit check No.12 unit check
No.12 unit mode COOL/DRY: light on light blinking FAN/STOP: light off
No.12 unit Thermo-ON: light on operation Thermo-OFF: light off
Cooling Heating Heating Display of indoor unit thermo-OFF thermo-OFF
Display of all control target data
Display of opening pulse of indoor LEV at time of abnormality delay

2	SW1 setting	Display mode				Displa	ay on the LED	Display on the LED1, 2 (display data)				SetON
2	_	_	_	2	8		4	5	9	7	8	
128	00000001	Actual frequency of abnormality delay	0–255 (Hz)									Display of actual frequency at time of abnormality delay
129	10110001		0–15									Display of fan step number at time of abnormality delay
131	11000001											
132	00100001	IC2 LEV opening pulse abnormality delay	,									
133	10100001	IC3 LEV opening pulse abnormality delay	0-2000 (pulse)									Delay of opening pulse of indoor LEV at time of abnormality delay
134	01100001											مقاتما ومام
135	11100001	IC5 LEV opening pulse abnormality delay										
136	00010001	High pressure sensor data at time of abnormality delay kgf/cm2	-99.9-999.9 (PSIG)	lG)								
137	10010001	TH4 (Compressor) sensor data at time of abnormality delay °C										
138	01010001	TH6 (Suction pipe) sensor data at time of abnormality delay °C	-99.9-999.9 (°F)									
139	11010001		_									
140	00110001											
141	10110001	8										Display of data from High
142	01110001		,									pressure sensor, all thermistors, and SC/SH at
143	11110001	IC2 SC/SH at time of abnormality delay °C										unie or abnormality delay
144	00001001											
145	10001001		-99.9-999.9(°C)	(0)								
146	01001001	IC5 SC/SH at time of abnormality delay °C	During realing; superheat (SH) (Fixed to	uperheat (SH) (ing cooling	"0" during cooling operation)					
147	11001001											
148	00100001	_										
149	10101001		,									
150	01101001	IC12 SC/SH at time of abnormality delay °C										

Display on the LED1, 2 (display data 2 3 4 5	Display mode 1 2 3 4 5 History of voltage error (U9/4220) - PAM error Converter Fault signal error signal error	Display on the LED1, 2 (display data 3 4 5	Display on the LED1, 2 (display data 3 4 5 PAM error Converter Fault synchronization signal error	Display on the LED1, 2 (display data 3 4 5 error Converter Fault synchronization signal error	Display on the LED1, 2 (display data) 4 5 Power Converter Fault signal error	5 Power Synchronization L1 open signal error) L1 open	6 phase error	6 7 7 L1 open phase error Under voltage error	8 Over voltage error	Notes
External connection status at time of abnormality delay External connection Status at time of Status a	CN3N 1-3 input CN3N 1-2 input CN3S 1-2 input CN3D 1-3 input CN3N 1-3 input CN3N 1-2 input CN3S 1-2 input CN3D 1-3 input	CN3N 1-3 input CN3N 1-2 input CN3S 1-2 input CN3D 1-3 input CN3N 1-3 input CN3N 1-2 input CN3S 1-2 input CN3D 1-3 input	CN3N 1-2 input CN3S 1-2 input CN3D 1-3 input CN3N 1-2 input CN3S 1-2 input CN3D 1-3 input	S 1-2 input CN3D 1-3 input S 1-2 input CN3D 1-3 input		CN3D 1-2 input					
00000011 Actual frequency of abnormality 0–255 (Hz)	Actual frequency of abnormality	0–255 (Hz)									Display of actual frequency at time of abnormality
10000011 Fan step number 0-15 at time of abnormality	Fan step number at time of abnormality										Display of fan step number at time of abnormality
11000011 IC1 LEV opening pulse 00100011 IC2 LEV opening pulse at time of abnormality at time of abnormality											
10100011 IC3 LEV opening pulse 0-2000 (pulse)		0-2000 (pulse)									Display of opening pulse of indoor LEV at time of abnormality
01100011 IC4 LEV opening pulse trume of abnormality											aprioring in
11100011 IC5 LEV opening pulse at time of abnormality	- 1										
00010011 High pressure sensor -99.9-999.9 (PSIG) abnormality	High pressure sensor data at time of abnormality		31G)								
10010011 sensor data at time of abnormality											Display of data from
TH6 (Succion pipe) seneor data at fime of abnormality — oo o ooo o /*E\)	TH6 (Suction pipe) sensor data at time of abnormality										High pressure sensor, all thermistors, and SC/SH at the mistors, and SC/SH at the mistory of physical structures.
TH3 (Outdoor liquid pipe) sensor data at time of abnormality	TH3 (Outdoor liquid pipe) sensor data at time of abnormality										time of abnormality.
00110011 sensor data at time of abnormality											
10110011 OC SC (cooling) at time of abnormality time of	OC SC (cooling) at time of abnormality	,									
01110011 IC1 SC/SH at time of abnormality											
)) ()()								Display of indoor SC/SH
00001011 IC3 SC/SH at time of During cooling; superheat (SH) (Fixed to "0" during cooling operation)	IC3 SC/SH at time of During cooling; superheat (SH) (Fixed to abnormality	During cooling; superheat (SH) (Fixed to			ooling operation)						data at time of abnormality
10001011 IC4 SC/SH at time of abnormality											
01001011 IC5 SC/SH at time of abnormality											
11001011 IC6 Capacity code 00101011 IC7 Capacity code 00101011 IC7 Capacity code	IC6 Capacity code										Display of indoor unit capacity code
10101011 IC8 Capacity code	IC8 Capacity code										The No.1 unit will start from the M-NET address with the lowest number
IC6 operation mode CTO Cooling Cooling	IC8 operation mode	Cooling	Cooling	Cooling		Heating		Heating			Display of indoor unit
110 10 10 10 10 10 10 1	ICA operation mode ICA operation	thermo-OFF thermo-OFF	thermo-OFF thermo-OFF	ON thermo-OFF		thermo-Of		thermo-OFF			operation mode
			-	-	-						

SW1	Display mode				Display on the LEI	Display on the LED1, 2 (display data)				Notes
_		-	2	ဧ	4	2	9	7	80	
217 10011011 218 01011001 219 11011001		0-2000 (pulse)								Display of opening pulse of indoor LEV
220 00111011 221 10111011 222 01111011 224 00000111 225 10000111 226 01000111 227 11000111 228 00100111	Co LEV opening puise Co TH23 (Gas) Co TH23 (Gas) Co TH23 (Gas) Co TH22 (iquid) Co TH22 (iquid) Co TH21 (intake) -99.9-999.9 (°F)								Display detected data of indoor unit themistor	
229 10100111 230 01100111 231 11100111	I IC6 SC/SH IC7 SC/SH IC8 SC/SH	−99.9–999.9 (°C) -during heating: subcool (SC)/during cooli	ocool (SC)/during		eat (SH) (Fixed to "	ng: superheat (SH) (Fixed to "0" during cooling operation)	peration)			Display of indoor SC/SH data
232 00010111 233 10010111 234 01010111	Target indoor SC/SH (IC6) Target indoor SC/SH (IC7) Target indoor SC/SH (IC7)	SCm/SHm (0.0–20.0) (°C)	0.0) (°C)							Display of all control target data
236 11010111 236 00110111 237 10110111	ICZ LEV opening pulse abnormality delay ICZ LEV opening pulse abnormality delay ICB LEV opening pulse abnormality delay	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormaliy delay
239 011101111 239 111101111 240 00001111			bcool (SC) perheat (SH) (Fi	xegd to "0" during	–99.9–999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixegd to "0" during cooling operation)					Display of indoor SC/SH data at time of abnormality delay
241 10001111 242 01001111 243 11001111	IC6 LEV opening pulse at time of abnormality IC7EV opening pulse at time of abnormality IC8 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality
244 00101111 245 10101111 246 01101111		–99.9–999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to	bcool (SC) perheat (SH) (Fi	xed to "0" during o	"0" during cooling operation)					Display of indoor SC/SH data at time of abnormality delay
250 01011111 251 110111111 252 00111111 253 10111111	IC9 LEV opening pulse IC10 LEV opening pulse IC11 LEV opening pulse IC12 LEV opening pulse	-0-2000 (pulse)								Display of opening pulse of indoor LEV

9

ELECTRICAL WIRING

This chapter provides an introduction to electrical wiring for MULTI-S series, together with notes concerning power wiring, wiring for control (transmission wires and remote controller wires), and the frequency converter.

9-1. OVERVIEW OF POWER WIRING

- (1) Use a separate power supply for the outdoor unit and indoor unit.
- (2) Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
- (3) The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops. Make sure the power-supply voltage does not drop more than 10 %.
- (4) Specific wiring requirements should adhere to the wiring regulations of the region.
- (5) Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.
- (6) Install an earth line longer than power cables.

⚠ Warning:

- Be sure to use specified wires to connect so that no external force is imparted to terminal connections. If connections are not fixed firmly, it may cause heating or fire.
- Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current


Caution:

- · Some installation site may require attachment of an earth leakage breaker. If no earth leakage breaker is installed, it may cause an electric shock
- · Do not use anything other than breaker and fuse with correct capacity. Using fuse and wire or copper wire with too large capacity may cause a malfunction of unit or fire.
- Be sure to install N-Line. Without N-Line, it could cause damage to the unit.

9-2. WIRING OF MAIN POWER SUPPLY AND EQUIPMENT CAPACITY

9-2-1. Wiring diagram for main power supply


■ Schematic Drawing of Wiring: When NOT using a Branch Box (example)




supplied from an outdoor unit, so provide it with power separately

- A-Control Indoor Unit CITY MULTI series Indoor unit
- Pull Box

■ Schematic Drawing of Wiring: When using Branch Boxes (example) <When power is supplied to branch box from the outdoor unit>



<When power is supplied to outdoor unit and branch box separately>



9-2-2. Cross section area of Wire for Main Power and ON/OFF capacities

Thickness of Wire for Main Power Supply and On/Off Capacities

<When power is supplied separately>

	or to outphilor coharact	,							
Model		Power Supply	Minimum Wi (mm² [Main Cable*2	re Thickness AWG]) Ground	Conduit size	Breaker for Wiring*1	Breaker for Current Leakage(If you use)		Maximum rating of over current protector device
	NTXMSM36/48A1*2**		5.3 [AWG10]	5.3 [AWG10]	1*3	30 A	30 A, 30 mA 0.1 second or less	36 A	64 A
Outdoor Unit	NTXMSH36/42/48A1*2**	1 '	8.4 [AWG8]	8.4 [AWG8]	1*3	40 A	40 A, 30 mA 0.1 second or less	45 A	80 A
	NTXMSM60A182**	60 Hz	8.4 [AWG8]	8.4 [AWG8]	1*3	40 A	40 A, 30 mA 0.1 second or less	45 A	80 A
E	Branch Box				Refe	r to installation	on manual of Branch B	ox.	

<When power is supplied from the outdoor unit>

		Power Supply	(mm² [AWGII	Conduit	Breaker for Wiring*1			Maximum rating of over
Model			Main Cable*2	Ground	SIZO	vviring '	Leakage(If you use)	ampacity	current protector device
	NTXMSM36/48A1*2**		8.4 [AWG8]	8.4 [AWG8]	1*³	40 A	40 A, 30 mA 0.1 second or less	42 A	70 A
Outdoor Unit	NTXMSH36/42/48A1*2**	,	13.3 [AWG6]	13.3 [AWG6]	1	45 A	45 A, 30 mA 0.1 second or less	51 A	86 A
	NTXMSM60A182**	60 Hz	13.3 [AWG6]	13.3 [AWG6]	1	50 A	50 A, 30 mA 0.1 second or less	55 A	90 A
Е	Branch Box				Refe	er to installation	on manual of Branch B	OX.	

^{*1} Please follow applicable federal, state, or local codes to prevent potential leakage/electric shock. Or install a ground fault interrupt for the prevention of leakage and electric shock.

IMPORTANT

If a current leakage breaker is used, it should be compatible with higher harmonics as this unit is equipped with an inverter. The use of an inadequate breaker can cause the incorrect operation of inverter.

 $^{^{\}star}2$ Use copper supply wires. Use the electric wires over the rating voltage 300 V.

^{*3} Although the conduit size is larger than the size specified for the wire thickness according to UL standards, use a conduit size of 1 inch.

Total operating current	Minimum w	ire thickness	(mm²/AWG)	Ground-fault interrupter *1	Local sv	vitch (A)	Breaker for wiring
of the indoor unit	Main Cable	Branch	Ground	(If you use)	Capacity	Fuse	(NFB)
F0 = 15 A or less *2	2.1/14	2.1/14	2.1/14	15 A current sensitivity *3	15	15	15
F0 = 20 A or less *2	3.3/12	3.3/12	3.3/12	20 A current sensitivity *3	20	20	20
F0 = 30 A or less *2	5.3/10	5.3/10	5.3/10	30 A current sensitivity *3	30	30	30

Apply to IEC61000-3-3 about max. permissive system impedance.

F2 = {V1 × (Quantity of Type1)/C} + {V1 × (Quantity of Type2)/C} + {V1 × (Quantity of Type3)/C} + {V1 × (Quantity of Type4)/C} + ... + {V1 × (Quantity of Type4)/C}

	Indoor unit	V1	V2
Type 1	*PEADA0**1AA90*	30.1	2.2
Type 2	*PEADA0**1AA80*, N*XAMT**A112A*	26.9	
Type 3	*PLA0A0**1EA70*, N*XDKS**A112A*	19.8	
Type 4	N*XCKS**A112**, *PLA0A0**1EA80*	17.1	
Type 5	N*XUKS**A112B*	9.9	2.4
Type 6	N*XFKS**A112A*, N*XWST**A112A*, N*XWPH**B112A*, N*XWST**B112A*, NTXUKS06A112A*, N*XVMFZ**A122A*	7.4	
Type 7	N*XWPH**A112A*	6.8	
Type 8	Branch box	5.1	3.0
Type 9	TPEFYP***MA143*, TPVFYP***AM14**	38.0	1.6
Type 10	TPKFYP***KM14**, TPEFYP***MS14**, TPCFYP***KM14**, TPLFYP***EM14**, TPLFYP***FM14**, TPKFYP***EM14**	19.8	2.4
Type 11	TPEFYP***MH14**, TPFFYP***CS14**, TPFFYP***RE14**	0.0	0.0
Type 12	TPEFYP***MH140* (connected to NTXMS*60A182** only)	13.8	4.8
Type 13	TPEFYP***MA144*, TPEFY***MA145*	18.6	3.0
Type 14	TPMFY***BM14*G	9.9	2.4

C: Multiple of tripping current at tripping time 0.01s

Please pick up "C" from the tripping characteristic of the breaker.

• Condition TPEFYP***MS14** × 4 + TPEFYP***MA143* × 1, C = 8 (refer to right sample chart)

→ 16 A breaker (Tripping current = 8 × 16 A at 0.01 s)

G1 = V2 × (Quantity of Type1) + V2 × (Quantity of Type2) + V2 × (Quantity of Type3) +...

+ V2 × (Quantity of Type14) + V3 × (Wire length [km])

G1	Current sensitivity
30 or less	30 mA 0.1 second or less
100 or less	100 mA 0.1 second or less

Wire thickness (mm ² /AWG)	V3
2.1/14	48
3.3/12	56
5.3/10	66


- 1. Use a separate power supply for the outdoor unit and indoor unit.
- 2. Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water etc.) when proceeding with the wiring and connections.
- 3. The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops. Make sure the power-supply voltage does not drop more than 10%.
- 4. Specific wiring requirements should adhere to the wiring regulations of the region.
- 5. Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.
- 6. Install an earth line longer than power cables.

9-3. DESIGN FOR CONTROL WIRING

Please note that the types and numbers of control wires needed by MULTI-S series depend on the remote controllers and whether they are linked with the system or not.

9-3-1. Selection number of control wires

		M-NET remote controller
	Use	Remote controller used in system control operations Group operation involving different refrigerant systems Linked operation with upper control system
Remote	e controller → indoor unit	
Wires connecting → indoor units		O como usino (o con molos)
Fransmission wires	Wires connecting → indoor units with outdoor unit	2-core wire (non-polar)
Trans wire	Wires connecting → outdoor units	



The Ground-fault interrupter should support inverter circuit.

The Ground-fault interrupter should combine using of local switch or wiring breaker.

^{*2} Please take the larger of F1 or F2 as the value for F0.

F1 = Total operating maximum current of the indoor units × 1.2

<Example of "F2" calculation>

^{= 14.65}

^{*3} Current sensitivity is calculated using the following formula.

9-4. WIRING TRANSMISSION CABLES

9-4-1. Types of control cables

1. Wiring transmission cables

Types of transmission cables	Shielded wire CVVS, CPEVS, or MVVS
Cable diameter	More than 13.5 ft² [1.25 mm²]
Maximum wiring length	Within 656 ft [200 m]

2. M-NET Remote control cables

Types of remote control cable	Shielded wire (2-core) CVVS, CPEVS, or MVVS
Cable diameter	AWG 20 to AWG 16 [0.5 to 1.25 mm ²]
Remarks	When 10 m is exceeded, use a cable with the same specifications as transmission line wiring.

3. MA Remote control cables

Type of remote control cable	Sheathed 2-core cable (unshielded) CVV
Cable diameter	AWG 22 to AWG 16 [0.3 to 1.25 mm ²] AWG 18 to AWG 16 [0.75 to 1.25 mm ²]*
Remarks	Within 656 ft [200 m]

^{*} Connected with simple remote controller.

9-4-2. Wiring examples

· Controller name, symbol and allowable number of controllers.

Name		Symbol	Allowable number of controllers	
Outdoor unit controller		ОС	_	
Indoor unit controller	CITY MULTI series	M-IC	NTXMS*36A142**	Refer to 2-2. SYSTEM CONSTRUCTION
			NTXMS*42A152**	
			NTXMS*48A182**	
			NTXMS*60A182**	
	N*X, T(A)P*A series	A-IC	NTXMS*36A142**	Refer to 2-3. SYSTEM CONSTRUCTIONN (BRANCH BOX SYSTEM)
			NTXMS*42A152**	
			NTXMS*48A182**	
			NTXMS*60A182**	
Branch box		ВС	_	0 to 2 units per 1 OC ⁻¹
Remote controller		RC	M-NET RC*2	Maximum of 12 controllers for 1 OC ^{*1}
			MA-RC	Maximum of 2 per group

Note:


^{*1} The number of connectable units may be limited by some conditions such as an indoor unit's capacity or each unit's equivalent power consumption.

^{*2} Don't use the Lossnay controller (PZ-61DR-E, PZ-43SMF-E, PZ-52SF-E, PZ-60DR-E).


9-5. SYSTEM SWITCH SETTING

In order to identify the destinations of signals to the outdoor units, indoor units, and remote controller of MULTI-S series, each microprocessor must be assigned an identification number (address). The addresses of outdoor units, indoor units, and remote controller must be set using their settings switches. Please consult the installation manual that comes with each unit for detailed information on setting procedures.

9-6. EXAMPLE EXTERNAL WIRING DIAGRAM FOR A BASIC SYSTEM



<When power is supplied to branch box from the outdoor unit>



A-control

MA RC

A-control | A-control | indoor unit |

MA RC

A-control

indoor unit

MA

A-control indoor unit

MA RC

9-7. METHOD FOR OBTAINING ELECTRICAL CHARACTERISTICS WHEN A CAPACITY AGREEMENT IS TO BE SIGNED WITH AN ELECTRIC POWER COMPANY

The electrical characteristics of connected indoor unit system for air conditioning systems, including CITY MULTI series, depend on the arrangement of the indoor and outdoor units.

First read the data on the selected indoor and outdoor units and then use the following formulas to calculate the electrical characteristics before applying for a capacity agreement with the local electric power company.

9-7-1. Obtaining the electrical characteristics of CITY MULTI series system

(1) Procedure for obtaining total power consumption

	Page numbers in this technical manual	Power consumption
Total power consumption of each indoor unit	See the technical manual of each indoor unit.	1
Power consumption of outdoor unit*	Standard capacity diagram— Refer to 4-4.	2
Total power consumption of system	See the technical manual of each indoor unit.	①+② <kw></kw>

^{*}The power consumption of the outdoor unit will vary depending on the total capacity of the selected indoor units.

(2) Method of obtaining total current

	Page numbers in this technical manual	Subtotal
Total current through each indoor unit	See the technical manual of each indoor unit.	1
Current through outdoor unit*	Standard capacity diagram— Refer to 4-4.	2
Total current through system	See the technical manual of each indoor unit.	①+② <a>

The current through the outdoor unit will vary depending on the total capacity of the selected indoor units.

(3) Method of obtaining system power factor

Use the following formula and the total power and current obtained in parts ① and ② on the above tables to calculate the system power factor.

9-7-2. Applying to an electric power company for power and total current

Calculations should be performed separately for heating and cooling employing the same methods; use the largest resulting value in your application to the electric power company.

10


REFRIGERANT PIPING TASKS


10-1. REFRIGERANT PIPING SYSTEM


10-1-1. NTXMSM36A142BA NTXMSH42A152BA NTXMSH36A142BA

NTXMSM48A182BA


NTXMSH48A182BA







10-1-2. NTXMSM60A182BA



The total capacity of connected indoor unit is as follows:

132 ft × 0.29 oz + 147 ft × 0.75 oz + 88 oz = 237 oz $\left[40 \times \frac{27.0}{1000} + 45 \times \frac{70.0}{1000} + 2.5 = 6.8 \text{ kg (rounded up)}\right]$

24 + 15 + 08 + 06 = 53

<Calculation example> Additional refrigerant charge


the charge to 13.4 lb [6.1 kg].)


(For example, if the calculated charge is 13.2 lb [6.01 kg], round up


The amount of additional refrigerant for NTXMSM60 which is

combination of extended pipes must not be over 28.4 lb[12.9kg]

calculated from the total capacity of indoor units and the







(2) Sections From Branch box Piping to Indoor Unit (a to h) Select the size from the table to the

right.

Model	Piping Diameter (inch[mm])	
NTXMSM36A142BA	Liquid Line	3/8 [ø9.52]
NTXMSM48A182BA	-	= =
NTXMSH36A142BA	Caa Lina	5/8 [ø15.88]
NTXMSH42A152BA	Gas Line	
NTXMSH48A182BA		
NTXMSM60A182BA	Liquid Line	3/8 [ø9.52]
	Gas Line	3/4 [ø19.05]

(2) Refrigerant Piping Diameter In Section From Branch box to Indoor Unit (Indoor Unit Piping Diameter)

Indoor unit series	Model number	A Liquid pipe (inch[mm])	B Gas pipe (inch[mm])
N*X series	012 or lower	1/4 [a6 25]	3/8 [ø9.52]
	015, 018	1/4 [ø6.35]	1/2 [ø12.7]
	24 or higher	3/8 [ø9.52]	5/8 [ø15.88]
T(A)P*A series	018 or lower	1/4 [ø6.35]	1/2 [ø12.7]
	24 or higher	3/8 [ø9.52]	5/8 [ø15.88]

■ Additional refrigerant charge

Refer to the same section in the previous page.

10-2. PRECAUTIONS AGAINST REFRIGERANT LEAKAGE


10-2-1. Introduction

R410A refrigerant of this air conditioner is non-toxic and non-flammable but leaking of large amount from an indoor unit into the room where the unit is installed may be deleterious. To prevent possible injury, the rooms should be large enough to keep the R410A concentration specified by ISO 5149-1 as follows.

Maximum concentration
Maximum refrigerant concentration of R410A of a room is
0.44kg/m³ accordance with ISO 5149-1.
To facilitate calculation, the maximum concentration is
expressed in units of kg/m³ [lbs/ft³] (kg [lbs] of R410A per m³ [ft³])

[Maximum concentration of R410A: 0.027 lbs/ft³ [0.44 kg/m³]

(ISO 5149-1)



10-2-2. Confirming procedure of R410A concentration

Follow (1) to (3) to confirm the R410A concentration and take appropriate treatment, if necessary.

(1) Calculate total refrigerant amount by each refrigerant system. Total refrigerant amount is precharged refrigerant at ex-factory plus additional charged amount at field installation.


Note:


When the air conditioning system consists of several independent refrigerant system, figure out the total refrigerant amount by each independent refrigerant system.

(2) Calculate room volumes (m) and find the room with the smallest volume

The part with _____ represents the room with the smallest volume.

(a) Situation in which there are no partitions






ings above and blow

least 0.15% of the floor

Opening

Wall

(c) If the smallest room has mechanical ventilation apparatus that is linked to a household gas detection and alarm device, the calculations should be performed for the second smallest room.



(3) Use the results of calculations (1) and (2) to calculate the refrigerant concentration:

The smallest room in which an indoor unit has been installed (ft³ [m³])

Maximum concentration of R410A:0.027 lbs/ft³ [0.44kg/m³]

If the calculation results do not exceed the maximum concentration, perform the same calculations for the larger second and third room, etc., until it has been determined that nowhere the maximum concentration will be exceeded.

DISASSEMBLY PROCEDURE

NTXMSM36A142BA NTXMSM48A182BA


>: Indicates the visible parts in the photos/figures.

Note: Turn OFF the power supply before disassembly.

OPERATING PROCEDURE

1. Removing the service panel and top panel

- Remove 3 service panel fixing screws (5 x 12) and slide the hook on the right downward to remove the service panel.
- (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it.



2. Removing the fan motor (MF1, MF2)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)
- (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2)
- (5) Disconnect the connectors, CNF1 and CNF2 on multi controller circuit board in electrical parts box.
- (6) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3)

Note: Tighten the propeller fan with a torque of 5.7 \pm 0.3 N·m [4.2 \pm 0.2 ft = lbs]

3. Removing the electrical parts box


- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connecting wire from terminal block.
- (4) Remove all the following connectors from multi controller circuit board:
- <Diagram symbol in the connector housing>
- Fan motor (CNF1, CNF2)
- Thermistor <HIC pipe> (TH2)
- Thermistor < Outdoor liquid pipe> (TH3)
- Thermistor < Compressor> (TH4)
- Thermistor <Suction pipe/Ambient, Outdoor> (TH7/6)
- High pressure switch (63H)
- High pressure sensor (63HS)
- Low pressure sensor (63LS)
- 4-way valve (21S4)
- Bypass valve (SV1)
- Linear expansion valve (LEV-A, LEV-B)


Pull out the disconnected wire from the electrical parts box.


(5) Remove the terminal cover and disconnect the compressor lead wire from the comp. terminal. (See Figure 1)

Note: The terminal cover can be easily removed by using a blade of flathead screwdriver.









From the previous page.

OPERATING PROCEDURE

(6) Remove 2 electrical parts box fixing screws (4 × 10) and detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.

PHOTOS/FIGURES

Photo 5

Electrical parts box

Hooks


Electrical parts box fixing screws


4. Removing the thermistor <Suction pipe> (TH6)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connector, TH7/6 (red), on the multi controller circuit board in the electrical parts box.
- (4) Loosen the wire clamps on top of the electrical parts box.
- (5) Pull out the thermistor <Suction pipe> (TH6) from the sensor holder. (See Photo 7)

Note: When replacing thermistor <Suction pipe> (TH6), replace it together with thermistor <Ambient> (TH7) since they are combined together.

Refer to procedure No.5 below to remove thermistor <Ambient> (TH7).





5. Removing the thermistor <Ambient> (TH7)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connector TH7/6 (red) on the multi controller circuit board in the electrical parts box.
- (4) Loosen the wire clamps on top of the electrical parts box. (See Photo 6)
- (5) Pull out the thermistor <Ambient> (TH7) from the sensor

Note: When replacing thermistor <Ambient> (TH7), replace it together with thermistor <Suction pipe> (TH6), since they are combined together. Refer to procedure No.4 above to remove thermistor <Suction pipe> (TH6).

Photo 8

Lead wire of thermistor <Ambient> (TH7)

Sensor holder

- 6. Removing the thermistor <Outdoor liquid pipe> (TH3) and Photo 9 thermistor <Compressor> (TH4), thermistor <HIC pipe> (TH2)
 - (1) Remove the service panel. (See Photo 1)
 - Disconnect the connectors, TH3 (white) and TH4 (white), TH2 (black) on the multi controller circuit board in the electrical parts box.
 - (3) Pull out the thermistor < Outdoor liquid pipe> (TH3) and thermistor < Compressor> (TH4) from the sensor holder. (See Photo 7 and 9)

PHOTOS/FIGURES



Thermistor <Outdoor liquid pipe> (TH3)

7. Removing the 4-way valve coil (21S4)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove 4-way valve coil fixing screw (M5 × 7).
- (3) Remove the 4-way valve coil by sliding the coil to the
- (4) Disconnect the connector 21S4 (green) on the multi controller circuit board in the electrical parts box.

8. Removing the 4-way valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box (See Photo 5)
- (4) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5×16) , then remove the valve bed. (See Photo 4 and 7)
- (5) Remove 2 cover panel fixing screws (5 x 12), then slide the cover panel (front) upward to remove it. (The cover panel (front) is fixed to the cover panel (rear) with a hook on the rear side. (See Photo 4)
- (6) Remove the cover panel (rear) fixing screws (2 for right side and 2 for rear/ 5 x 12), then slide the cover panel (rear) upward to remove it. (The cover panel (rear) is fixed to the side panel (R) with
- (7) Remove 3 side panel (R) fixing screws (5 × 12) in the rear of the unit, then slide the side panel (R) upward to remove it. (The side panel (R) is fixed to the side plate with hooks on the rear side.)
- (8) Remove the 4-way valve coil. (See Photo 10)
- (9) Recover refrigerant.
- (10) Remove the welded part of 4-way valve.

- 1. Recover refrigerant without spreading it in the air.
- 2. The welded part can be removed easily by removing the side panel (R).
- 3. When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (248°F [120°C] or more), then braze the pipes so that the inside of pipes are not oxidized.

Photo 10



4-way valve coil fixing screw

9. Removing bypass valve coil (SV1) and bypass valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8 (5))
- (4) Remove the cover panel (rear). (Refer to procedure 8 (6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the bypass valve coil fixing screw (M4 × 6).
- (7) Remove the bypass valve coil by sliding the coil upward.
- (8) Disconnect the connector SV1 (gray) on the multi controller circuit board in the electrical parts box.
- (9) Remove the electrical parts box. (See Photo 5)
- (10) Recover refrigerant.
- (11) Remove the welded part of bypass valve.

Refer to the notes below.

10. Removing the high pressure switch (63H) and high pressure sensor (63HS)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8 (5))
- (4) Remove the cover panel (rear). (Refer to procedure 8 (6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Pull out the lead wire of high pressure switch and high pressure sensor.
- 7) Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of high pressure switch and high pressure sensor.

Refer to the notes below.

11. Removing the low pressure sensor (63LS)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8 (5))
- (4) Remove the cover panel (rear). (Refer to procedure 8 (6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Disconnect the connector 63LS (blue) on the multi controller circuit board in the electrical parts box.
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of low pressure sensor.

Refer to the notes below.

12. Removing linear expansion valve (LEV-A, LEV-B)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8 (5))
- (4) Remove the cover panel (rear). (Refer to procedure 8 (6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the linear expansion valve coil. (See Photo 11,12)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of linear expansion valve.

Refer to the notes on the right.

PHOTOS/FIGURES

Photo 11





Photo 12



Notes:


- 1. Recover refrigerant without spreading it in the air.
- 2. The welded part can be removed easily by removing the side panel (R).
- When installing the following parts, cover it with a wet cloth to prevent it from heating as the temperature below, then braze the pipes so that the inside of pipes are not oxidized;
- Bypass valve (procedure 9), 248°F [120°C] or more
- High pressure switch and high pressure sensor (procedure 10), 212°F [100°C] or more
- Low pressure sensor (procedure 11), 212°F [100°C] or more
- · LEV (procedure 12), 248°F [120°C] or more


13. Removing the compressor (MC)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove 2 front cover panel fixing screws (5 × 12) and remove the cover panel (front). (See Photo 4)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Remove the valve bed. (Refer to procedure 8 (4))
- (9) Remove 3 separator fixing screws (4 × 10) and remove the separator. (See Figure 2)
- (10) Remove the comp felt covering the compressor, and remove the thermistor <Compressor> (TH4), thermal protector (TRS), and the lead wires. (See Photo 7 and 13)
- (11) Recover refrigerant.
- (12) Remove the 3 compressor fixing nuts for motor using spanner or adjustable wrench.
- (13) Remove the welded pipe of compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES






14. Removing the accumulator

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8 (5))
- (4) Remove the cover panel (rear). (Refer to procedure 8 (6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the electrical parts box. (See Photo 5)
- (7) Remove the valve bed. (Refer to procedure 8 (4))
- (8) Recover refrigerant.
- (9) Remove 4 welded pipes of accumulator inlet and outlet.
- (10) Remove 2 accumulator leg fixing screws (4 × 10). (See Photo 15)

Note: Recover refrigerant without spreading it in the air.

Fusible plug Outlet Accumulator




OPERATING PROCEDURE PHOTOS/FIGURES 15. Removing the reactor (DCL) Figure 3 (1) Remove the service panel. (See Photo 1) Reactors (2) Remove the top panel. (See Photo 1) (3) Remove the electrical parts box (See photo 5) (4) Remove 6 screws (4 x 10) for reactors to remove the reactors. (See Figure 3) Screws for reactors 16. Changing the fusible plug Photo 16 See the following descriptions. • Be careful not to expose the fusible plug to the braze torch flame or transfer heat to it. (See Photo 16) • The temperature of the fusible plug must not become 140°F (60°C) or more while working. Protect the fusible plug with a wet cloth when necessary. (The fusible plug breaks at 158°F [70°C]). • Tighten the screw in 14 - 18 N·m* (11-13 lbf·ft) with 2 Fusible plug wrenches. *1 N·m ≈ 10 kgf·cm

17.Removing the thermal protector (TRS))

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the cover panel front. (See Photo 1)
- (3) Pull out the lead wire of high pressure switch and discon nect the connector, 63H (yellow) from the multi controller board in the electrical parts box. (See Photo 11)
- (4) Remove the comp felt covering the compressor. (See Photo 13)
- (5) Loosen the clamp or band for the lead wire of the electrical parts box and separator.
- (6) Pull out the thermal protector (TRS) from the holder. (See Photo 17)

PHOTOS/FIGURES

Photo 17



18. Removing the fuse holders


- (1) Remove the service panel. (See photo 1)
- (2) Remove the fuse covers. (See Figure 4)
- (3) Remove 2 screws (3 x 12) for fuse holders to remove the fuse holders.


(See Figure 4 and Photo 18)

Notes:

- 1. Bracket, circuit board and other parts can get deformed when inserting and removing the fuse cover.
- 2. Remove the fuse cover in the way that surrounding parts will not be affected.

Photo 18





NTXMSM60A182BA


→: Indicates the visible parts in the photos/figures.

Note: Turn OFF the power supply before disassembly.

OPERATING PROCEDURE

1. Removing the service panel and top panel

- Remove 3 service panel fixing screws (5 x 12) and slide the hook on the right downward to remove the service panel.
- (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it.



2. Removing the fan motor (MF1, MF2)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)
- (3) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2)
- (4) Disconnect the connectors, CNF1 and CNF2 on multi controller board in electrical parts box.
- (5) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3)

Note: Tighten the propeller fan with a torque of 5.7 \pm 0.3 N·m [4.2 \pm 0.2 ft = lbs]

Photo 2 Propeller Front panel Fan motor fixing screws Fan motor Fan motor fixing screws

3. Removing the electrical parts box

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- Disconnect the connecting wire from terminal block. (See Photo 5)
- (4) Remove all the following connectors from outdoor multi controller circuit board;
 - <Diagram symbol in the connector housing>
 - Fan motor (CNF1, CNF2)
 - Thermistor <HIC pipe> (TH2)
 - Thermistor < Outdoor liquid pipe> (TH3)
 - Thermistor < Compressor> (TH4)
 - Thermistor <Suction pipe/Ambient, Outdoor> (TH7/6)
 - High pressure switch (63H)
 - High pressure sensor (63HS)
 - Low pressure sensor (63LS)
 - 4-way valve (21S4)
 - Bypass valve (SV1)
 - Linear expansion valve (CNLVA/CNLVB)

Pull out the disconnected wire from the electrical parts box.

(5) Remove the terminal cover and disconnect the compressor lead wire.

Note: The terminal cover can be easily removed by using a blade of flathead screwdriver.







Photo 4




From the previous page.

OPERATING PROCEDURE

(6) Remove 2 electrical parts box fixing screws (4 × 10) then detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.

PHOTOS/FIGURES

Photo 5




4. Removing the thermistor <Suction pipe> (TH6)


- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connectors, TH7/6 (red), on the multi controller circuit board in the electrical parts box.
- Loosen the wire clamps on the back of electrical parts
- Pull out the thermistor <Suction pipe> (TH6) from the sensor holder. (See Photo 7)

Note: When replacing thermistor <Suction pipe> (TH6). replace it together with thermistor <Ambient> (TH7) since they are combined together.

Refer to procedure No.5 below to remove thermistor <Ambient> (TH7).

Photo 6






5. Removing the thermistor <Ambient> (TH7)

- (1) Remove the service panel. (See Photo 1)
- Remove the top panel. (See Photo 1)
- Disconnect the connector TH7/6 (red) on the multi controller circuit board in the electrical parts box.
- (4) Loosen the wire clamps on top of the electrical parts box. (See Photo 6.)
- Pull out the thermistor <Ambient> (TH7) from the sensor

Note: When replacing thermistor <Ambient> (TH7), replace it together with thermistor <Suction pipe> (TH6), since they are combined together. Refer to procedure No.4 above to remove thermistor <Suction pipe> (TH6).

Photo 7



Thermistor <Suction pipe> (TH6)


Thermistor <Hic pipe>

Thermistor <Compressor> (TH4)

Ball valve and stop valve fixing screws

Photo 8

Lead wire of thermistor <Ambient> (TH7)



Sensor holder

- Removing the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4), thermistor <HIC pipe> (TH2)
 - (1) Remove the service panel. (See Photo 1)
 - (2) Disconnect the connectors, TH3 (white) and TH4 (white), TH2 (black) on the multi controller circuit board in the electrical parts box.
 - (3) Pull out the thermistor <Outdoor liquid pipe> (TH3) and thermistor <Compressor> (TH4) from the sensor holder. (See Photo 9-1 and 9-2)

PHOTOS/FIGURES




Photo 9-2



Thermistor <Outdoor liquid pipe> (TH3)

7. Removing the 4-way valve coil (21S4)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove 4-way valve coil fixing screw (M5 × 7).
- (3) Remove the 4-way valve coil by sliding the coil to the right.
- (4) Disconnect the connector 21S4 (green) on the multi controller circuit board in the electrical parts box.


8. Removing the 4-way valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box (See Photo 5)
- (4) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16), then remove the valve bed. (See Photo 4 and 7)
- (5) Remove 2 cover panel fixing screws (5 x 12), then slide the cover panel (front) upward to remove it. (The cover panel (front) is fixed to the cover panel (rear) with a hook on the rear side. (See Photo 4)
- (6) Remove the cover panel (rear) fixing screws (2 for right side and 2 for rear/ 5 x 12), then slide the cover panel (rear) upward to remove it.
 (The cover panel (rear) is fixed to the side panel (R) with
 - (The cover panel (rear) is fixed to the side panel (R) with 2 screws.)
- (7) Remove 3 side panel (R) fixing screws (5 × 12) in the rear of the unit, then slide the side panel (R) upward to remove it. (The side panel (R) is fixed to the side plate with hooks on the rear side.)
- (8) Remove the 4-way valve coil. (See Photo 10)
- (9) Recover refrigerant.
- (10) Remove the welded part of 4-way valve.

Notes:

- 1. Recover refrigerant without spreading it in the air.
- The welded part can be removed easily by removing the side panel (R).
- When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (248°F [120°C] or more), then braze the pipes so that the inside of pipes are not oxidized.

Photo 10



fixing screw

156

9. Removing bypass valve coil (SV1) and bypass valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the bypass valve coil fixing screw (M4 × 6).
- (7) Remove the bypass valve coil by sliding the coil upward.
- (8) Disconnect the connector SV1 (gray) on the multi controller circuit board in the electrical parts box.
- (9) Remove the electrical parts box. (See Photo 5)
- (10) Recover refrigerant.
- (11) Remove the welded part of bypass valve.

Refer to the notes below.


10. Removing the high pressure switch (63H) and high pressure sensor (63HS)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Pull out the lead wire of high pressure switch and high pressure sensor.
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of high pressure switch and high pressure sensor.

Refer to the notes below.

PHOTOS/FIGURES

Photo 11



11. Removing the low pressure sensor (63LS)


- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Disconnect the connector 63LS (blue) on the multi controller circuit board in the electrical parts box.
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of low pressure sensor.

Refer to the notes below.

Photo 12

switch (63H)

Linear expansion valve



12. Removing linear expansion valve (LEV-A, LEV-B)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the linear expansion valve coil. (See Photo 12)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of linear expansion valve.


Notes:

- 1. Recover refrigerant without spreading it in the air.
- The welded part can be removed easily by removing the right side panel.
- When installing the following parts, cover it with a wet cloth to prevent it from heating as the temperature below, then braze the pipes so that the inside of pipes are not oxidized;
 - Bypass valve (procedure 9), 248°F [120°C] or more
 - High pressure switch and high pressure sensor (procedure 10), 212°F [100°C] or more
 - Low pressure sensor (procedure 11), 100°C or more
 - LEV (procedure 12), 248°F [120°C] or more

13. Removing the compressor (MC)


- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove 2 front cover panel fixing screws (5 × 12) and remove the front cover panel. (See Photo 4)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Remove the valve bed. (Refer to procedure 8 (4))
- (9) Remove 3 separator fixing screws (4 × 10) and remove the separator. (See Figure 2)
- (10) Remove the comp felt covering the compressor, and remove the thermistor <Compressor> (TH4), thermal protector (TRS), and the lead wires. (See Photo 7 and 14)
- (11) Recover refrigerant.
- (12) Remove the 3 compressor fixing nuts for motor using spanner or adjustable wrench.
- (13) Remove the welded pipe of compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.




PHOTOS/FIGURES

Figure 2







14. Removing the accumulator

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box. (See Photo 5)
- (4) Remove the valve bed. (See procedure 8 (4))
- (5) Remove the cover panel (front). (Refer to procedure 8(5))
- (6) Remove the cover panel (rear) (Refer to procedure 8(6))
- (7) Remove the side panel (R). (Refer to procedure 8 (7))
- (8) Recover refrigerant.
- (9) Remove 2 welded pipes of accumulator inlet and outlet.
- (10) Remove 2 accumulator leg fixing screws (4 × 10). (See Photo 16)

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES

Photo 15






Photo 16



15. Removing the reactor (DCL)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box (See photo 5)
- (4) Remove 6 screws (4 x 10) for reactors to remove the reactors. (See Figure 3)



16. Changing the fusible plug

See the following descriptions.


- Be careful not to expose the fusible plug to the braze torch flame or transfer heat to it. (See Photo 17)
- The temperature of the fusible plug must not become 140°F (60°C) or more while working. Protect the fusible plug with a wet cloth when necessary.

(The fusible plug breaks at 158°F [70°C]).

- Tighten the screw in 14 18 N·m* (11-13 lbf·ft) with 2 wrenches.
- *1 N·m ≈ 10 kgf·cm

PHOTOS/FIGURES


Photo 17



17. Removing the thermal protector (TRS))

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the cover panel front. (See Photo 1)
- (3) Pull out the lead wire of high pressure switch and disconnect the connector, 63H (yellow) from the multi controller board in the electrical parts box. (See Photo 11)
- (4) Remove the comp felt covering the compressor. (See Photo 13)
- (5) Loosen the clamp or band for the lead wire of the electrical parts box and separator.
- (6) Pull out the thermal protector (TRS) from the holder. (See Photo 18)

Photo 18



18. Removing the fuse holders

- (1) Remove the service panel. (See Photo 1)
- (2) Remove 2 screws (4 x 10) for cont base to remove the cont base. (See Figure 4)
- (3) Remove the fuse covers. (See Figure 5)
- (4) Remove screws (3 x 12) for fuse holders to remove the fuse holders. (See Figure 4 and Photo 19)

Notes:

- 1. Bracket, circuit board and other parts can get deformed when inserting and removing the fuse cover.
- Remove the fuse cover in the way that surrounding parts will not be affected.

Photo 19




Figure 4




Figure 5



fuse hold (3×12)

NTXMSH36A142BA

NTXMSH42A152BA

NTXMSH48A182BA

>: Indicates the visible parts in the photos/figures.

OPERATING PROCEDURE

1. Removing the service panel and top panel

- Remove 3 service panel fixing screws (5 x 12), then slide the hook on the right downward to remove the service panel.
- (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it.

PHOTOS/FIGURES Photo 1 Top panel fixing screws Top panel. Service panel fixing screw Slide Grille fixing screws Service panel Fan grille Grille fixing screws Service panel fixing screws

2. Removing the fan motor (MF1, MF2)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)
- (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2)
- (5) Disconnect the connectors, CNF1 and CNF2 on the multi controller circuit board in the electrical parts box.
- (6) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3)

Note: Tighten the propeller fan with a torque of $5.7 \pm 0.3 \text{ N} \cdot \text{m}$. [4.2 \pm 0.2 ft = lbs]


3. Removing the electrical parts box


- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connecting wire from terminal block.
- (4) Remove all of the following connectors from multi controller circuit board;
- <Diagram symbol in the connector housing>
- Fan motor (CNF1, CNF2)
- Thermistor <HIC pipe> (TH2)
- Thermistor < Outdoor liquid pipe> (TH3)
- Thermistor < Compressor> (TH4)
- Thermistor <Suction pipe/Ambient, Outdoor> (TH7/6)
- High pressure switch (63H)
- High pressure sensor (63HS)
- Low pressure sensor (63LS)
- 4-way valve (21S4)
- Bypass valve (SV1, SV2)
- · Linear expansion valve (LEV-A, LEV-B)
- Base heater (SS)


Pull out the disconnected wire from the electrical parts box.

(5) Remove the terminal cover and disconnect the compressor lead wire from the comp. terminal. (See Figure 1)

Note: The terminal cover can be easily removed by using a blade of flathead screwdriver.







Continue to the next page.

From the previous page.

OPERATING PROCEDURE

(6) Remove 2 electrical parts box fixing screws (4 × 10), then detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.

Photo 5 Electrical parts box Hooks Electrical parts box fixing screws

4. Removing the thermistor <Suction pipe> (TH6)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connector, TH7/6 (red), on the multi controller circuit board in the electrical parts box.
- (4) Loosen the wire clamps on the top of the electrical parts box. (See Photo 6)
- (5) Pull out the thermistor <Suction pipe> (TH6) from the sensor holder. (See Photo 7)

Note: When replacing thermistor <Suction pipe> (TH6), replace it together with thermistor <Ambient> (TH7) since they are combined together.

Refer to procedure No.5 below to remove thermistor <Ambient> (TH7).





Photo 7



5. Removing the thermistor <Ambient> (TH7)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connector TH7/6 (red) on the multi controller circuit board in the electrical parts box.
- (4) Loosen the wire clamps on top of the electrical parts box. (See Photo 6)
- (5) Pull out the thermistor <Ambient> (TH7) from the sensor

Note: When replacing thermistor <Ambient> (TH7), replace it together with thermistor <Suction pipe> (TH6), since they are combined together. Refer to procedure No.4 above to remove thermistor <Suction pipe> (TH6).

Photo 8 Lead wire of thermistor <Ambient> (TH7) Sensor holder

- 6. Removing the thermistor < Outdoor liquid pipe> (TH3) and Photo 9 thermistor <Compressor> (TH4), thermistor <HIC pipé> (TH2)
 - (1) Remove the service panel. (See Photo 1)
 - Disconnect the connectors, TH3 (white) and TH4 (white). TH2 (black) on the multi controller circuit board in the electrical parts box.
 - (3) Pull out the thermistor < Outdoor liquid pipe> (TH3) and thermistor < Compressor> (TH4) from the sensor holder. (See Photo 7 and 9)

PHOTOS/FIGURES



Thermistor <Outdoor liquid pipe> (TH3)

7. Removing the 4-way valve coil (21S4)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove 4-way valve coil fixing screw (M5 × 7).
- (3) Remove the 4-way valve coil by sliding the coil to the
- Disconnect the connector 21S4 (green) on the multi controller circuit board in the electrical parts box.

8. Removing the 4-way valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box (See Photo 5)
- (4) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16), then remove the valve bed. (See Photo 4 and 7)
- (5) Remove 2 cover panel fixing screws (5 x 12), then slide the cover panel (front) upward to remove it. (The cover panel (front) is fixed to the cover panel (rear) with a hook on the rear side. (See Photo 4)
- (6) Remove the cover panel (rear) fixing screws (2 for right side and 2 for rear/ 5 x 12), then slide the cover panel (rear) upward to remove it. (The cover panel (rear) is fixed to the side panel (R) with
- (7) Remove 3 side panel (R) fixing screws (5 × 12) in the rear of the unit, then slide the side panel (R) upward to remove it. (The side panel (R) is fixed to the side plate with hooks on the rear side.)
- (8) Remove the 4-way valve coil. (See Photo 10)
- (9) Recover refrigerant.
- (10) Remove the welded part of 4-way valve.

- 1. Recover refrigerant without spreading it in the air.
- 2. The welded part can be removed easily by removing the side panel (R).
- 3. When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (248°F [120°C] or more), then braze the pipes so that the inside of pipes are not oxidized.

Photo 10

4-way valve coil (21S4)

4-way valve



4-way valve coil fixing screw

9. Removing bypass valve coil (SV1, SV2) and bypass valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front), (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the bypass valve coil fixing screw (M4 × 6).
- Remove the bypass valve coil by sliding the coil upward.
- Disconnect the connector SV1 (gray) or SV2 (blue) on the multi controller circuit board in the electrical parts box.
- (9) Remove the electrical parts box. (See Photo 5)
- (10) Recover refrigerant.
- (11) Remove the welded part of bypass valve.

Refer to the notes below.


10. Removing the high pressure switch (63H) and high pressure sensor (63HS)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- Remove the cover panel (front), (Refer to procedure 8(5))
- Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Pull out the lead wire of high pressure switch and high pressure sensor.
- Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- Remove the welded part of high pressure switch and high pressure sensor.

Refer to the notes below.

PHOTOS/FIGURES

Photo 11




11. Removing the low pressure sensor (63LS)

- (1) Remove the service panel. (See Photo 1)
- Remove the top panel. (See Photo 1) (2)
- Remove the cover panel (front). (Refer to procedure 8(5))
- Remove the cover panel (rear) (Refer to procedure 8(6)) (4)
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- Disconnect the connector 63LS (blue) on the multi controller circuit board in the electrical parts box.
- Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of low pressure sensor.

Refer to the notes below.

Photo 12



valve

12. Removing linear expansion valve (LEV-A, LEV-B)

- (1) Remove the service panel. (See Photo 1)
- Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the linear expansion valve coil. (See Photo 11.12)
- Remove the electrical parts box. (See Photo 5)
- (8) Recover refrigerant.
- (9) Remove the welded part of linear expansion valve.

Refer to the notes on the right.

Notes:

1. Recover refrigerant without spreading it in the air.

valve coil (LEV-B)


- 2. The welded part can be removed easily by removing the side panel (R).
- 3. When installing the following parts, cover it with a wet cloth to prevent it from heating as the temperature below, then braze the pipes so that the inside of pipes are not oxidized;
- Bypass valve (procedure 9), 248°F [120°C] or more
- · High pressure switch and high pressure sensor (procedure 10), 212°F [100°C] or more
- Low pressure sensor (procedure 11), 212°F [100°C] or
- LEV (procedure 12), 248°F [120°C] or more


13. Removing the compressor (MC)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 8(5))
- (4) Remove the cover panel (rear) (Refer to procedure 8(6))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove 2 front cover panel fixing screws (5 × 12) and remove the cover panel (front). (See Photo 4)
- (7) Remove the electrical parts box. (See Photo 5)
- (8) Remove the valve bed. (Refer to procedure 8 (4))
- (9) Remove 3 separator fixing screws (4 × 10) and remove the separator. (See Figure 2)
- (10) Remove the comp felt covering the compressor, and remove the thermistor <Compressor> (TH4), thermal protector (TRS), and the lead wires. (See Photo 7 and 13)
- (11) Recover refrigerant.
- (12) Remove the 3 compressor fixing nuts for motor using spanner or adjustable wrench.
- (13) Remove the welded pipe of compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.

PHOTOS/FIGURES





14. Removing the accumulator


- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the cover panel (front). (Refer to procedure 13 (3))
- (4) Remove the cover panel (rear). (Refer to procedure 13 (5))
- (5) Remove the side panel (R). (Refer to procedure 8 (7))
- (6) Remove the electrical parts box. (See Photo 5)
- (7) Remove the valve bed. (See procedure 8 (4))
- (8) Recover refrigerant.
- (9) Remove 4 welded pipes of accumulator inlet and outlet.
- (10) Remove 2 accumulator leg fixing screws (4 × 10). (See Photo 15)

Note: Recover refrigerant without spreading it in the air.

Photo 14




Photo 15



15. Removing the reactor (DCL)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box (See Photo 5)
- (4) Remove 6 screws (4 x 10) for reactor to remove the reactors. (See Figure 3)

PHOTOS/FIGURES



16. Removing the base heater

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)
- (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2)
- (5) Remove all of the following connectors from multi controller circuit board:
 - <Diagram symbol in the connector housing>
 - Fan motor (CNF1, CNF2)
 - · Base heater (SS)

Pull out the disconnected wire from the electrical parts box. (See Photo 4)

- (6) Loosen the wire clamps on the side of the motor support and separator.
- (7) Remove 2 motor support fixing screws (5 x 12), then remove the motor support with fan motor still attached. (See Photo 16)
- (8) Remove 4 base heater cover fixing screws (4 x 10), then remove the base heater cover.
- (9) Remove the base heater. (See Photo 17)

Notes:

- 1. Tighten the propeller fan with a torque of 5.7 ± 0.3 N·m [4.2 ± 0.2 ft = lbs]
- Rotate the propeller fan and make sure that the base heater and the lead wires do not interfere with the movement of the propeller fan.

Photo 16




Photo 17




17. Changing the fusible plug

See the following descriptions.

- Be careful not to expose the fusible plug to the braze torch flame or transfer heat to it. (See Photo 18)
- The temperature of the fusible plug must not become 140°F (60°C) or more while working. Protect the fusible plug with a wet cloth when necessary.
- (The fusible plug breaks at 158°F [70°C]).
- Tighten the screw in 14 18 N·m* (11-13 lbf·ft) with 2 wrenches.
- *1 N·m ≈ 10 kgf·cm

PHOTOS/FIGURES


Photo 18



18. Removing the thermal protector (TRS))

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the cover panel front. (See Photo 1)
- (3) Pull out the lead wire of high pressure switch and disconnect the connector, 63H (yellow) from the multi controller board in the electrical parts box. (See Photo 11)
- (4) Remove the comp felt covering the compressor. (See Photo 13)
- (5) Loosen the clamp or band for the lead wire of the electrical parts box and separator.
- (6) Pull out the thermal protector (TRS) from the holder. (See Photo 19)

Photo 19



19. Removing the fuse holders

- (1) Remove the service panel. (See Photo 1)
- (2) Remove 2 screws (4 x 10) for cont base to remove the cont base. (See Figure 4)
- (3) Remove the fuse covers. (See Figure 5)
- (4) Remove screws (3 x 12) for fuse holders to remove the fuse holders. (See Figure 5 and Photo 20)

Notes:

- 1. Bracket, circuit board and other parts can get deformed when inserting and removing the fuse cover.
- 2. Remove the fuse cover in the way that surrounding parts will not be affected.

Photo 20

Fuse holders





Figure 4

Figure 5




12

REMOTE CONTROLLER

12-1. REMOTE CONTROLLER FUNCTIONS

<TAR-40MAA>


Controller interface



The functions of the function buttons change depending on the screen

Refer to the button function guide that appears at the bottom of the LCD for the functions they serve on a given screen.

When the system is centrally controlled, the button function guide that corresponds to the locked button will not appear.



① [ON/OFF] button

Press to turn ON/OFF the indoor unit.

② [SELECT/HOLD] button

Press to save the setting.

When the Main menu is displayed, pressing this button will enable/disable the HOLD function.

③ [RETURN] button

Press to return to the previous screen.

4 [MENU] button

Press to bring up the Main menu.

5 Backlit LCD

Operation settings will appear.

When the backlight is off, pressing any button turns the backlight on and it will stay lit for a certain period of time depending on the screen.

When the backlight is off, pressing any button turns the backlight on and does not perform its function. (except for the [ON/OFF] button)

6 ON/OFF lamp

This lamp lights up in green while the unit is in operation. It blinks while the remote controller is starting up or when there is an error.

Tunction button [F1]

Main display: Press to change the operation mode.

Menu screen: The button function varies with the screen.

® Function button [F2]

Main display: Press to decrease temperature.

Main menu: Press to move the cursor left.

Menu screen: The button function varies with the screen.

9 Function button [F3]

Main display: Press to increase temperature.

Main menu: Press to move the cursor right.

Menu screen: The button function varies with the screen.

① Function button [F4]

Main display: Press to change the fan speed.


Menu screen: The button function varies with the screen.

Display

The main display can be displayed in two different modes: "Full" and "Basic". The initial setting is "Full". To switch to the "Basic' mode, change the setting on the Main display setting. (Refer to operation manual included with remote controller.)

<Full mode>

All icons are displayed for explanation.



① Operation mode

② Preset temperature

3 Clock

4 Fan speed

⑤ Button function guide

Functions of the corresponding buttons appear here.

6

Appears when the ON/OFF operation is centrally controlled.

7 **0****

Appears when the operation mode is centrally controlled.

8

Appears when the preset temperature is centrally controlled.

9

Appears when the filter reset function is centrally controlled.

110

Indicates when filter needs maintenance.

① Room temperature


12 1

Appears when the buttons are locked.

Appears when the On/Off timer or Auto-off timer function is enabled.

appears when the timer is disabled by the centralized control system. appears when the HOLD function is enable.

<Basic mode>



(H) (P)

Appears when the Weekly timer is enabled.



Appears while the units are operated in the energy saving mode. (Will not appear on some models of indoor units)

16

Appears while the outdoor units are operated in the silent mode.

Appears when the built-in thermistor on the remote controller is activated to monitor the room temperature (①).

appears when the thermistor on the indoor unit is activated to monitor the room temperature.

18 70

Indicates the vane setting.

19 🗩 *

Indicates the louver setting.

② **※**

Indicates the ventilation setting.

(2) **[**3

Appears when the preset temperature range is restricted.

② **A** *1

Appears when an energy saving operation is performed using a "3D i-See sensor" function.

② Centrally controlled

Appears for a certain period of time when a centrally-controlled item is operated.


Preliminary error display

A check code appears during the preliminary error.


Most settings (except ON/OFF, mode, fan speed, temperature) can be made from the Main menu.

^{*1} These functions are not applied to the floor standing models.

Menu structure



Not all functions are available on all models of indoor units.



Not all functions are available on all models of indoor units.

Main menu list

Main menu	Setting and display items		Setting details
Operation	Ation Vane · Louver · Vent. (Lossnay) High power *3		Use to set the vane angle. • Select a desired vane setting. Use to turn ON/OFF the louver. • Select a desired setting from "ON" and "OFF." Use to set the amount of ventilation. • Select a desired setting from "Off," "Low," and "High."
			Use to reach the comfortable room temperature quickly. • Units can be operated in the High-power mode for up to 30 minutes.
	Comfort	Manual vane angle	Use to fix each vane angle.
		3D i-See sensor	Use to set the following functions for 3D i-See sensor. • Air distribution • Energy saving option • Seasonal airflow
Timer	Timer	ON/OFF timer *1	Use to set the operation ON/OFF times. • Time can be set in 5-minute increments.
		Auto-Off timer	Use to set the Auto-Off time. • Time can be set to a value from 30 to 240 in 10-minute increments.
Week	Weekly ti	mer *1, *2	Use to set the weekly operation ON/OFF times. • Up to 8 operation patterns can be set for each day. (Not valid when the ON/OFF timer is enabled.)
OU silent mode *1, *3		mode *1, *3	Use to set the time periods in which priority is given to quiet operation of outdoor units over temperature control. Set the Start/Stop times for each day of the week. •Select the desired silent level from "Normal," "Middle," and "Quiet."
Energy saving	Restriction	Temp. range *2	Use to restrict the preset temperature range. • Different temperature ranges can be set for different operation modes.
		Operation locked	Use to lock selected functions. • The locked functions cannot be operated.
	Energy saving	Auto return *2	Use to get the units to operate at the preset temperature after performing energy saving operation for a specified time period. • Time can be set to a value from 30 and 120 in 10-minute increments. (This function will not be valid when the preset temperature ranges are restricted.)
		Schedule *1, *3	Set the start/stop times to operate the units in the energy saving mode for each day of the week, and set the energy saving rate. • Up to 4 energy saving operation patterns can be set for each day. • Time can be set in 5-minute increments. • Energy saving rate can be set to a value from 0% or 50 to 90% in 10% increments.
Initial setting	Basic setting	Main/Sub	When connecting 2 remote controllers, one of them needs to be designated as a sub controller.
		Clock	Use to set the current time.
		Daylight saving time	Set the daylight saving time.
		Administrator password	The administrator password is required to make the settings for the following items. • Timer setting • Energy saving setting • Weekly timer setting • Restriction setting • Outdoor unit silent mode setting

^{*1} Clock setting is required. *2 2°F (1°C) increments.


^{*3} This function is available only when certain outdoor units are connected.

Main menu		and display items	Setting details
Initial setting	Display setting	Main display	Use to switch between "Full" and "Basic" modes for the Main display, and use to change the background colors of the display to black.
		Display de- tails	Make the settings for the remote controller related items as necessary. Clock: The initial settings are "Yes" and "24h" format. Temperature: Set either Celsius (°C) or Fahrenheit (°F). Room temp.: Set Show or Hide. Auto mode: Set Auto mode display or Only Auto display.
		Contrast • Brightness	Use to adjust screen contrast and brightness.
		Language selection	Use to select the desired language.
	Operation setting	Auto mode	Whether or not to use Auto mode can be selected by using the button. This setting is valid only when indoor units with Auto mode function are connected.
		Setback mode	Whether or not to use the Setback mode can be selected by using the button. This setting is valid only when indoor units with the Setback mode function are connected.
Maintenance Error info		ormation	Use to check error information when an error occurs. • Check code, error source, refrigerant address, model name, manufacturing number contact information (dealer's phone number) can be displayed. (The model name, manufacturing number, and contact information need to be registered in advance to be displayed.)
	Filter information		Use to check the filter status. • The filter sign can be reset.
	Cleaning	Auto descending panel	Use to lift and lower the auto descending panel (Optional parts).
	Test run		Select "Test run" from the Service menu to bring up the Test run menu. • Test run • Drain pump test run
	Input maintenance		Select "Input maintenance Info." from the Service menu to bring up the Maintenance information screen. The following settings can be made from the Maintenance Information screen. • Model name input • Serial No. input • Dealer information input • Initialize maintenance info.
	Settings	Function set- ting	Make the settings for the indoor unit functions via the remote controller as necessary.
	Check	Error history	Display the error history and execute "delete error history".
		Diagnosis	Self check: Error history of each unit can be checked via the remote controller. Remote controller check: When the remote controller does not work properly, use the remote controller checking function to troubleshoot the problem.
		Smooth main- tenance *1	Use to display the maintenance data of indoor/outdoor units.
		Request code	Use to check operation data such as thermistor temperature and error information.
	Others	Maintenance password	Use to change the maintenance password.
		Initialize re- mote control- ler	Use to initialize the remote controller to the factory shipment status.
		Remote con- troller infor- mation	Use to display the remote controller model name, software version, and serial number.

^{*1} This function is available only when certain outdoor units are connected.

OCHT810C 173

<PAR-FL32MA>




- When using the wireless remote controller, point it towards the receiver on the indoor unit.
- If the remote controller is operated within approximately two minutes after power is supplied to the indoor unit, the indoor unit may beep twice as the unit is performing the initial automatic check.
- The indoor unit beeps to confirm that the signal transmitted from the remote controller has been received.

 Signals can be received up to approximately 7 meters in a direct line from the indoor unit in an area 45 to the left and right of the unit.

 However, illumination such as fluorescent lights and strong light can affect the ability of the indoor unit to receive signals.
- If the operation lamp near the receiver on the indoor unit is blinking, the unit needs to be inspected. Consult your dealer for service.
- Handle the remote controller carefully. Do not drop the remote controller or subject it to strong shocks. In addition, do not get the remote controller wet or leave it in a location with high humidity.
- To avoid misplacing the remote controller, install the holder included with the remote controller on a wall
 and be sure to always place the remote controller in the holder after use.


<PAR-SL101A-E>

Controller interface



 This button is enabled or disabled depending on the model of the indoor unit.

Display



12-2. ERROR INFORMATION


When an error occurs, the following screen will appear. Check the error status, stop the operation, and consult your dealer.

1. Check code, error unit, refrigerant address, model name, and serial number will appear.

The model name and serial number will appear only if the information has been registered.

Press the F1 or F2 button to go to the next page.

Contact information (dealer's phone number) will appear if the information has been registered.



2. Press the F4 button or the [ON/OFF] button to reset the error that is occurring.


Errors cannot be reset while the ON/OFF operation is prohibited.

Select "OK" with the F4 button.

Error information 1/2
Error code A3
Error unit IU 8 Unit#1
Time Occurred 82/81 4:48
Model name
Serial No.

Reset error: Reset button

Page A Reset







Error reset

Error reset


Main menu: MENU

Navigating through the screens

• To go back to the Service menu [MENU] button

· Checking the error information

While no errors are occurring, page 2/2 of the error information can be viewed by selecting "Error information" from the Maintenance menu. Errors cannot be reset from this screen.



12-3. SERVICE MENU

Maintenance password is required

- 1. Select "Service" from the Main menu, and press the [SELECT] button.
 - *At the main display, the menu button and select "Service" to make the maintenance setting.



When the Service menu is selected, a window will appear asking for the password.

To enter the current maintenance password (4 numerical digits), move the cursor to the digit you want to change with the $\boxed{\text{F1}}$ or $\boxed{\text{F2}}$ button.




Set each number (0 through 9) with the F3 or F4 button.



Then, press the [SELECT] button.

Note: The initial maintenance password is "9999". Change the default password as necessary to prevent unauthorized access. Have the password available for those who need it.

If you forget your maintenance password, you can initialize the password to the default password "9999" by pressing and holding the F1 button for 10 seconds on the maintenance password setting screen.



3. If the password matches, the Service menu will appear.

Note: Air conditioning units may need to be stopped to make only at "Settings". There may be some settings that cannot be made when the system is centrally controlled.



A screen will appear that indicates the setting has been saved.

Navigating through the screens

- To go back to the Service menu [MENU] button
- To return to the previous screen...... [RETURN] button






12-4. TEST RUN

12-4-1. TAR-40MAA


1. Select "Service" from the Main menu, and press the [SELECT] button.



Select "Test run" with the F1 or F2 button, and press the [SELECT] button.



2. Select "Test run" with the F1 or F2 button, and press the [SELECT] button.



Test run operation


Press the F1 button to go through the operation modes in the order of "Cool and Heat".

Cool mode: Check the cold air blows out. Heat mode: Check the heat blows out.

Check the operation of the outdoor unit's fan.



Press the [SELECT] button and open the Vane setting screen.



Auto vane check

Check the auto vane with the F1 F2 buttons.



Press the [RETURN] button to return to "Test run operation".




Press the [ON/OFF] button.

When the test run is completed, the "Test run menu" screen will appear.

The test run will automatically stop after 2 hours.

*The function is available only for the model with vanes.




12-4-2. PAR-FL32MA

Measure an impedance between the power supply terminal block on the outdoor unit and ground with a 500 V Megger and check that it is equal to or greater than 1.0 M Ω .

- ① Turn on the main power to the unit.
- ② Press the button twice continuously. (Start this operation from the status of remote controller display turned off.)
 - A mand current operation mode are displayed.
- ③ Press the ☐ (♣♦♦ □) button to activate cool a mode, then check whether cool air blows out from the unit.
- ④ Press the ☐ (♣♦♦ ♦) button to activate HEAT mode, then check whether warm air blows out from the unit.
- ⑤ Press the button and check whether strong air blows out from the unit.
- Press the button and check whether the auto vane operates properly.
- ② Press the ON/OFF button to stop the test run.


Note:

- Point the remote controller towards the indoor unit receiver while following steps ② to ⑦.
- It is not possible to run in FAN, DRY or AUTO mode.



12-4-3. PAR-SL101A-E

- ① Press the ____ button ① to stop the air conditioner.
 - If the weekly timer is enabled (wearn is on), press the button ③ to disable it (wearn is off).
- ② Press the button ② for 5 seconds.
 - CHECK comes on and the unit enters the service mode.
- ③ Press the button ②.
 - 📧 🖲 comes on and the unit enters the test run mode.
- 4 Press the following buttons to start the test run.
 - Switch the operation mode between cooling and heating and start the test run.
 - : Switch the fan speed and start the test run.
 - Switch the airflow direction and start the test run.
 - Switch the louver and start the test run.
 - Start the test run.
- ⑤ Stop the test run.
 - Press the ____ button ① to stop the test run.
 - After 2 hours, the stop signal is transmitted.




12-5. FUNCTION SETTING

12-5-1. TAR-40MAA

1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Setting" from the Service menu, and press the [SELECT] button.


Select "Function setting", and press the [SELECT] button.



Set the indoor unit refrigerant addresses and unit numbers with the F1
through F4 buttons, and then press the [SELECT] button to confirm the
current setting.


Note: Checking the indoor unit No.

When the [SELECT] button is pressed, the target indoor unit will start fan operation. If the unit is common or when running all units, all indoor units for the selected refrigerant address will start fan operation.




When data collection from the indoor units is completed, the current settings appears highlighted.

Non-highlighted items indicate that no function settings are made. Screen appearance varies depending on the "Unit No." setting.



4. Use the F1 or F2 button to move the cursor to select the mode number, and change the setting number with the F3 or F4 button.




5. When the settings are completed, press the [SELECT] button to send the setting data from the remote controller to the indoor units.

When the transmission is successfully completed, the screen will return to the Function setting screen.

Note: • Make the above settings only on Mr. Slim units as necessary.


- The above function settings are not available for the CITY MULTI units.
- Refer to the indoor unit Installation Manual for the detailed information about initial settings, mode numbers, and setting numbers for the indoor units.
- Be sure to write down the settings for all functions if any of the initial settings has been changed after the completion of installation work.



12-5-2. PAR-FL32MA

Functions can be selected with the wireless remote controller. Function selection using wireless remote controller is available only for refrigerant system with wireless function. Refrigerant address cannot be specified by the wireless remote controller.


[Flow of function selection procedure]



Flow of function selection procedure

The flow of the function selection procedure is shown below. This example shows how to turn off the function that raises the set temperature by 4 degrees during HEAT operation.

The procedure is given after the flow chart.



or longer

area, the unit ends function selection mode automatically if nothing is input for 10 minutes

[Operating instructions]

- ① Check the function settings.
- $\textcircled{2} \text{ Press the } \overset{\text{CHECK}}{\bigsqcup} \text{ button twice continuously.} \rightarrow \overset{\text{CHECK}}{\bigsqcup} \text{ is lit and "00" blinks.}$

Press the TEMP (a) button once to set "50". Direct the IR wireless remote controller toward the receiver of the indoor unit and press the h button.

③ Set the unit number.

Press the TEMP (a) (b) button to set the unit number. (Press "01" to specify the indoor unit whose unit number is 01.)

Direct the IR wireless remote controller toward the receiver of the indoor unit and press the button.

By setting unit number with the button, specified indoor unit starts performing fan operation.

Detect which unit is assigned to which number using this function. If unit number is set to AL, all the indoor units in same refrigerant system start performing fan operation simultaneously.

Notes:

- 1. If a unit number that cannot be recognized by the unit is entered, 3 beeps of 0.4 seconds will be heard. Reenter the unit number setting.
- 2. If the signal was not received by the sensor, you will not hear a beep or a "double ping sound" may be heard. Reenter the unit number setting.
- Select a mode

Press the TEMP (2) button to set a mode. Press "24" to turn on the function that raises the set temperature by 4 degrees during heat operation. Direct the IR wireless remote controller toward the sensor of the indoor unit and press the

→ The sensor-operation indicator will blink and beeps will be heard to indicate the current setting number.

Current setting number: 1 = 1 beep (one second)

2 = 2 beeps (one second each)

3 = 3 beeps (one second each)

Notes:

- 1. If a mode number that cannot be recognized by the unit is entered, 3 beeps of 0.4 seconds will be heard. Reenter the mode number.
- 2. If the signal was not received by the sensor, you will not hear a beep or a "double ping sound" may be heard. Reenter the mode number.
- Select the setting number.

Press the TEMP (1) button to select the setting number. (02: Not available)

Direct the IR wireless remote controller toward the receiver of the indoor unit and press the _____ button.

→ The sensor-operation indicator will blink and beeps will be heard to indicate the setting number.

Setting number: 1 = 2 beeps (0.4 seconds each)

2 = 2 beeps (0.4 seconds each, repeated twice)

3 = 2 beeps (0.4 seconds each, repeated 3 times)

Notes:

- 1. If a setting number that cannot be recognized by the unit is entered, the setting will turn back to the original setting.
- 2. If the signal was not received by the sensor, you will not hear a beep or a "double ping sound" may be heard. Reenter the setting number.

182

- ® Repeat steps @ and ® to make an additional setting without changing unit number.
- ② Repeat steps ③ to ⑤ to change unit number and make function settings on it.
- ® Complete the function settings

Press (button.

Do not use the wireless remote controller for 30 seconds after completing the function setting.

12-5-3. PAR-SL101A-E




Fig. 1



2. Setting the unit number Press the button to set unit number (a). (Fig. 2)

press the SET button.

press the set button.

1. Going to the function select mode

[CHECK] is lit and "00" blinks. (Fig. 1) Press the button to set the "50".

Press the MENU button between of 5 seconds.



Fig. 2

3. Select a mode



Fig. 3

Press the button to set Mode number (B). (Fig. 3) Direct the wireless remote controller toward the receiver of the indoor unit and press the strip button. Current setting number: 1=1 beep (1 second) 2=2 beeps (1 second each) 3=3 beeps (1 second each)

(Start this operation from the status of remote controller display turned off.)

Direct the wireless remote controller toward the receiver of the indoor unit and

Direct the wireless remote controller toward the receiver of the indoor unit and



Fig. 4

4. Selecting the setting number Use the button to change the Setting number ©. (Fig. 4) Direct the wireless remote controller toward the receiver of the indoor unit and press the **SET** button. 5. To select multiple functions continuously

Repeat select 3 and 4 to change multiple function settings continuously. 6. Complete function selection

Direct the wireless remote controller toward the sensor of the indoor unit and press the OOFF/ON button.


Note: Be sure to write down the settings for all functions if any of the initial settings has been changed after the completion of installation work.

12-6. ERROR HISTORY

1. Select "Service" from the Main menu, and press the [SELECT] button.



Select "Check" with the $\boxed{\text{F1}}$ or $\boxed{\text{F2}}$ button, and press the $\boxed{\text{SELECT]}}$ button.




2. Select "Error history" with the F1 or F2 button, and press the [SELECT] button.



3. 16 error history records will appear.

4 records are shown per page, and the top record on the first page indicates the latest error record.



4. Deleting the error history

To delete the error history, press the F4 button (Delete) on the screen that shows error history.

A confirmation screen will appear asking if you want to delete the error history.




Press the F4 button (OK) to delete the history.



"Error history deleted" will appear on the screen.

Press the [RETURN] button to go back to the Check menu screen.



12-7. SELF-DIAGNOSIS

12-7-1. TAR-40MAA


1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Check" from the Service menu, and press the [SELECT] button.

Select "Diagnosis" from the Check menu, and press the [SELECT] button.

Select "Self check" with the F1 or F2 button, and press the [SELECT] button.


2. With the F1 or F2 button, enter the refrigerant address, and press the [SELECT] button.





3. Check code, unit number, attribute will appear.

"-" will appear if no error history is available.



When there is no error history



4. Resetting the error history

Press the F4 button (Reset) on the screen that shows the error history.



A confirmation screen will appear asking if you want to delete the error history.



Press the F4 button (OK) to delete the error history.

If deletion fails, "Request rejected" will appear.

"Unit not exist" will appear if no indoor units that are correspond to the entered address are found.

Navigating through the screens

- To go back to the Service menu [MENU] button
- To return to the previous screen............. [RETURN] button






12-7-2. PAR-FL32MA

When a malfunction occurs to air conditioner, both indoor unit and outdoor unit will stop and operation lamp blinks to inform unusual stop.


<Malfunction-diagnosis method at maintenance service>



[Procedure]

- 1. Press the CHECK button twice.
 - "CHECK" lights, and refrigerant address "00" blinks.
 - Check that the remote controller's display has stopped before continuing.
- 2. Press the TEMP (1) (a) buttons.
 - Select the refrigerant address of the indoor unit for the self-diagnosis. Note: Set refrigerant address using the outdoor unit's DIP switch (SW1). (For more information, see the outdoor unit installation manual.)
- 3. Point the remote controller at the sensor on the indoor unit and press the HOUR button.
 - If an air conditioner error occurs, the indoor unit's sensor emits an intermittent buzzer sound, the operation light blinks, and the check code is output.
 - (It takes 3 seconds at most for check code to appear.)
- 4. Point the remote controller at the sensor on the indoor unit and press the ON/OFF button.
 - The check mode is cancelled.

12-7-3. PAR-SL101A-E



[Procedure]

- 1. Press the ____ button ① to stop the air conditioner.
 - If the weekly timer is enabled (WEXT) is on), press the to disable it (WEXT) is off).
- 2. Press the button 2 for 5 seconds.
 - CHECK (A) comes on and the unit enters the self-check mode.
- Press the button s to select the refrigerant address (M-NET address) of the indoor unit for which you want to perform the self-check.
- 4. Press the set button 4.
 - If an error is detected, the check code is indicated by the number of beeps from the indoor unit and the number of blinks of the OPERATION INDICATOR lamp.
- 5. Press the ____ button ①.
 - IMEM (A) and the refrigerant address (M-NET address) (B) go off and the self-check is completed.

12-8. REMOTE CONTROLLER CHECK

If operations cannot be completed with the remote controller, diagnose the remote controller with this function.

 Select "Service" from the Main menu, and press the [SELECT] button.




Select "Check" from the Service menu, and press the [SELECT] button.



Select "Diagnosis" from the Check menu, and press the [SELECT] button.



Select "Remote controller check" with the F1 or F2 button, and press the [SELECT] button.




2. Select "Remote controller check" from the Diagnosis menu, and press the [SELECT] button to start the remote controller check and see the check results.



To cancel the remote controller check and exit the "Remote controller check" menu screen, press the [MENU] or the [RETURN] button.



The remote controller will not reboot itself.



3. OK: No problems are found with the remote controller. Check other parts for problems.

E3, 6832: There is noise on the transmission line, or the indoor unit or another remote controller is faulty. Check the transmission line and the other remote controllers.

NG (ALL1): Send-receive circuit fault. The remote controller needs replacing.

ERC:

The number of data errors is the discrepancy between the number of bits in the data transmitted from the remote controller and that of the data that was actually transmitted over the transmission line. If data errors are found, check the transmission line for external noise interference.



If the [SELECT] button is pressed after the remote controller check results are displayed, remote controller check will end, and the remote controller will automatically reboot itself.

Check the remote controller display and see if anything is displayed (including lines). Nothing will appear on the remote controller display if the correct voltage (8.5–12 VDC) is not supplied to the remote controller. If this is the case, check the remote controller wiring and indoor units.

Remote controller check results screen



12-9. SMOOTH MAINTENANCE


1. Select "Service" from the Main menu, and press the [SELECT] button.



Select "Check" with the F1 or F2 button, and press the [SELECT] button.



Select "Smooth maintenance" with the F1 or F2 button, and press the [SELECT] button.



2. Set each item.

Select the item to be changed with the F1 or F2 button.




Select the required setting with the F3 or F4 button.

- ■<Ref.address>setting [0]-[15]
- Stable mode>setting [Cool]/ [Heat]/ [Normal]

Press the [SELECT] button, Fixed operation will start.


Note: Stable mode will take approx. 20 minutes.






3. The operation data will appear.

The Compressor-Accumulated operating (COMP. run) time is 10-hour unit, and the Compressor-Number of operation times (COMP. ON/OFF) is a 100-time unit (fractions discarded).








Navigating through the screens

- To go back to the Service menu [MENU] button
- To return to the previous screen [RETURN] button




12-10. REQUEST CODE

Details on the operation data including each thermistor temperature and error history can be confirmed with the remote controller.

1. Select "Service" from the Main menu, and press the [SELECT] button.

Select "Check" with the F1 or F2 button, and press the [SELECT] button.

Select "Request code" with the F1 or F2 button, and press the [SELECT] button.



Request code

Ref.address

F1

MENU

Request code

Request: SELECT ▼Cur.

F2

RETUR

F3

F4

ON

2. Set the Refrigerant address and Request code.

Select the item to be changed with the F1 or F2 button.

Select the required setting with the F3 or F4 button.

- ■<Ref.address>setting [0]-[15]
- ■<Reguest code>setting

Press the [SELECT] button, Data will be collected and displayed.

Request code ▶ Ref.address Request code **PP4** (69) Request: SELECT ▼ Cur.

Request code: 004 Discharge temperature: 69°C

MITSUBISHI ELECTRIC TRANE HVAC US LLC

HEAD OFFICE: 1340 SATELLITE BOULEVARD, SUWANEE, GA 30024 USA

©Copyright 2023 MITSUBISHI ELECTRIC CORPORATION

Issued: Nov. 2024 No. OCHT810C Issued: Dec. 2023 No. OCHT810B Issued: Sep. 2023 No. OCHT810A Published: Mar. 2023 No. OCHT810 Made in Japan

Specifications are subject to change without notice.